

[Manuals.plus](#) /

› [FURORA LIGHTING](#) /

› FURORA LIGHTING Desmet V9636-5 2-Light Wall Sconce User Manual

FURORA LIGHTING V9636-5

FURORA LIGHTING Desmet V9636-5 2-Light Wall Sconce User Manual

Model: V9636-5

1. PRODUCT OVERVIEW

The FURORA LIGHTING Desmet V9636-5 is a 2-light wall sconce designed to enhance your outdoor living spaces. Featuring a transitional style with a black finish and an elegant black shade, this fixture is compatible with both incandescent and LED light sources. Its robust construction is intended for wall-mount installation.





Image 1.1: Front view of the FURORA LIGHTING Desmet V9636-5 2-Light Wall Sconce, showcasing its black finish and cylindrical design.

Key Features:

- Black finish for a sleek appearance.
- Transitional style suitable for various outdoor decors.
- LED compatible, offering energy-efficient lighting options.
- Designed for outdoor wall-mount installation.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these safety precautions during installation and operation.

- **Disconnect Power:** Always turn off the electrical power at the circuit breaker or fuse box before beginning

installation or performing any maintenance.

- **Qualified Electrician:** If you are unsure about the installation process, consult a qualified electrician.
- **Proper Wiring:** Ensure all electrical connections are made in accordance with local codes and ordinances.
- **Grounding:** This fixture must be properly grounded.
- **Bulb Wattage:** Do not exceed the maximum wattage specified for this fixture (250 watts).
- **Outdoor Use Considerations:** While rated for outdoor use, the product specifications indicate it is **Not Water Resistant**. To ensure longevity and prevent damage, install this fixture in a covered outdoor area where it will not be directly exposed to heavy rain or snow.
- **Handle with Care:** The fixture contains glass components. Handle with care to prevent breakage.

3. PACKAGE CONTENTS

Carefully unpack your new light fixture and lay out all parts on a clear surface. Ensure all components are present before discarding packaging materials.

- Light Fixture (1)
- Mounting Hardware (screws, wire nuts, mounting plate) (estimated)
- Installation Instructions (this manual)

Note: Bulbs are typically not included and must be purchased separately.

4. SETUP AND INSTALLATION

Follow these general steps for installing your wall sconce. Specific details may vary based on your electrical box and wall type. Always refer to local electrical codes.

1. Prepare for Installation:

- Turn off power at the main circuit breaker.
- Ensure the mounting surface is clean, dry, and structurally sound.

2. Attach Mounting Plate:

- Secure the mounting plate to the electrical junction box using the provided screws.

3. Make Electrical Connections:

- Connect the fixture's ground wire to the house ground wire (usually bare copper or green) using a wire nut.
- Connect the fixture's white wire to the house white (neutral) wire.
- Connect the fixture's black wire to the house black (hot) wire.
- Ensure all connections are secure and covered with wire nuts.

4. Mount the Fixture:

- Carefully align the fixture with the mounting plate and secure it with the provided screws or nuts.


5. Install Bulbs:

- Insert the appropriate light bulbs (not included) into the sockets. Do not exceed 250 watts total.

6. Restore Power:

- Turn the power back on at the circuit breaker and test the fixture.

Surface Wall Mount



D: 6"

Image 4.1: Dimensional drawing of the wall sconce, showing approximate measurements: Height (H) 18 inches, Depth (D) 6 inches, and Extension (E) 8.75 inches.

5. OPERATING INSTRUCTIONS

Once installed and powered, the FURORA LIGHTING Desmet V9636-5 wall sconce operates like any standard light fixture. It is designed to be controlled via a wall switch or a compatible remote control system, as indicated in its specifications.

- **Wall Switch Control:** Flip the connected wall switch to the "ON" position to illuminate the fixture. Flip to "OFF" to turn it off.
- **Remote Control (if applicable):** If integrated with a remote control system, follow the instructions provided with your remote for pairing and operation.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:**
 - Ensure power is off before cleaning.
 - Wipe the fixture with a soft, dry, or slightly damp cloth.
 - Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:**
 - Turn off power at the circuit breaker.
 - Allow bulbs to cool completely before touching.
 - Unscrew old bulbs and replace with new ones of the correct type and wattage (GU24 base, max 250 watts total).
- **Inspection:** Periodically inspect the fixture for any signs of wear, loose connections, or damage.

7. TROUBLESHOOTING

If your light fixture is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	• Power is off at the switch or breaker. • Loose wire connections. • Defective bulb.	• Ensure power is on. • Check wire connections (with power off). • Replace bulb.

Problem	Possible Cause	Solution
Light flickers.	• Loose bulb. • Loose wire connections. • Incorrect bulb type.	• Tighten bulb. • Check wire connections (with power off). • Ensure correct bulb type and wattage.
Fixture appears damaged.	• Physical impact. • Exposure to harsh weather (despite outdoor rating, it's not water resistant).	• Contact customer support for replacement parts or advice. • Consider relocating to a more sheltered outdoor area.

If these steps do not resolve the issue, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	FURORA LIGHTING
Model Number	V9636-5
Product Dimensions	6 x 6 x 18 inches
Item Weight	4.46 pounds
Color	Black
Material	Metal, Glass
Style	Transitional
Light Fixture Form	Sconce
Specific Uses For Product	Outdoor
Indoor/Outdoor Usage	Outdoor
Power Source	Corded Electric
Installation Type	Wall Mount
Control Method	Remote (compatible)
Light Source Type	Incandescent, LED
Finish Type	Black Finish
Shade Material	Glass
Number of Light Sources	2
Voltage	120 Volts (AC)

Feature	Detail
Wattage	250 watts (max total)
Bulb Base	GU24
Water Resistance Level	Not Water Resistant
Assembly Required	Yes
UPC	748066596364

9. WARRANTY AND SUPPORT

FURORA LIGHTING products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or visit the official FURORA LIGHTING website.

If you require technical assistance, have questions about installation, or need to report a missing/damaged part, please contact FURORA LIGHTING customer support through their official channels. You can often find contact information on the product packaging or the brand's website:

FURORA LIGHTING Store: [Visit the FURORA LIGHTING Store on Amazon](#)

© 2023 FURORA LIGHTING. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00BMT421G>

More documents and user manuals: <https://manuals.plus/>