

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GUESS](#) /

› [GUESS Men's Rigor Iconic Blue Stain Resistant Silicone Watch U0247G3 Instruction Manual](#)

GUESS U0247G3

GUESS Men's Rigor Iconic Blue Stain Resistant Silicone Watch Instruction Manual

Model: U0247G3

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your GUESS Men's Rigor Iconic Blue Stain Resistant Silicone Watch (Model U0247G3). Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.

PRODUCT FEATURES

- Iconic Blue Multi-Function Dial:** Displays time, day, and date.
- Day and Date Functions:** Integrated subdials for convenient tracking of the day of the week and date.
- 46 MM Case Size:** Features a robust 46mm case for a prominent wrist presence.
- Durable Mineral Crystal:** Protects the watch dial from scratches and impacts.
- Brushed Rose Gold-Tone Case with Blue Top Ring:** A stylish combination of finishes and colors.
- Comfortable Iconic Blue Stain Resistant Silicone Strap:** Designed for durability and comfort, with resistance to staining.
- Buckle Closure:** Secure and adjustable strap fastening.

SETUP

Setting the Time

1. Pull the crown (the small knob on the side of the watch case) out to the second click position.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time. Ensure AM/PM is correctly set if your watch has a 24-hour indicator or if setting the date.
3. Push the crown back into its normal position to start the watch.

Setting the Date and Day

1. Pull the crown out to the first click position.
2. Turn the crown clockwise to adjust the date.
3. Turn the crown counter-clockwise to adjust the day of the week.
4. Once the date and day are set, push the crown back into its normal position.

Note: Avoid setting the date and day between 9:00 PM and 3:00 AM, as this can interfere with the automatic date change mechanism.

OPERATING YOUR WATCH

Wearing the Watch

Place the watch on your wrist and adjust the silicone strap using the buckle closure until it fits comfortably. The strap should be snug enough to prevent the watch from sliding around, but not so tight as to restrict circulation.

Using Multi-Function Dials

Your watch features multi-function subdials for day and date display. These will automatically advance once set correctly. No additional operation is typically required for these functions after initial setup.

MAINTENANCE

General Care

- Clean your watch regularly with a soft, dry cloth to remove dust and dirt.
- For the silicone strap, use a mild soap and water solution if necessary, then rinse thoroughly and dry completely. The strap is stain resistant, but regular cleaning helps maintain its appearance.
- Avoid exposing your watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- The mineral crystal is durable but not scratch-proof. Avoid contact with abrasive surfaces.

Water Resistance

While your watch may offer some water resistance, it is important to understand its limitations. Avoid submerging the watch in water unless its specific water resistance rating (usually indicated on the case back) permits it. Do not operate the crown or pushers when the watch is wet.

Battery Replacement

This watch uses a Lithium Metal battery. When the watch stops or the second hand moves erratically, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch stops or loses time	Low battery	Replace battery by a professional.
Date/Day not changing	Incorrectly set, or set during restricted hours	Reset date/day outside of 9 PM - 3 AM.
Condensation inside crystal	Exposure to extreme temperature changes or moisture ingress	Consult a watch technician immediately to prevent damage.

If you encounter issues not listed here, or if the suggested solutions do not resolve the problem, please contact GUESS customer support or an authorized service center.

SPECIFICATIONS

- **Model Number:** U0247G3
- **Case Material:** Brushed Rose Gold-Tone
- **Strap Material:** Stain Resistant Silicone (Blue)
- **Dial Color:** Iconic Blue Multi-Function
- **Case Diameter:** 46 mm
- **Crystal:** Mineral
- **Movement:** Quartz
- **Functions:** Hour, Minute, Second, Day, Date
- **Battery:** 1 Lithium Metal battery (included)
- **Product Dimensions:** 5.31 x 5.12 x 5.31 inches
- **Item Weight:** 7.05 ounces
- **Manufacturer:** GUESS
- **Date First Available:** August 15, 2013

PRODUCT VISUALS



Front view of the GUESS Men's Rigor Iconic Blue Stain Resistant Silicone Watch, showcasing the blue multi-function dial and rose gold-tone case.



Detail of the blue stain-resistant silicone strap and buckle closure.



Side profile of the watch, highlighting the rose gold-tone case and crown.

OFFICIAL PRODUCT VIDEO

This video provides a detailed 360-degree view of the GUESS Men's Rigor Iconic Blue Stain Resistant Silicone Watch, showcasing its design and features.

WARRANTY AND SUPPORT

Your GUESS watch is covered by a limited warranty against manufacturing defects. For specific warranty terms, registration, and support inquiries, please refer to the warranty card included with your purchase or visit the official GUESS Watches website. Keep your proof of purchase for warranty claims. For further assistance, you may contact GUESS customer service through their official channels.

© 2024 GUESS Watches. All rights reserved.