

[Manuals.plus](#) /

› [Winsome](#) /

› Winsome Timmy Accent Table (Model 20315) Instruction Manual

Winsome 20315

Winsome Timmy Accent Table (Model 20315) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Winsome Timmy Accent Table, Model 20315. This versatile piece of furniture is designed to function as an accent table or nightstand, featuring three drawers for convenient storage and an ample top surface. Its transitional style and black finish allow it to complement various home decors.

Please read these instructions carefully before beginning assembly to ensure proper setup and safe use of the product.



Figure 1: Fully assembled Winsome Timmy Accent Table.

SAFETY INFORMATION

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Assemble the unit on a soft, clean surface to prevent scratching.
- Do not overtighten screws or fasteners, as this may damage the material.

- This table has a maximum weight recommendation of 25 pounds. Do not exceed this limit.
- Keep small parts and packaging materials away from children during assembly.
- Once assembled, place the table on a level surface to prevent wobbling.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present in your package. If any items are missing or damaged, please contact customer support.

- Tabletop
- Side Panels (2)
- Back Panel
- Bottom Panel
- Drawer Fronts (3)
- Drawer Side Panels (6)
- Drawer Back Panels (3)
- Drawer Bottom Panels (3)
- Drawer Knobs (3)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Assembly Tool (Allen wrench/screwdriver)



Figure 2: Example of table components prior to assembly.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Winsome Timmy Accent Table is required. All necessary assembly tools are included in the package. Follow the step-by-step guide provided with your product for detailed instructions. The general steps are outlined below:

1. **Unpack and Organize:** Carefully remove all components from the packaging. Lay them out on a clean,

soft surface. Identify each part using the labels or diagrams in your product-specific assembly guide.

2. **Assemble the Frame:** Attach the side panels to the bottom and back panels using the provided hardware (dowels, screws, cam locks). Ensure all connections are secure but do not overtighten.
3. **Attach the Tabletop:** Secure the tabletop to the assembled frame.
4. **Assemble the Drawers:** For each of the three drawers, connect the drawer side panels, back panel, and bottom panel to the drawer front. Install the drawer knobs.
5. **Install Drawers:** Carefully slide the assembled drawers into their respective slots. Ensure they glide smoothly. If a drawer does not slide smoothly, check the alignment of the rails and adjust the screws as needed.

For enhanced stability, consider applying wood glue to dowel connections during assembly. Allow sufficient drying time before moving the table.

Your browser does not support the video tag.

Video 1: A detailed overview of the Winsome Timmy Accent Table, including assembly tips and features. This video provides a helpful visual guide before you begin the assembly process.

Your browser does not support the video tag.

Video 2: A review highlighting the assembly process and final appearance of the Winsome Timmy Accent Table, offering insights into what to expect during setup.

Your browser does not support the video tag.

Video 3: An influencer's perspective on the Winsome Timmy Accent Table, covering its features and the assembly experience.

OPERATING INSTRUCTIONS

The Winsome Timmy Accent Table is designed for straightforward use.

- **Drawer Use:** The three drawers are equipped with smooth-gliding mechanisms. To open, gently pull the knob. To close, push the drawer firmly until it is flush with the table frame.
- **Top Surface:** The top surface provides ample space for lamps, books, decorative items, or other essentials. Ensure items placed on top do not exceed the maximum weight recommendation of 25 pounds.



Figure 3: Winsome Timmy Accent Table with drawers open, demonstrating storage capacity.

MAINTENANCE

Proper care will help maintain the appearance and longevity of your accent table.

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or

polishes that may damage the finish.

- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood.
- **Protection:** Use coasters under beverages and protective pads under hot items to prevent marks on the tabletop.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your Winsome Timmy Accent Table, refer to the following common solutions:

- **Wobbling Table:** Ensure the table is placed on a level surface. Check all assembly connections and tighten any loose screws.
- **Drawers Not Sliding Smoothly:** Verify that the drawer rails are correctly aligned and securely fastened. Adjust the screws on the rails if needed. Ensure no debris is obstructing the drawer glides.
- **Minor Scratches/Blemishes:** Small imperfections can sometimes occur during shipping. For minor scuffs, a furniture touch-up pen matching the black finish may be used.
- **Odor:** New furniture may have a slight odor from manufacturing. This typically dissipates within a few days. Ensure the room is well-ventilated.

SPECIFICATIONS

Brand	Winsome
Model Number	20315
Product Dimensions (D x W x H)	15.75"D x 15.75"W x 23.62"H
Item Weight	28.7 Pounds
Maximum Weight Recommendation	25 Pounds
Frame Material	Engineered Wood
Color	Black
Number of Drawers	3
Drawer Interior Dimensions (W x D x H)	10.1" x 13.3" x 3.9" each
Finish Type	Painted
Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes
Includes All Assembly Tools	Yes



Figure 4: Winsome Timmy Accent Table with key dimensions.

WARRANTY AND SUPPORT

Winsome Trading, Inc. provides a manufacturer's warranty for replacement parts up to 60 days from the date of purchase. Please retain your proof of purchase for warranty claims.

For assistance with missing parts, damaged components, or assembly questions, please refer to the contact information provided in your product packaging or on the Winsome official website. When contacting support, please have your model number (20315) and purchase date readily available.