#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > PROFLO /
- > PROFLO Amador PF9312 Toilet Tank Only User Manual

#### PROFLO PF9312

# PROFLO Amador PF9312 Toilet Tank Only User Manual

Model: PF9312

## 1. Introduction

This manual provides essential instructions for the proper installation, operation, and maintenance of your PROFLO Amador PF9312 Toilet Tank. Please read this manual thoroughly before beginning installation or use to ensure safe and efficient performance. This product is a toilet tank only and requires a coordinating toilet bowl for complete installation.



Image 1.1: The PROFLO Amador PF9312 Toilet Tank. This image displays the white vitreous china toilet tank with its flush lever on the side.

## 2. SAFETY INFORMATION

Observe all local plumbing and building codes during installation. Always wear appropriate personal protective equipment, such as safety glasses and gloves, when handling plumbing fixtures and tools. Ensure the water supply is turned off before beginning any installation or maintenance work. If you are unsure about any part of the installation process, consult a qualified plumber.

## 3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- PROFLO Amador PF9312 Toilet Tank (Vitreous China, White)
- Internal tank components (flush valve, fill valve, flush lever)
- Tank-to-bowl bolts and gasket (typically included with tank)

**Note:** A toilet bowl, toilet seat, and wax ring/flange bolts are sold separately and are required for a complete toilet installation.

## 4. SETUP AND INSTALLATION

## 4.1 Preparation

- 1. Turn off the water supply to the toilet area.
- 2. Remove any existing toilet tank and clean the area around the toilet bowl's mounting surface.
- 3. Ensure the rough-in dimension (distance from the wall to the center of the drain pipe) is 12 inches for proper fitment.

#### 4.2 Tank Installation

- 1. Place the tank-to-bowl gasket onto the flush valve opening at the bottom of the toilet tank.
- 2. Carefully align the tank with the bolt holes on the toilet bowl.
- 3. Insert the tank-to-bowl bolts through the tank and bowl holes. Secure with washers and nuts from underneath the bowl, tightening evenly until the tank is stable and does not rock. Avoid overtightening to prevent cracking the vitreous china.
- 4. Connect the water supply line to the fill valve shank at the bottom of the tank. Hand-tighten, then use a wrench for a final quarter-turn.
- 5. Turn on the water supply slowly and check for leaks. Allow the tank to fill.



Image 4.1: The PROFLO Amador PF9312 Toilet Tank shown installed on a compatible toilet bowl. Note that the bowl and seat are separate components.

## 5. OPERATING INSTRUCTIONS

To operate the toilet, simply press down on the flush lever located on the side of the tank. This action lifts the flush valve, allowing water to flow from the tank into the toilet bowl, initiating the flush cycle. Release the lever once the flush is complete. The tank will then refill automatically.

## 6. MAINTENANCE

## 6.1 Cleaning

Clean the exterior of the toilet tank with a soft cloth and mild, non-abrasive cleaning agents. Avoid harsh chemicals or abrasive scrubbers, as these can damage the vitreous china finish. For internal components, periodic inspection for mineral buildup is recommended. Use a toilet bowl cleaner specifically designed for internal tank use if necessary, following the product's instructions.

## **6.2 Component Inspection**

Periodically inspect the fill valve, flush valve, and flush lever for proper function and wear. Ensure the flapper or seal is seating correctly to prevent leaks. Adjust the water level if needed, typically by adjusting the fill valve float mechanism according to the manufacturer's instructions for the specific fill valve model.

### 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tank does not fill or fills slowly	Water supply turned off; clogged fill valve; kinked supply line.	Ensure water supply is on; clean or replace fill valve; straighten supply line.
Tank continuously runs or leaks	Flapper not sealing properly; fill valve not shutting off; water level too high.	Inspect/replace flapper; adjust or replace fill valve; adjust water level.
Weak flush	Low water level in tank; clogged siphon jet or rim holes in bowl (bowl issue).	Adjust water level to correct height; clean bowl's siphon jet and rim holes (refer to bowl manual).

For issues not listed here or if troubleshooting steps do not resolve the problem, contact PROFLO customer support or a qualified plumber.

#### 8. Specifications

Model: PF9312

Material: Vitreous China

Color: White

Item Weight: 31.8 pounds

**Product Dimensions:** 16.6 x 9.6 x 14.75 inches (Length x Width x Height)

Installation Method: Floor Mounted (tank to bowl)

Rough-In Dimension: 12 inches

**Included Components:** Toilet Tank Only

#### 9. WARRANTY AND SUPPORT

PROFLO products are factory tested to ensure flawless function. This PROFLO toilet tank is covered under PROFLO's Fixtures warranty for one year after installation. For specific warranty details, claims, or technical support, please refer to the official PROFLO website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty purposes.

#### Related Documents - PF9312



#### PROFLO PF1400T Series Dual Flush Two Piece Toilet - Product Specifications

Comprehensive product specifications, features, model details, dimensions, and certifications for the PROFLO PF1400T Series Dual Flush Two Piece Toilet. Includes warranty information and installation guidance.



#### PROFLO HET Toilet Bowl and Tank Installation Instructions (1.28 GPF)

Comprehensive installation guide for the PROFLO HET Toilet Bowl and Tank, featuring 1.28 gallons per flush. Includes tools needed, removal of old toilet, installation steps, adjustments, troubleshooting, and warranty information.




#### PROFLO PF6112WH 1.28 gpf Closet Tank Parts Breakdown and Warranty Information

Detailed parts breakdown for the PROFLO PF6112WH 1.28 gpf closet tank. Includes a list of available tank lids, internal components with part numbers, and warranty details. Features textual descriptions of diagrams and components.




#### PROFLO HET Two-Piece Universal Series Toilet/Tank Installation Instructions

This document provides comprehensive installation instructions for the PROFLO HET Two-Piece Universal Series Toilet/Tank, covering both skirted and exposed bowl models. It includes a list of necessary tools and included parts, step-by-step guidance for removing the old toilet and installing the new one, and troubleshooting tips.



#### PROFLO Toilet Seat Installation and Cleaning Guide

Comprehensive guide for installing and cleaning PROFLO toilet seats, including models PFTSHEC1000WH, PFTSHEC1000BS, PFTSHEC2000WH, and PFTSHEC2000BS. Features easy installation steps and lift-and-pull cleaning instructions.



#### PROFLO Toilet Seat Installation and Cleaning Guide

Step-by-step instructions for installing and cleaning PROFLO toilet seats, including models PFTSEC1000WH, PFTSEC2000WH, and PFTSEC2000BS. Features easy installation and lift-and-pull cleaning methods.