

Napoleon NEFL42FH

Napoleon Allure 42-inch Wall Mount Electric Fireplace

Model: NEFL42FH

Brand: Napoleon

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Napoleon Allure 42-inch Wall Mount Electric Fireplace. Please read all instructions carefully before installation and use to ensure proper function and safety.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons. Keep combustible materials at least 3 feet (0.9 m) from the front of the fireplace. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fireplace. This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep children away. Do not operate any fireplace with a damaged cord or plug, or if the fireplace has been dropped or damaged in any manner. Disconnect power before performing any maintenance or cleaning.

PACKAGE CONTENTS

Before beginning installation, ensure all components are present and undamaged. If any parts are missing or damaged, do not attempt to assemble or operate the fireplace. Contact customer service for assistance.

- Napoleon Allure 42-inch Electric Fireplace Unit
- Remote Control (with 1 CR2 battery included)
- Mounting Bracket and Hardware
- Crystal Cube Ember Bed Media
- User Manual

SETUP AND INSTALLATION

The Napoleon Allure 42-inch Electric Fireplace offers versatile installation options: wall-mounted or fully recessed.

Wall Mount Installation

1. Choose a suitable location on a wall, ensuring it is away from drapes, furniture, and high-traffic areas.
2. Secure the mounting bracket to the wall studs using the provided hardware. Ensure the bracket is level.
3. Carefully lift the fireplace unit and hook it onto the wall mounting bracket.
4. Plug the fireplace into a standard 120V AC outlet.

Recessed Installation

1. Construct a framed opening in the wall that matches the dimensions of the fireplace for a flush fit. Refer to the product specifications for exact cutout dimensions.
2. Ensure there is adequate clearance around the unit for ventilation and electrical connections.
3. Slide the fireplace unit into the framed opening and secure it using the appropriate fasteners.
4. Connect the fireplace to a dedicated 120V AC circuit.




Image: The Napoleon Allure 42-inch electric fireplace seamlessly integrated into a modern kitchen wall, demonstrating a typical installation scenario.



Image: A side profile of the Napoleon Allure 42-inch electric fireplace, illustrating its compact depth suitable for both wall-mount and recessed installations.

OPERATING INSTRUCTIONS

Your Napoleon Allure electric fireplace can be operated using the touch-sensitive manual controls located on the unit or the included multi-function remote control.

Manual Controls

The touch-sensitive controls are located on the front panel of the fireplace. These allow you to power the unit on/off, adjust flame colors and brightness, control the heater, and set the timer.



Image: A detailed view of the touch-sensitive control panel on the fireplace, showing icons for power, temperature, timer, heat, and flame color options.

Remote Control Operation

The remote control provides full functionality from a distance.

QUICKLY HEAT LARGE ROOMS
UP TO 400 SQUARE FEET

FRONT GLASS STAYS
COOL TO THE TOUCH



MESH SCREEN FRONT
PROVIDES "GLARE-FREE"
VIEW OF THE FLAMES

CRYSTAL CUBE EMBER BED

Image: The sleek black remote control for the Napoleon Allure fireplace, featuring dedicated buttons for power, timer, thermostat, heater, and distinct blue and orange flame controls.



Image: An illustrative diagram mapping the remote control buttons to their respective functions, including power, orange flame brightness, blue flame brightness, heater control, and timer settings.

Flame Effects

The fireplace features LED lit dancing flame effects with crystal cube ember bed. You can choose from three flame color options:

- **Blue Flames:** Provides a modern, cool ambiance.
- **Orange Flames:** Mimics a traditional wood-burning fire.
- **Combination:** A blend of blue and orange for a unique visual experience.

Adjust the brightness settings for each flame color using the remote control or manual buttons.



Image: The Napoleon Allure 42-inch electric fireplace showcasing its vibrant blue flame effect, emanating from the crystal cube ember bed.



Image: The Napoleon Allure 42-inch electric fireplace displaying a classic, warm orange flame effect, simulating a traditional fire.




Image: The Napoleon Allure 42-inch electric fireplace featuring a dynamic combination of blue and orange flames, creating a unique and captivating visual.

Heater Operation

The integrated fan-forced heater provides supplemental warmth for areas up to 400 sq. ft. It features a thermostatic control, allowing you to set your desired room temperature. The heater vents from the top center of the unit for even heat distribution. The heater can be operated independently of the flame effects, allowing for year-round enjoyment.

Timer Function

Use the timer function to set the fireplace to automatically turn off after a specified duration. This is useful for energy saving and convenience.



- ⦿ POWER - TURNS THE APPLIANCE ON/OFF.
- ⦿ ORANGE FLAME - CONTROLS FLAME BRIGHTNESS.
- ⦿ BLUE FLAME - CONTROLS FLAME BRIGHTNESS.
- ⦿ HEATER - CONTROLS THE HEATER.
- ⦿ TIMER - CONTROLS THE TIMER.



Image: A visual breakdown of the fireplace's key operational features, including the 5000 BTU heater, thermostatic control, realistic flame illusion, and the multi-function remote.




Image: An infographic illustrating the functional benefits of the fireplace, such as its heating capacity for large rooms, cool-to-touch front glass, glare-free mesh screen, and the aesthetic crystal cube ember bed.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace. Always disconnect power before performing any maintenance.

Cleaning

- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Glass Panel:** Clean the glass panel with a soft cloth and a non-abrasive glass cleaner.
- **Air Vents:** Periodically vacuum the air intake and exhaust vents to prevent dust buildup, which can impede heater performance.

General Care

Ensure the power cord is not pinched or placed under the fireplace. Store the remote control in a safe place when not in use. No

user-serviceable parts are inside the main unit other than the remote control battery.

TROUBLESHOOTING

If you experience issues with your fireplace, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power to the unit; Power switch off; Remote control battery depleted.	Check power outlet and circuit breaker; Ensure main power switch is ON; Replace remote control battery.
No heat output.	Heater function off; Thermostat set too low; Air vents blocked.	Activate heater function; Increase thermostat setting; Clear any obstructions from air vents.
Flame effect not working.	Flame function off; LED components issue.	Activate flame function; If problem persists, contact customer support.
Remote control not responding.	Battery depleted; Obstruction between remote and unit.	Replace CR2 battery; Ensure clear line of sight to the fireplace sensor.

If troubleshooting steps do not resolve the issue, please contact Napoleon customer support.

SPECIFICATIONS

Feature	Detail
Model Name	Allure- NEFL42FH
Product Dimensions (D x W x H)	5" x 42" x 22"
Item Weight	45.2 Pounds
Power Source	AC/DC
Heat Output	5000 BTU
Heating Coverage	Up to 400 sq ft
Material	Metal
Finish Type	Black
Installation Type	Wall Mount (also suitable for recessed)
Special Features	LED Flame Effect, Crystal cube ember bed, Thermostatic heater, Remote Control
Included Components	Remote Control
Remote Control Batteries	1 CR2 battery (included)
UPC	629169053315, 629169039708, 629169042852

WARRANTY INFORMATION





This Napoleon Allure Electric Fireplace is covered by a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, or to make a warranty claim, please refer to the warranty card included with your product or contact Napoleon customer support.

CUSTOMER SUPPORT

For technical assistance, replacement parts, or any questions regarding your Napoleon Allure Electric Fireplace, please contact Napoleon customer support. Have your model number (NEFL42FH) and purchase information ready when contacting support.

Manufacturer: Napoleon

Related Documents - NEFL42FH

	<p>Napoleon Allure Vertical Series Installation and Operation Manual</p> <p>Comprehensive installation and operation manual for the Napoleon Allure Vertical Series electric fireplaces (models NEFVC32H and NEFVC38H). Covers safety information, installation steps, electrical requirements, operation, troubleshooting, and warranty.</p>
	<p>Napoleon Elevation Series Gas Fireplace Installation Manual</p> <p>Comprehensive installation manual for Napoleon Elevation Series gas fireplaces (EX36, EX42 models). Covers safety, venting, electrical, gas installation, and finishing for Natural Gas and Propane units.</p>
	<p>Napoleon NZ25 Zero Clearance Fireplace: Installation and Operation Manual</p> <p>Comprehensive installation, operation, maintenance, and safety guide for the Napoleon NZ25 zero clearance solid fuel burning fireplace. Includes warranty information and troubleshooting tips.</p>
	<p>BLKBLP42 Birch Log Placement Guide - Napoleon Fireplaces</p> <p>Step-by-step instructions for correctly placing Napoleon BLKBLP42 Birch logs in your fireplace for optimal performance and visual appeal. Includes safety warnings and tips.</p>
	<p>Napoleon Rosedale Series RD3N Installation Manual</p> <p>Comprehensive installation manual for the Napoleon Rosedale Series RD3N and RD3P gas fireplace heaters. Covers safety, installation procedures, operation, maintenance, and troubleshooting.</p>



Napoleon BLKAX36-1 Birch Log Set Installation Guide

Step-by-step instructions for correctly installing the Napoleon BLKAX36-1 Birch Log Set. Learn how to place logs, embers, and ensure proper burner function for a realistic fireplace experience.