

ION ISP29R

ION Clipster Ultra-Portable Bluetooth Speaker User Manual

Model: ISP29R

1. INTRODUCTION

The ION Clipster is an ultra-portable Bluetooth speaker designed for on-the-go audio. Its integrated clip allows for easy attachment to backpacks, belt loops, or purses, making it an ideal companion for various activities. The Clipster streams music wirelessly from any Bluetooth-enabled device, offering convenience and clear sound wherever you are.

Key Features:

- Streams music wirelessly from any Bluetooth music player.
- Integrated clip for easy attachment to bags, clothing, or other items.
- Compatible with iPad, iPhone, iPod, Android devices, and other Bluetooth music players.
- Features large, rubberized volume and Play/Pause controls for easy operation.
- Equipped with a built-in rechargeable battery for hours of listening.

2. WHAT'S IN THE BOX

Please check the contents of your Clipster package:

- ION Clipster Ultra-Portable Bluetooth Speaker
- USB Charging Cable
- Quickstart Guide
- Safety & Warranty Manual







Figure 2.1: Front view of the ION Clipster speaker.

3. SETUP

3.1 Charging the Clipster

Before first use, fully charge the Clipster's internal rechargeable battery. Use the included USB cable to connect the Clipster's micro-USB port to a standard USB power adapter (not included) or a computer's USB port.

- The charging indicator light will illuminate while charging.
- The light will turn off once charging is complete.





Figure 3.1: Micro-USB charging port location.

3.2 Powering On/Off

- To power on, press and hold the **Power button** (*power icon*) until the indicator light illuminates.
- To power off, press and hold the **Power button** again until the indicator light turns off.

3.3 Bluetooth Pairing

The Clipster will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is currently connected. The Bluetooth indicator light will flash rapidly.

1. Ensure your Bluetooth device (smartphone, tablet, etc.) has Bluetooth enabled.
2. Go to your device's Bluetooth settings and select "ION Clipster" from the list of available devices.
3. Once paired, the Clipster's Bluetooth indicator light will glow solid blue, and you will hear an audible confirmation.
4. If pairing fails, turn off the Clipster and your Bluetooth device, then repeat the steps.



Figure 3.2: Control buttons on the Clipster.

4. OPERATION

4.1 Audio Playback

After successful pairing, you can begin playing audio from your Bluetooth device. The Clipster's controls allow for basic playback management:

- **Play/Pause:** Press the **Play/Pause button** (*play/pause icon*) to start or pause audio playback.
- **Volume Up:** Press the **Volume + button** (*volume up icon*) to increase the volume.
- **Volume Down:** Press the **Volume - button** (*volume down icon*) to decrease the volume.

Note: Track skipping (next/previous) is typically controlled directly from your connected Bluetooth device.

4.2 Using the Integrated Clip

The Clipster features a durable, integrated carabiner-style clip. This allows you to securely attach the speaker to various items for hands-free listening:

- Attach to a belt loop while walking or hiking.
- Clip to a backpack strap for music on the go.
- Secure to a beach chair or umbrella for outdoor relaxation.

Video 4.1: Official product video demonstrating the ION Clipster's portability and features. This video shows the speaker being clipped to various items and used in different outdoor settings, highlighting its wireless connectivity and sound.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the Clipster. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the Clipster in a cool, dry place when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the unit regularly, even if not in constant use.
- **Important:** The ION Clipster is *not waterproof*. Exercise caution and avoid exposing the device to water, rain, or excessive moisture.

6. TROUBLESHOOTING

Problem	Possible Solution
No sound from Clipster.	• Ensure Clipster is powered on and charged. • Check that the volume on both the Clipster and your Bluetooth device is turned up. • Verify that the Clipster is successfully paired with your device (solid blue Bluetooth light). • Try re-pairing the device.
Cannot pair Clipster with Bluetooth device.	• Make sure Clipster is in pairing mode (flashing blue Bluetooth light). • Ensure your Bluetooth device's Bluetooth is enabled and it is within range (approx. 30 ft / 9 m). • Turn off and restart both the Clipster and your Bluetooth device. • Clear the Clipster from your device's Bluetooth list and try pairing again.
Battery not holding charge or short battery life.	• Ensure the USB cable is securely connected to both the Clipster and the power source. • Try a different USB port or power adapter. • Battery performance may degrade over time with regular use.

7. SPECIFICATIONS

Feature	Detail
Model Number	ISP29R
Connectivity	Bluetooth, USB
Wireless Communication Technology	Bluetooth
Speaker Maximum Output Power	2 Watts
Impedance	4 Ohm
Power Source	Battery Powered (1 Lithium Ion battery included)
Product Dimensions (L x W x H)	1.2 x 2.8 x 6 inches (3.05 x 7.11 x 15.24 cm)

Feature	Detail
Item Weight	6.4 ounces (181.44 grams)
Mounting Type	Clip On
Is Waterproof	No

8. WARRANTY AND SUPPORT

The ION Clipster comes with a limited warranty. Please refer to the included Safety & Warranty Manual for detailed information regarding warranty coverage, terms, and conditions.

For technical support, troubleshooting assistance, or warranty claims, please visit the official ION Audio website or contact their customer support directly. Contact information can typically be found in the Safety & Warranty Manual or on the manufacturer's website.