

[manuals.plus](#) /› [DuroMax](#) /› [DuroMax XP7HPE 208cc Electric Start Gas Engine User Manual](#)**DuroMax XP7HPE**

DuroMax XP7HPE 208cc Electric Start Gas Engine

User Manual

1. INTRODUCTION

This manual provides essential instructions for the safe operation, maintenance, and troubleshooting of your DuroMax XP7HPE 208cc Electric Start Gas Engine. This 4-stroke OHV engine is designed for multi-use applications, including powering lawn and garden equipment, go-karts, pressure washers, log splitters, and water pumps. Please read this manual thoroughly before operating the engine to ensure proper use and to prevent injury or damage.



Image 1.1: Front view of the DuroMax XP7HPE 208cc Electric Start Gas Engine, showcasing its blue casing and key components like the air filter and fuel tank.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in serious injury or death.

- **Carbon Monoxide Hazard:** Engine exhaust contains carbon monoxide, a colorless, odorless, poisonous gas. Never operate the engine indoors or in poorly ventilated areas. Ensure adequate ventilation when operating.
- **Fuel Safety:** Gasoline is highly flammable and its vapors are explosive. Handle fuel with extreme care. Store gasoline in approved containers in a well-ventilated area away from ignition sources. Do not refuel a hot or running engine.
- **Hot Surfaces:** The engine and exhaust system become very hot during operation and remain hot for a period after shutdown. Avoid contact with hot surfaces to prevent burns.
- **Moving Parts:** Keep hands, feet, hair, and clothing away from moving parts such as the flywheel, fan, and recoil starter to prevent entanglement and injury.
- **Electrical Safety:** Ensure all electrical connections are secure and insulated. Do not operate the engine in wet conditions.
- **Proposition 65 Warning:** This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

3. PRODUCT OVERVIEW AND KEY COMPONENTS

The DuroMax XP7HPE engine features a robust design for reliable performance. Key components include:

- **208cc 4-Stroke OHV Engine:** Provides efficient power output.
- **Electric Start Key Switch Box:** For convenient starting.
- **Recoil Start:** Manual pull-start option.
- **Large 1 Gallon Fuel Tank:** Allows for extended operation.
- **Dual, Semi-dry, Oil Bath Air Cleaner:** Ensures clean air intake.
- **Transistorized Magneto Ignition System:** For reliable spark.
- **3/4" Diameter Shaft:** Standard size for various applications.
- **EPA and CARB Approved:** Meets environmental standards.



Image 3.1: Side view of the engine, highlighting the carburetor and the air filter assembly, crucial for engine performance.






Image 3.2: Top view of the engine, displaying the fuel tank and the oil fill cap, essential for fuel and oil management.


4. SETUP AND INSTALLATION

4.1 Unpacking and Inspection

Carefully remove the engine from its packaging. Inspect for any shipping damage. Ensure all components listed in the packing list are present.

4.2 Adding Engine Oil

The engine is shipped without oil. Before first use, add 0.6 liters (20 oz) of 30W engine oil. Locate the oil fill cap/dipstick (typically yellow) and fill to the upper mark on the dipstick. Do not overfill.






Image 4.1: Top view of the engine, indicating the location of the fuel tank and the oil fill cap for initial setup.

4.3 Adding Fuel

Fill the fuel tank with fresh, unleaded 87 octane gasoline. Do not use E85 or mixed fuels. Ensure the fuel cap is securely tightened after refueling.

4.4 Battery Connection (for Electric Start)

Connect the battery cables to the engine's electric start terminals. Ensure correct polarity (red to positive, black to negative). Secure connections to prevent vibration-induced disconnections.



Image 4.2: Side view of the engine, illustrating the electric start motor and associated wiring connections.

4.5 Engine Mounting

Mount the engine securely to a stable, level surface using appropriate hardware. Refer to the engine mount diagram for bolt patterns and dimensions.




Image 4.3: Diagram illustrating the engine's mounting bolt pattern and dimensions for secure installation.




Image 4.4: Bottom view of the engine, clearly showing the four mounting points for attachment to equipment.

5. OPERATION

5.1 Pre-Operation Check

- Check engine oil level.
- Check fuel level.
- Inspect air filter.
- Ensure all connections are secure.

5.2 Starting the Engine

1. Turn the fuel valve to the 'ON' position.
2. Move the choke lever to the 'CLOSED' position (for cold starts). For warm starts, the choke may not be necessary.
3. Move the throttle lever to the 'FAST' position.
4. **Electric Start:** Turn the ignition key to the 'START' position. Release the key once the engine starts.
5. **Recoil Start:** Grasp the recoil starter handle and pull slowly until resistance is felt, then pull quickly and firmly. Repeat if necessary.
6. Once the engine starts, gradually move the choke lever to the 'OPEN' position as the engine warms up.



Image 5.1: Side view of the engine, highlighting the recoil starter mechanism for manual engine ignition.

5.3 Stopping the Engine

1. Move the throttle lever to the 'SLOW' or 'IDLE' position.
2. Turn the ignition key to the 'OFF' position (for electric start models) or move the engine switch to 'OFF'.
3. Turn the fuel valve to the 'OFF' position.

6. MAINTENANCE

Regular maintenance is crucial for the longevity and optimal performance of your engine.

6.1 Maintenance Schedule

Item	Every Use	Every 25 Hrs / Monthly	Every 100 Hrs / Annually
Check Engine Oil Level	✓		
Clean Air Filter		✓	
Change Engine Oil			✓
Inspect Spark Plug			✓
Inspect Fuel Line			✓

6.2 Oil Change Procedure

Drain old oil when the engine is warm. Remove the oil drain plug and allow oil to drain completely. Replace the drain plug and refill with 0.6 liters (20 oz) of recommended engine oil (e.g., SAE 30W or 10W-30).

6.3 Air Filter Cleaning

Remove the air filter cover and element. Clean the element with warm, soapy water, rinse thoroughly, and allow to air dry completely. Reinstall the dry filter element and cover.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your engine.

Problem	Possible Cause	Solution
Engine will not start	No fuel, stale fuel, incorrect choke position, low oil, spark plug issue, battery dead (electric start)	Add fresh fuel, adjust choke, check oil level, inspect/clean/replace spark plug, charge/replace battery
Engine runs poorly	Dirty air filter, stale fuel, incorrect throttle, spark plug issue	Clean air filter, replace fuel, adjust throttle, inspect/clean spark plug
Excessive vibration	Loose mounting bolts, unbalanced load, internal engine issue	Tighten mounting bolts, ensure load is balanced, consult service center if persistent
Electric start not charging battery	Faulty charging system, loose connections, battery issue	Check connections, test charging system components, test battery

8. SPECIFICATIONS

Feature	Specification
Model	XP7HPE
Engine Type	4-Stroke, OHV
Displacement	208cc (196ml)
Bore x Stroke	68mm x 54mm
Max Output	3600 RPM
Max Torque	13.2 Nm / 9.7 ft-lb
Shaft Size	3/4" Diameter, 2-3/8" Long, 3/16" Keyway
Shaft End	5/16" Size 24 UNF - Drilled and Tapped
Fuel Type	Unleaded Gasoline (87 Octane)
Fuel Tank Capacity	1 Gallon
Oil Capacity	0.6 Liters (20 oz)
Start System	Electric Start, Recoil Start

Feature	Specification
Ignition System	Transistorized Magneto
Air Cleaner	Dual, Semi-dry, Oil Bath
Product Dimensions (L x W x H)	17.3" x 16.7" x 17.12"
Item Weight	44 Pounds
Emissions Compliance	EPA and CARB Approved

DuroMax

XP7HPE

208cc Gasoline Engine



ENGINE FEATURES

Electric Start

An electric key start that allows for easy and reliable starting without the need for manual pulling. Reduces the risk of starting issues especially for those with physical limitations

Compact and Lightweight

This powerful 208cc 4-stroke OHV engine has plenty of power for multiple light duty applications including go karts, pressure washers, trailer mounted/mobile carwashes, log splitters, roto tillers- cultivators, and water/trash transfer pumps.

COMPARABLE TO

HONDA <ul style="list-style-type: none"> • GP160 (163cc) • GX160 (163cc) • GP200 (196cc) • GX200 (196cc) 	PREDATOR <ul style="list-style-type: none"> • Horizontal (212cc) 	KOHLER <ul style="list-style-type: none"> • RH255 (196cc) • RH265 (196cc) • CH260 (208cc) • CH270 (208cc) 	YAMAHA <ul style="list-style-type: none"> • MZ175 (171cc) • MZ200 (192cc)
 <ul style="list-style-type: none"> • XR750 (163cc) • XR950 (208cc) 			

Image 8.1: Diagram summarizing key specifications and features of the DuroMax XP7HPE engine.




Image 8.2: Close-up view of the engine's output shaft, indicating its 4-inch length for compatibility assessment.

9. WARRANTY INFORMATION

DuroMax products are typically covered by a limited warranty. For specific warranty terms, conditions, and registration procedures, please refer to the warranty card included with your product or visit the official DuroMax website. Keep your proof of purchase for warranty claims.


10. CUSTOMER SUPPORT

For technical assistance, parts, or service inquiries, please contact DuroMax customer support. You can find contact information on the official DuroMax website or through your product documentation.

DuroMax Power Equipment

Website: www.duromaxpower.com (Example link, please verify official website)

Related Documents - XP7HPE

 <p>DuroMax XP7000iHT User Manual</p>	<p><u>DuroMax XP7000iHT User Manual - Operation, Maintenance, and Safety Guide</u></p> <p>Official user manual for the DuroMax XP7000iHT portable tri-fuel generator. Learn how to safely set up, operate, and maintain your generator using gasoline, propane, or natural gas. Includes detailed instructions, safety warnings, troubleshooting tips, and specifications from DuroMax Power Equipment.</p>
 <p>DuroMax XP16000iHT User Manual</p>	<p><u>DuroMax XP16000iHT User Manual: Reliable Tri-Fuel Portable Generator</u></p> <p>This user manual for the DuroMax XP16000iHT Tri-Fuel portable generator provides comprehensive guidance on setup, operation, safety procedures, and maintenance. Learn to use your generator reliably for home backup, job sites, and outdoor adventures with features like the CO Alert system. Visit duromaxpower.com for more information.</p>
 <p>DuroMax XP12000EH User Manual</p>	<p><u>DuroMax XP12000EH Generator User Manual: Operation, Setup & Maintenance Guide</u></p> <p>Comprehensive user manual for the DuroMax XP12000EH Dual Fuel Generator. Learn about safe setup, operation, maintenance, troubleshooting, and warranty for reliable portable power.</p>
 <p>DuroMax XP12000EH User Manual</p>	<p><u>DuroMax XP12000EH Dual Fuel Generator User Manual: Operation, Safety, and Maintenance</u></p> <p>Comprehensive user manual for the DuroMax XP12000EH Dual Fuel Portable Generator. Provides detailed guidance on setup, operation, safety procedures, maintenance, troubleshooting, and warranty information for reliable power generation.</p>
 <p>DuroMax XP16000iHT User Manual</p>	<p><u>DuroMax XP16000iHT Tri Fuel Portable Generator User Manual</u></p> <p>Comprehensive user manual for the DuroMax XP16000iHT Tri Fuel Portable Generator, covering setup, operation, maintenance, safety procedures, and troubleshooting for reliable power.</p>
 <p>DuroMax NEXT GENERATION POWER SYSTEMS</p> <p>Gasoline High Pressure Pump Owner's Manual</p> <p>For Other Customer Service Call 1-800-232-1222 Monday - Friday 8:00 a.m. to 8:00 p.m. EST</p>	<p><u>DuroMax Gasoline High Pressure Pump Owner's Manual</u></p> <p>Comprehensive owner's manual for the DuroMax Gasoline High Pressure Pump (Model XP702HP), covering safety precautions, operation, maintenance, troubleshooting, specifications, and warranty information.</p>



XP7HPE SERVICE MANUAL



[\[pdf\] User Manual](#)

XP7HPE 1 thg 5 2025 — Always follow the inspection maintenance recommendations and schedules in this instruction manual ○ Make sure engine is off before you begin any C1zv eIFe8L m media amazon images I |||

XP7HPE SERVICE MANUAL REV: XP7HPE_rev05092023 This manual provides information regarding the operation and maintenance of these products. We have made every effort to ensure the accuracy of the information in this manual. We reserve the right to change this product at any time without prior notice....

lang:en **score:45** filesize: 6.41 M page_count: 46 document date: 2023-05-19

REV: XP7HPE_rev05092023

This manual provides information regarding the operation and maintenance of these products. We have made every effort to ensure the accuracy of the information in this manual. We reserve the right to change this product at any time without prior notice.

5880 Ontario Mills Pkwy
Ontario, CA 91764 USA
www.duromaxpower.com
Call our Customer Care Team Toll Free 855-543-8444
844-DUROMAX



XP7HPE USER MANUAL



[\[pdf\] User Manual](#)

User Manual DuroMax XP7HPE 208cc Electric Start Gas Powered 50 State Approved Multi Use Engine Blue A1dh 8uvOsL m media amazon images I |||

XP7HPE USER MANUAL REV: XP7HPE_rev02032023 This manual provides information regarding the operation and maintenance of these products. We have made every effort to ensure the accuracy of the information in this manual. We reserve the right to change this product at any time without prior notice. 5...

lang:en **score:44** filesize: 1.92 M page_count: 64 document date: 2023-02-10

REV: XP7HPE_rev02032023

This manual provides information regarding the operation and maintenance of these products. We have made every effort to ensure the accuracy of the information in this manual. We reserve the right to change this product at any time without prior notice.

5880 Ontario Mills Pkwy
Ontario, CA 91764 USA
www.duromaxpower.com
Call our Customer Care Team Toll Free 855-543-8444
844-DUROMAX

User Manual of Product 1:

DuroMax XP7HPE 212cc 7HP Electric Start Gas Powered, 50 State Approved, Multi-Use Engine , Blue

[\[pdf\] User Manual Owner's Manual Warranty](#)

User Manual of Product 1 DuroMax XP7HPE 212cc 7HP ElectricThis manual provides information regarding the operation and maintenance these products We have made every effort to ensure accuracy the B1nbSgN3fYLm media amazon images I B1nbSgN3fYL |||

User Manual of Product 1: DuroMax **XP7HPE** 212cc 7HP Electric Start Gas Powered, 50 State Approved, Multi-Use Engine , Blue Gasoline Engine Owner s Manual Max Tool Customer Service customer_service maxtool.com or call 1-800-629-3325 option 3 Monday -Thursday 6am to 7pm, Friday 6am to 5:30pm. PST P...

lang:en **score:35** filesize: 2.73 M page_count: 31 document date: 2023-01-19



REV: XP7HPE_rev05092023
This manual provides information regarding the operation and maintenance of these products. We have made every effort to ensure the accuracy of the information in this manual. We reserve the right to change this product at any time without prior notice.


888 Ontario Mills Blvd
Ontario, CA 91761 USA
www.duromaxpower.com
Call our Customer Care Team Toll Free 844-PST-8444
844-DUROMAX

[pdf] User Manual

Service Manual 208cc 3 4 Inch Shaft Recoil Electric Start Gasoline Engine XP7HPE DuroMax Power Equipment XP7HPE servicemanual rev05092023 WEBcdn shopify s files 1 0613 1168 0689 WEB v 1686069095 |||

XP7HPE SERVICE MANUAL REV: XP7HPE_rev05092023 This manual provides information regarding the operation and maintenance of these products. We have made every effort to ensure the accuracy of the information in this manual. We reserve the right to change this product at any time without prior notice....

lang:en score:31 filesize: 6.41 M page_count: 46 document date: 2023-05-19



[pdf] User Manual Owner's Manual Warranty

User Manual IBM D5c490039d25c7 static appliances connection attachments |||


Gasoline Engine Owner's Manual DuroMax Customer Service info

duromaxpower.com or call 844-DUROMAX Mo ... ype Ignition type Lubricating type

Fuel consumption g/kW-h Dry weight Dimension LWH in. XP7HP XP7HPE XP16HP

XP16HPE 4-strok, OHV, 25, single-cylinder, force air-cooled 7054 9066 9066 4.2/36...

lang:en score:24 filesize: 862.24 K page_count: 30 document date: 2018-08-10



[pdf] Warranty

Sequeira Calderon Efrain click here DuroMax XP7HPE 208cc Electric Start Gas Powered 50 State

Approved Multi Use Engine Blue 61tRyNwZPRS m media amazon images I |||

DuroMax Generator Warranty All DuroMax generators have a 30 day replacement warranty and carry a full 1 year parts warranty. Parts are not charged during the warranty period and freight charges are the responsibility of the customer. Return shipping is the responsibility of the buyer. If you have an...

lang:en score:23 filesize: 89 K page_count: 1 document date: 2016-09-27



[DuroMax XP7HPE 208cc OHV Electric Start Engine - Features & Specifications](#)

Product overview and specifications for the DuroMax XP7HPE engine, featuring a 208cc OHV 4-stroke engine with electric start, EPA/CARB approval, and a 3-year warranty. Includes dimensions and performance specs.

lang:tl score:23 filesize: 996.76 K page_count: 2 document date: 2021-09-01




[\[pdf\] User Manual](#)

1584541 Man1 media tractorsupply is content TractorSupplyCompany tsc product 1 58 45 41 |||

XP7HPE USER MANUAL REV: XP7HPE_rev04042022 This manual provides information regarding the operation and maintenance of these products. We have made every effort to ensure the accuracy of the information in this manual. We reserve the right to change this product at any time without prior notice. 5...

lang:en score:22 filesize: 1.69 M page_count: 64 document date: 2022-05-04



[\[pdf\] User Manual Owner's Manual Declaration of Conformity Warranty](#)

P XP6 5HP XP6 5HPE XP13HP XP13HPE doc IBM xp7hp xp16hp manual rev081018 content toolots

s3 amazonaws attachment file x p |||


Gasoline Engine Owner's Manual DuroMax Customer Service info

duromaxpower.com or call 844-DUROMAX Mo ... ype Ignition type Lubricating type

Fuel consumption g/kW-h Dry weight Dimension LWH in. XP7HP **XP7HPE** XP16HP

XP16HPE 4-strok, OHV,25,single-cylinder, force air-cooled 7054 9066 9066 4.2/36...

lang:en score:21 filesize: 857.89 K page_count: 30 document date: 2018-08-10




[\[pdf\] User Manual Owner's Manual Declaration of Conformity Warranty](#)

P XP6 5HP XP6 5HPE XP13HP XP13HPE doc IBM XP7HP Manual buymbs Images variant medium DuroMax

Gasoline Engine Owner s Manual Max Tool Customer Service customer_service maxtool.com or call 1-800-... ype Ignition type Lubricating type Fuel consumption g/kW-h Dry weight Dimension LWH in. XP7HP **XP7HPE** XP16HP XP16HPE 4-strok, OHV,25,single-cylinder, force air-cooled 7054 9066 9066 4.2/36...

lang:en **score:20** filesize: 2.72 M page_count: 30 document date: 2017-11-09



[\[pdf\] User Manual Owner's Manual Declaration of Conformity Warranty Catalog](#)

P XP6 5HP XP6 5HPE XP13HP XP13HPE doc IBM 208cc 3 4 in Shaft Portable Gas Powered Recoil Start Engine Warranty DUROMAX XP7HP 811640011192 0811640011192 1000590554 cdeb3e78 c20d 4969 98f7 3435063d5c50 images thdstatic catalog Images cd |||

Gasoline Engine Owner s Manual Max Tool Customer Service customer_service duromaxgenerators.com or c ... ype Ignition type Lubricating type Fuel consumption g/kW-h Dry weight Dimension LWH in. XP7HP **XP7HPE** XP16HP XP16HPE 4-stroke, OHV,25,single-cylinder, force air-cooled 7054 9066 9066 5.2/4...

lang:en **score:10** filesize: 960.42 K page_count: 30 document date: 2017-10-25