

Manuals.plus /

- › Funko /
- › Funko POP Sci-Fi: Robby The Robot Toy Figure User Manual

Funko FUN3404

Funko POP Sci-Fi: Robby The Robot Toy Figure User Manual

Brand: Funko | Model: FUN3404

INTRODUCTION

This manual provides essential information for the care and display of your Funko POP Sci-Fi: Robby The Robot Toy Figure. Funko is a leading pop culture licensed toy company known for its stylized vinyl collectibles. This figure is part of the extensive Pop! Vinyl series, celebrating iconic characters from various franchises.



This image displays the Funko POP Robby the Robot figure. On the left, the figure is shown inside its collector's box, which

features the 'Pop! Movies' logo and 'Forbidden Planet' branding with the number 89. The box highlights the character name 'Robby the Robot' and indicates it is a vinyl figure. On the right, the Robby the Robot figure is shown outside its packaging, revealing its full design, including its clear dome head, red eyes, and metallic grey body.

SETUP

The Funko POP Robby The Robot figure is designed for display. Follow these steps for initial setup:

1. **Unboxing:** Carefully remove the figure from its packaging. The packaging is designed for display and protection; retain it if you wish to preserve its collector's value.
2. **Placement:** Choose a stable, flat surface for display. Ensure the area is free from direct sunlight, extreme temperatures, and excessive humidity to prevent material degradation.
3. **Stability:** The figure is designed to stand independently. Ensure it is placed on a level surface to prevent accidental falls.

OPERATING

This Funko POP figure is a static collectible and does not require any operational procedures. It is intended for display purposes.

- **Display:** Position the figure as desired on your chosen display surface.
- **Interaction:** While durable, avoid excessive handling or dropping the figure to prevent damage to its paint or structure.

MAINTENANCE

Proper maintenance will help preserve the appearance and longevity of your figure.

- **Cleaning:** Gently wipe the figure with a soft, dry, lint-free cloth to remove dust. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the paint or material.
- **Storage:** If storing the figure, ensure it is in a cool, dry place, away from direct sunlight and extreme temperatures. Original packaging can provide additional protection during storage.

TROUBLESHOOTING

Most issues with collectible figures are minor and related to display or environmental factors.

Problem	Solution
Figure is dusty.	Gently wipe with a soft, dry cloth. For stubborn dust, a soft brush can be used.
Figure falls over easily.	Ensure it is placed on a completely flat and stable surface. Check if any part of the figure's base is uneven.
Minor scuffs or marks.	Avoid rubbing vigorously. For minor marks, a very slightly damp cloth (water only) can be tried, but test on an inconspicuous area first.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	6 x 6 x 8 inches
Item Weight	4 ounces
ASIN	B00C0ELIXM
Item Model Number	FUN3404
Manufacturer Recommended Age	8 - 15 years
Manufacturer	FunKo

WARRANTY AND SUPPORT

Funko POP figures are collectible items. While specific warranties may vary by retailer or region, Funko generally ensures product quality at the time of purchase. For any concerns regarding manufacturing defects, please contact the retailer from whom the product was purchased.

For general inquiries about Funko products, you may visit the official Funko website: www.funko.com.