



Manuals.plus /

- › Sharp /
- › Sharp EL-344RB Metric Conversion Wallet Calculator User Manual

## Sharp EL-344RB

# Sharp EL-344RB Metric Conversion Wallet Calculator User Manual

Model: EL-344RB

## INTRODUCTION

---

Thank you for choosing the Sharp EL-344RB Metric Conversion Wallet Calculator. This compact and solar-powered calculator is designed for convenient everyday calculations and essential metric conversions. Its 10-digit LCD display ensures clear readability, and the protective wallet case provides portability and durability. This manual provides instructions for the proper setup, operation, and maintenance of your calculator.




Image: The Sharp EL-344RB Metric Conversion Wallet Calculator, shown with its protective wallet case. The calculator features a 10-digit LCD display and a standard keypad.

## SETUP

The Sharp EL-344RB calculator is solar-powered and does not require batteries under normal operating conditions. For optimal performance, ensure the solar panel is exposed to sufficient light.

### Initial Use:

1. **Unpack:** Carefully remove the calculator from its packaging and protective wallet case.
2. **Power On:** The calculator will automatically power on when exposed to light. If the display is blank, ensure the solar panel is receiving adequate illumination.
3. **Clear Display:** Press the **ON/C** button to clear any previous calculations or entries from the display.

## OPERATING INSTRUCTIONS

### Basic Calculations:

- **Addition (+), Subtraction (-), Multiplication (×), Division (÷):** Enter the first number, press the desired operation key, enter the second number, then press = for the result.

- **Clear Entry (CE):** Clears the last entered number without affecting previous operations.
- **All Clear (ON/C):** Clears all entries and operations, resetting the calculator.
- **Percentage (%):** Used for percentage calculations. For example, to calculate 15% of 200, enter 200× 15 %.

## Metric Conversions:

The EL-344RB features dedicated keys for common metric conversions. Refer to the calculator's keypad for specific conversion labels (e.g., **cm/inch**, **kg/lb**, **L/gal**).

1. **Enter Value:** Input the numerical value you wish to convert.
2. **Press Conversion Key:** Press the appropriate conversion key. The display will show the converted value.
3. **Reverse Conversion:** Pressing the same conversion key again will typically convert the value back to its original unit.

*Example: Converting 10 inches to centimeters.*

1. Enter **10**.
2. Press the **cm/inch** key. The display will show the equivalent value in centimeters.

## Memory Functions:

- **Memory Plus (M+):** Adds the displayed value to the memory.
- **Memory Minus (M-):** Subtracts the displayed value from the memory.
- **Recall Memory (MR):** Displays the current value stored in memory.
- **Clear Memory (MC):** Clears the memory, setting its value to zero.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the calculator's surface. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the display or casing.
- **Storage:** When not in use, store the calculator in its protective wallet case to prevent scratches and damage. Avoid exposing it to extreme temperatures, high humidity, or direct sunlight for extended periods when stored.
- **Solar Panel:** Keep the solar panel clean and unobstructed to ensure continuous power supply.

## TROUBLESHOOTING

---

- **Blank Display:**

Ensure the solar panel is exposed to sufficient light. The calculator requires ambient light to operate. If in a dimly lit environment, move it to a brighter area.

- **Incorrect Calculations:**

Press **ON/C** to clear all previous operations and memory. Re-enter your calculation carefully. Check for correct key presses and operation order.

- **Keys Not Responding:**

Ensure the calculator is clean and free from debris around the keys. If the issue persists, try moving it to a brighter area to ensure adequate power.

## SPECIFICATIONS

---

<b>Model Number</b>	EL-344RB
<b>Display Type</b>	10-Digit LCD
<b>Power Source</b>	Solar Powered
<b>Calculator Type</b>	Basic with Metric Conversion
<b>Material</b>	Plastic
<b>Dimensions (Approx.)</b>	Wallet-sized (specific dimensions not provided, refer to product packaging)
<b>Weight</b>	1.26 Pounds (approximate shipping weight)

## WARRANTY INFORMATION

---

Specific warranty terms and conditions for the Sharp EL-344RB calculator are typically provided with the product at the time of purchase or can be found on the official Sharp website. Please retain your proof of purchase for warranty claims. For detailed warranty information, please refer to the documentation included in your product packaging or visit the official Sharp support portal.

## CUSTOMER SUPPORT

---

For further assistance, technical support, or inquiries regarding your Sharp EL-344RB calculator, please contact Sharp customer support. Contact details can usually be found on the official Sharp website or in the product packaging.

**Online Support:** Visit the official Sharp website for FAQs, product registration, and support resources.

**Telephone Support:** Refer to your product documentation or the Sharp website for regional customer service phone numbers.