## Nuova Simonelli Mprob10capad

# Nuova Simonelli Prontobar Mprob10capad Espresso Coffee Machine/Grinder User Manual

Model: Mprob10capad

Setup Operation Maintenance Troubleshooting Specifications Warranty Support

## Introduction

Thank you for choosing the Nuova Simonelli Prontobar Mprob10capad Espresso Coffee Machine/Grinder. This fully automatic machine is designed for both commercial and personal use, offering high-quality espresso and milk-based beverages with ease. Please read this manual carefully before operating the machine to ensure proper use, optimal performance, and longevity.



Image: Nuova Simonelli Prontobar Mprob10capad Espresso Coffee Machine/Grinder. This image displays the sleek, stainless steel design of the fully automatic espresso machine, featuring its integrated grinders and control panel.

## Important Safety Instructions

- Always ensure the machine is connected to a grounded power outlet (230V/60/1-ph).
- Do not immerse the machine, cord, or plug in water or other liquids.
- Keep hands and utensils away from moving parts during operation.
- Exercise caution when handling hot surfaces and steam.
- Unplug the machine before cleaning or maintenance.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.

## Setup

### 1. Unpacking and Placement

1. Carefully remove the machine from its packaging.
2. Place the machine on a stable, level, and heat-resistant surface.
3. Ensure adequate ventilation around the machine.
4. Keep the machine away from direct sunlight and heat sources.

### 2. Water Connection

- Connect the machine to a potable water supply using the provided hoses.
- Ensure the water pressure is within the recommended range (refer to specifications).
- It is recommended to use a water filter to prevent scale buildup.

### 3. Power Connection

- Plug the power cord into a grounded 230V/60/1-ph electrical outlet.
- Do not use extension cords or adapters.

### 4. Initial Rinse

- Follow the on-screen prompts or manual instructions for the initial system rinse to flush out any manufacturing residues.

## Operating Instructions

### 1. Filling the Bean Hoppers

- Open the lids of the two coffee bean hoppers.
- Pour fresh, whole coffee beans into each hopper.
- Close the lids securely to maintain bean freshness.

### 2. Adjusting Grind Settings

- The machine features two integrated grinders. Refer to the display for grind adjustment options.
- Adjust the grind fineness according to your preferred espresso extraction. Finer grind for slower extraction, coarser for faster.

### 3. Making Espresso

1. Place your cup under the coffee spouts.
2. Select your desired espresso shot (single or double) from the control panel.
3. The machine will automatically grind, tamp, and brew the coffee.
4. Adjust the group height as needed for different cup sizes.

### 4. Using the Smart Wand (Automatic Milk Frothing)

1. Fill a milk pitcher with cold milk.
2. Position the Smart Wand into the milk.
3. Select the desired milk temperature and texture from the control panel.
4. The Smart Wand will automatically froth the milk to perfection.
5. After use, always clean the Smart Wand immediately.

### 5. Hot Water Dispensing

- Place a cup under the hot water spout.
- Select the hot water function from the control panel.

## Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Prontobar machine.

### 1. Daily Cleaning

- **Smart Wand:** After each use, wipe the Smart Wand with a damp cloth. Perform the automatic steam wand cleaning cycle as prompted by the machine.
- **Drip Tray and Coffee Grounds Container:** Empty and clean daily. Wash with warm, soapy water and rinse thoroughly.
- **Exterior:** Wipe the stainless steel exterior with a soft, damp cloth. Do not use abrasive cleaners.

### 2. Weekly Cleaning

- **Brew Group:** Follow the machine's instructions for the automatic brew group cleaning cycle using a cleaning tablet.
- **Bean Hoppers:** Empty any remaining beans and wipe the hoppers clean.

### 3. Descaling

- The machine will indicate when descaling is required.
- Use only Nuova Simonelli approved descaling solutions.
- Follow the on-screen instructions for the descaling process.

### 4. Water Filter Replacement

- Replace the water filter cartridge as recommended by the manufacturer or when prompted by the machine.

## Troubleshooting

Before contacting customer support, please refer to the following common issues and solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| No coffee dispenses. | No water in reservoir/connected supply, clogged brew group, empty bean hopper. | Check water supply, perform brew group cleaning, refill bean hopper. |
| Coffee is too weak or too strong. | Incorrect grind setting, incorrect coffee dose. | Adjust grind fineness (finer for stronger, coarser for weaker), check coffee dose settings. |
| Milk not frothing correctly. | Smart Wand clogged, milk too warm, incorrect milk type. | Clean Smart Wand thoroughly, use cold fresh milk, ensure proper milk type for frothing. |
| Machine displays "Descale" message. | Scale buildup in the system. | Perform a descaling cycle as per maintenance instructions. |
| Error message on display. | Specific internal issue. | Note the error code and refer to the full manual or contact customer support. |

## Specifications

- **Model:** Mprob10capad
- **Brand:** Nuova Simonelli
- **Type:** Fully Automatic Espresso Coffee Machine/Grinder
- **Boilers:** (1) 1.4 Lt. Coffee Boiler, (1) 1.4 Lt. Steam Boiler
- **Grinders:** (2) Integrated Coffee Grinders
- **Milk System:** Automatic Milk Frothing Steam Wand (Smart Wand)
- **Body Material:** Stainless Steel
- **Color:** Black
- **Power:** 230V/60/1-ph
- **Certifications:** UL, NSF4
- **Special Features:** Adjustable Group Height
- **Included Components:** Filter, Milk Frother
- **Capacity:** 1.4 Liters (each boiler)
- **ASIN:** B00C35NXKE

## Warranty Information

Nuova Simonelli provides a limited warranty for the Prontobar Mprob10capad machine. The specific terms and duration of the warranty may vary by region and retailer. Please retain your proof of purchase for warranty claims.
For detailed warranty information, please refer to the warranty card included with your product or visit the official Nuova Simonelli website.

## Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact Nuova Simonelli customer support or your authorized dealer.

- **Online Support:** Visit the official Nuova Simonelli website for FAQs, support resources, and contact forms.
- **Phone Support:** Refer to your product documentation for regional customer service phone numbers.
- When contacting support, please have your model number (Mprob10capad) and serial number ready.

© 2023 Nuova Simonelli. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**