

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ideal Standard](#) /
- › [Ideal Standard Idealrain B9420AA Shower Rail 600 mm User Manual](#)

Ideal Standard B9420AA

Ideal Standard Idealrain B9420AA Shower Rail 600 mm User Manual

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Ideal Standard Idealrain B9420AA Shower Rail 600 mm. Please read these instructions carefully before beginning installation to ensure proper function and longevity of the product. This shower rail is designed to securely hold a handheld showerhead, allowing for adjustable height and angle.

SETUP AND INSTALLATION

Unpacking

Carefully remove all components from the packaging. Inspect all parts for any signs of damage. Do not discard packaging until you have confirmed all parts are present and undamaged.

Included Components

- Idealrain Shower Rail (600 mm)
- Swivel Push Button Slider (for shower holder)
- Mounting Hardware (screws, wall plugs)
- Wall Brackets

Tools Required (Not Included)

- Drill
- Drill bits suitable for wall material
- Pencil or marker
- Measuring tape
- Spirit level
- Screwdriver

Mounting Instructions

1. **Determine Mounting Position:** Choose a suitable location on the wall, ensuring the rail is vertically aligned and at a comfortable height for all users. Use a spirit level to mark the positions for the top and bottom wall

brackets.

2. **Mark Drill Holes:** Hold the wall brackets at the marked positions and use a pencil to mark the exact drilling points for the screws. Refer to the technical drawings for precise dimensions and spacing.




Figure 1: Technical drawing showing the overall dimensions of the shower rail, including a total length of approximately 609mm and a mounting distance of 550mm between the centers of the wall brackets.

3. **Drill Holes:** Using an appropriate drill bit for your wall material, drill holes at the marked points. Insert the provided wall plugs into the drilled holes.



Figure 2: Detailed technical drawing illustrating various dimensions, including a total rail length of 603mm, a mounting distance of 550mm, a wall projection of 56mm, and a shower holder diameter of 38mm.

4. **Attach Wall Brackets:** Secure the wall brackets to the wall using the provided screws. Ensure they are firmly attached and level.
5. **Install Shower Rail:** Slide the shower rail into the attached wall brackets. Secure the rail to the brackets according to the manufacturer's design, typically by tightening a small screw or cap.
6. **Attach Shower Holder:** Ensure the swivel push button slider is correctly positioned on the rail.

OPERATION

Adjusting the Shower Holder

The Ideal Standard Idealrain shower rail features a swivel push button slider for easy adjustment of your handheld showerhead. To adjust the height or angle of the showerhead:

1. **Height Adjustment:** Press the button on the slider mechanism. While holding the button, slide the shower holder up or down the rail to your desired height. Release the button to lock the holder in place.
2. **Angle Adjustment:** The shower holder can be tilted to direct the water flow. Gently adjust the angle of the showerhead within the holder to suit your preference.




Figure 3: The Ideal Standard Idealrain B9420AA Shower Rail, showcasing its chrome finish and the adjustable shower holder.

MAINTENANCE

Cleaning

To maintain the chrome finish and ensure the longevity of your shower rail, follow these cleaning guidelines:

- Use a soft cloth and mild soap or a non-abrasive cleaner specifically designed for chrome finishes.
- Avoid using abrasive sponges, scouring pads, or harsh chemical cleaners, as these can damage the chrome plating.
- Rinse thoroughly with clean water after cleaning and dry with a soft cloth to prevent water spots.
- Regular cleaning will help prevent limescale buildup and maintain the product's appearance.

TROUBLESHOOTING

Common Issues

- **Shower Holder Slips:** If the shower holder does not stay in place, ensure the push button mechanism is fully released after adjustment. If the issue persists, inspect the internal mechanism for debris or wear.
- **Rail Feels Loose:** Check the wall brackets and mounting screws. Tighten any loose screws. If the rail continues to be unstable, the wall plugs or screws may need to be replaced or re-secured.
- **Dull Chrome Finish:** Refer to the cleaning instructions in the Maintenance section. Ensure you are using appropriate cleaning products and methods.

SPECIFICATIONS

Manufacturer	Ideal Standard
Part Number	B9420AA
Item Model Number	B9420AA
Product Dimensions	60.3 x 4 x 12.7 cm
Size	603 millimetri (600 mm nominal)
Colour	Chrome
Style	Modern
Finish	Chrome
Material	Brass
Installation Method	Wall Mounted
Mounting Type	Wall Mounted
Item Package Quantity	1
Item Weight	503 g

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. Ideal Standard products typically come with a manufacturer's warranty covering defects in materials and workmanship.

For technical support or further assistance, please contact your retailer or visit the official Ideal Standard website for customer service contact details.