

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lenco](#) /

› [Lenco DVP-745 Portable DVD Player User Manual](#)

## Lenco DVP-745

# Lenco DVP-745 Portable DVD Player User Manual

Model: DVP-745

## INTRODUCTION

This manual provides essential information for the safe and efficient use of your Lenco DVP-745 Portable DVD Player. Please read it thoroughly before operating the device and retain it for future reference.



**Figure 1:** The Lenco DVP-745 Portable DVD Player, showing the main unit with its screen open, a remote control, and a portable antenna. The device is black with silver accents.

## IMPORTANT SAFETY INSTRUCTIONS

- Do not expose the device to rain or moisture.
- Do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel.
- Keep the device away from direct sunlight and heat sources.

## PACKAGE CONTENTS

Verify that all items are present in the package:

- Lenco DVP-745 Portable DVD Player
- Remote Control
- Power Adapter
- Car Adapter (if included)
- Antenna (for DVB-T/TNT reception)
- User Manual

## SETUP

---

### 1. Charging the Battery

Before first use, fully charge the internal battery. Connect the supplied power adapter to the DC IN port on the player and then to a wall outlet. The charging indicator will illuminate.

### 2. Connecting the Antenna

For DVB-T/TNT reception, connect the provided antenna to the antenna input port on the side of the player. Extend the antenna fully for optimal signal reception.

### 3. Powering On/Off

To power on the device, slide the POWER switch to the ON position. To power off, slide it to the OFF position.

## OPERATING INSTRUCTIONS

---

### 1. Playing a DVD/CD

1. Open the disc cover gently.
2. Place a DVD or CD onto the disc spindle with the label side facing up.
3. Close the disc cover. The player will automatically detect and begin playback.
4. Use the control buttons on the player or the remote control for playback functions (Play, Pause, Stop, Skip, Volume).

### 2. Using USB/SD Card

The Lenco DVP-745 supports media playback from USB drives and SD cards.

- Insert a USB flash drive into the USB port or an SD card into the SD card slot.
- Navigate to the Media Source selection (usually via a 'Source' or 'Mode' button) and select USB or SD.
- Browse your files (MP3, WMA, JPG, MPEG) using the navigation buttons and press OK/Play to start playback.

### 3. DVB-T/TNT Digital TV Reception

1. Ensure the antenna is properly connected and extended.
2. Switch the input source to DVB-T/TNT mode.
3. Perform an automatic channel scan through the OSD (On-Screen Display) menu to find available digital television channels.
4. Use the CH+/CH- buttons to change channels.

### 4. Menu Navigation

Access the OSD menu by pressing the MENU button on the player or remote. Use the arrow keys to navigate and OK/ENTER to confirm selections. Adjust settings such as picture, sound, and system preferences.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the player. For the screen, use a specialized screen cleaning cloth. Do not use liquid cleaners or abrasive materials.
- **Disc Care:** Handle discs by their edges. Keep them clean and free from scratches. Store discs in their cases when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. If storing the device for an extended period, charge the battery to approximately 50% every few months.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery discharged; Power adapter not connected; Power switch OFF.	Charge the battery; Connect power adapter; Slide power switch to ON.
No disc playback	Disc inserted incorrectly; Disc dirty/scratched; Incorrect disc format.	Insert disc correctly (label up); Clean or replace disc; Ensure disc is compatible (DVD, CD, VCD).
No TV channels	Antenna not connected/positioned correctly; No signal in area; Channel scan not performed.	Connect/adjust antenna; Check local signal strength; Perform auto channel scan.
Remote control not working	Batteries depleted; Obstruction between remote and player; Remote not pointed at sensor.	Replace batteries; Remove obstructions; Point remote directly at the IR sensor.

## SPECIFICATIONS

- **Model:** DVP-745
- **Screen Size:** 17.5 cm (7 inches)
- **Supported Disc Formats:** DVD, DVD+/-R/RW, CD, CD-R/RW, VCD, Kodak Picture CD
- **Supported Media Formats (USB/SD):** MP3, WMA, JPG, MPEG
- **Integrated Tuner:** DVB-T/TNT HD
- **Connectivity:** USB port, SD card reader
- **Color:** Black
- **Dimensions (approx.):** 25.6 x 19.6 x 13 cm
- **Weight (approx.):** 1.4 kg






## WARRANTY AND SUPPORT

The Lenco DVP-745 Portable DVD Player comes with a manufacturer's warranty of 1 year from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support or service inquiries, please refer to the official Lenco website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

*Note:* This warranty does not cover damage caused by misuse, accident, unauthorized modifications, or normal wear and

Related Documents - DVP-745

	<p><a href="#">Sony DVP-NS305/NS310/NS315/NS405/NS410/NS415 Service Manual</a></p> <p>This service manual provides detailed technical information and block diagrams for the Sony DVP-NS305, DVP-NS310, DVP-NS315, DVP-NS405, DVP-NS410, and DVP-NS415 DVD players. It includes specifications, circuit diagrams, and component layouts essential for maintenance and repair.</p>
	<p><a href="#">Delta DVP Series Programmable Logic Controllers: High Performance Automation Solutions</a></p> <p>Explore the Delta DVP Series of Programmable Logic Controllers (PLCs), offering high performance, diverse models, and expandability for industrial automation applications. Find detailed specifications and product information.</p>
	<p><a href="#">Delta DVP Series Programmable Logic Controllers: Your Guide to Digitized Automation</a></p> <p>Explore the Delta DVP Series of Programmable Logic Controllers (PLCs), designed for digitized automation. This comprehensive catalog details various models including DVP-E, DVP-S, DVP-PM, and DVP-MC series, highlighting their features, specifications, and applications in industrial automation.</p>
	<p><a href="#">Delta DVP Series Programmable Logic Controllers (PLCs) - Product Catalog</a></p> <p>Explore the comprehensive range of Delta DVP Series Programmable Logic Controllers (PLCs), including motion control, network, standard, and analog I/O models. Find detailed specifications, features, and ordering information for industrial automation solutions.</p>
	<p><a href="#">Delta DVP Series: Programmable Logic Controllers for Digitized Automation</a></p> <p>Explore Delta's DVP Series Programmable Logic Controllers (PLCs), offering advanced automation solutions for diverse industrial needs. Discover high-performance PLCs, motion controllers, and HMIs designed for efficiency and reliability.</p>



### [Delta DVP Series Programmable Logic Controllers \(PLCs\) - Product Catalog](#)

Explore the Delta DVP Series Programmable Logic Controllers (PLCs), a comprehensive range of industrial automation solutions offering high performance, diverse models, and advanced motion control capabilities. This catalog details specifications, features, and ordering information for various DVP PLC series.