

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Pocket Bottles](#) /
- › [Zees Inc Pocket Bottles CB1040 Fish Foldable Bottle User Manual](#)

Pocket Bottles CB1040

Instruction Manual: Zees Inc Pocket Bottles

Model: CB1040

INTRODUCTION

The Pocket Bottles CB1040 Fish Foldable Bottle is designed for convenience and portability, making it an ideal companion for various activities such as gym workouts, travel, work, school, and hiking. Its unique flat and reusable design offers an easier way to carry your hydration on the go.



Image: Front view of the Zees Inc Pocket Bottle, showcasing its vibrant fish design and the attached carabiner for easy carrying.

KEY FEATURES

- **BPA Free Material:** Constructed from safe, non-toxic materials.
- **Foldable and Easy to Carry:** Designed to collapse for compact storage and transport, includes a carabiner for attachment.
- **Dishwasher Safe:** Allows for convenient and thorough cleaning.

- **Freezer Safe:** Can be placed in the freezer to chill contents or create ice packs.

SETUP

Initial Cleaning

1. Before first use, thoroughly wash the bottle with warm soapy water.
2. Rinse thoroughly to remove any soap residue.
3. The bottle is dishwasher safe; place it on the top rack for cleaning.

Filling the Bottle

1. Unscrew the cap from the top of the bottle.
2. Fill with your desired beverage. Do not overfill.
3. Securely screw the cap back on to prevent leaks.

OPERATING INSTRUCTIONS

Using the Carabiner

The included carabiner allows for easy attachment to bags, backpacks, or belt loops, enhancing portability.

- Open the carabiner clip by pressing the spring-loaded gate.
- Attach the carabiner to a secure loop or strap on your gear.
- Ensure the gate closes completely to secure the bottle.



Image: The Pocket Bottle in its folded state, demonstrating how the carabiner can be used for compact carrying.

Drinking from the Bottle

- To drink, simply pull up the spout on the cap.
- After drinking, push the spout down firmly to seal and prevent leaks.

MAINTENANCE

Cleaning

- Wash the bottle regularly, especially after each use, to maintain hygiene.
- The bottle is dishwasher safe (top rack recommended).
- For hand washing, use a bottle brush to clean the interior thoroughly.
- Ensure the cap and spout are also cleaned to prevent residue buildup.

Storage

- When not in use, ensure the bottle is clean and dry before storing.
- The foldable design allows for compact storage in drawers or bags.



Image: Side profile of the Pocket Bottle, illustrating its thin, foldable design for easy storage.

Freezer Use

- The bottle is freezer safe. You can fill it partially with water and freeze it to keep your drink cold longer.
- Do not fill completely with water before freezing, as water expands when frozen and could damage the bottle.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bottle is leaking.	Cap not screwed on tightly or spout not fully closed.	Ensure the cap is securely tightened and the drinking spout is pushed down completely. Check for any damage to the cap or bottle opening.
Difficulty cleaning the interior.	Narrow opening or residue buildup.	Use a long-handled bottle brush. For stubborn residue, soak with warm soapy water or a mixture of water and baking soda before scrubbing.
Bottle retains odor.	Improper cleaning or prolonged storage with liquids.	Wash thoroughly with warm soapy water. For persistent odors, fill with a mixture of baking soda and water, let it sit overnight, then rinse well. Ensure bottle is completely dry before storage.

SPECIFICATIONS

Brand	Pocket Bottles
Model Number	CB1040
Material	Plastic (BPA Free)
Color	Multicolor (Fish Theme)
Capacity	16 Ounces
Special Features	Leak Proof, Foldable, Carabiner Included
Product Care Instructions	Dishwasher Safe, Freezer Safe
Recommended Uses	School, Hiking, Gym, Travel
Item Weight	0.1 Pounds
Item Dimensions (LxWxH)	5 x 1 x 10.5 inches (unfolded)
Manufacturer	Zee's Creations Inc.
UPC	817441010402

WARRANTY AND SUPPORT

This product is designed for durability and convenience. For any manufacturing defects or issues not covered by normal wear and tear, please contact the retailer or manufacturer directly. Specific warranty details may vary by region and purchase point.

For further assistance or inquiries, please refer to the contact information provided by your point of purchase or visit the official Pocket Bottles website.