



Manuals.plus /

› Artemide /

› Artemide Talo Mini 21 Halogen Wall Light User Manual

## Artemide 0613018A

# Artemide Talo Mini 21 Halogen Wall Light User Manual

Model: 0613018A

## 1. INTRODUCTION

---

Thank you for purchasing the Artemide Talo Mini 21 Halogen Wall Light. This elegant fixture is designed to provide warm, ambient lighting to your indoor spaces. This manual provides essential information for the safe installation, operation, and maintenance of your new wall light. Please read this manual thoroughly before installation and keep it for future reference.

### Important Safety Instructions

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Do not install this fixture in wet or damp locations. It is designed for indoor use only.
- Ensure the mounting surface is sound and can support the weight of the fixture.
- Use only the specified bulb type and wattage (150W R7s Halogen). Exceeding the maximum wattage may cause overheating and damage to the fixture or create a fire hazard.
- Allow the fixture to cool completely before replacing the bulb or performing any maintenance.

## 2. PACKAGE CONTENTS

---

Please check that all components are present and undamaged before beginning installation. If any parts are missing or damaged, do not attempt to install the fixture and contact your retailer.

- Artemide Talo Mini 21 Wall Light Fixture (1)
- Mounting Hardware Kit (screws, wall anchors, etc.) (1 set)
- Instruction Manual (this document) (1)

**Note:** Bulbs are not included with this fixture. You will need one 150W R7s Halogen bulb.

### 3. SETUP AND INSTALLATION

---

Follow these steps carefully for proper installation. If you are unsure about any step, consult a qualified electrician.

1. **Turn Off Power:** Before starting any electrical work, ensure the power supply to the circuit you are working on is turned off at the main circuit breaker or fuse box. Verify the power is off using a voltage tester.
2. **Prepare Mounting Surface:** Identify the desired location for the wall light. Ensure there is a suitable electrical junction box available.
3. **Attach Mounting Bracket:** Secure the fixture's mounting bracket to the electrical junction box using the screws provided in the hardware kit. Ensure it is firmly attached.
4. **Make Electrical Connections:** Carefully connect the electrical wires from the fixture to the corresponding wires from the junction box.
  - Connect the black wire (Live/Hot) from the fixture to the black wire from the junction box.
  - Connect the white wire (Neutral) from the fixture to the white wire from the junction box.
  - Connect the green or bare copper wire (Ground) from the fixture to the ground wire from the junction box.

Secure all connections with wire nuts and ensure no bare wire is exposed. Gently tuck the wires into the junction box.

5. **Mount the Fixture:** Align the fixture body with the mounting bracket and secure it in place using the provided screws. Ensure the fixture is flush against the wall and stable.
6. **Install the Bulb:** Carefully insert one 150W R7s Halogen bulb into the lamp holder. Do not touch the halogen bulb with bare hands, as oils can reduce bulb life. Use a clean cloth or gloves.
7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker. Test the light to ensure it functions correctly.



**Figure 3.1:** The Artemide Talo Mini 21 Halogen Wall Light in white, mounted on a wall. The light fixture has a sleek, rectangular shape with rounded ends, and it emits a warm, soft light both upwards and downwards, creating an ambient glow on the wall surface.

## 4. OPERATING INSTRUCTIONS

---

The Artemide Talo Mini 21 Halogen Wall Light is designed for simple operation via a standard wall switch.

- **Turning On/Off:** Use the wall switch connected to the fixture's circuit to turn the light on or off.
- **Light Output:** The fixture uses a Halogen bulb, which provides a warm white light, ideal for creating a comfortable and inviting atmosphere.
- **Control Type:** This fixture is designed for 2-wire control, typically operated by a standard on/off wall switch.

## 5. MAINTENANCE

---

Regular maintenance will help preserve the appearance and functionality of your Artemide Talo Mini 21 Wall Light.

### Cleaning

- Always disconnect power before cleaning.
- Allow the fixture to cool completely.
- Wipe the fixture with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or polishes, as they may damage the finish.

### Bulb Replacement

When the bulb needs replacement, follow these steps:

1. **Turn Off Power:** Disconnect power to the fixture at the circuit breaker.
2. **Allow to Cool:** Wait for the fixture and bulb to cool down completely. Halogen bulbs can be very hot.
3. **Remove Old Bulb:** Carefully remove the old 150W R7s Halogen bulb. Refer to the fixture's design for specific access to the bulb compartment.
4. **Install New Bulb:** Insert a new 150W R7s Halogen bulb. Avoid touching the glass part of the bulb with bare hands. Use a clean cloth or gloves to handle the new bulb.
5. **Restore Power:** Restore power at the circuit breaker and test the light.

## 6. TROUBLESHOOTING

---

If you experience issues with your Artemide Talo Mini 21 Wall Light, refer to the common problems and solutions below. If the problem persists, contact a qualified electrician or Artemide customer support.

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check the circuit breaker or fuse. Ensure the wall switch is in the 'ON' position.
	Bulb is faulty or not installed correctly.	Replace the bulb with a new 150W R7s Halogen bulb. Ensure it is seated properly.
	Loose wiring connection.	<b>WARNING: Disconnect power first.</b> Check all wire connections inside the junction box and fixture. Tighten any loose connections.
Light flickers.	Loose bulb or faulty bulb.	Ensure the bulb is securely seated. Try replacing the bulb.
	Incompatible dimmer switch (if applicable).	This fixture is designed for 2-wire control. If using a dimmer, ensure it is compatible with Halogen loads.
Fixture is hot to the touch.	Normal operation for Halogen.	Halogen bulbs generate significant heat. This is normal. Ensure adequate ventilation around the fixture. Do not touch when operating.
	Incorrect bulb wattage.	Ensure you are using a 150W R7s Halogen bulb. Do not exceed the maximum wattage.

## 7. SPECIFICATIONS

---

<b>Brand</b>	Artemide
<b>Model Number</b>	0613018A
<b>Dimensions (L x W x H)</b>	8.25" x 4" x 3.75" (21 cm x 10 cm x 4.3 cm)
<b>Material</b>	Aluminum
<b>Color</b>	White
<b>Lamp Type</b>	Halogen
<b>Bulb Base</b>	R7s
<b>Max Wattage</b>	150W
<b>Input Voltage</b>	120V
<b>Control Type</b>	2-wire (Standard Wall Switch)
<b>Installation Type</b>	Surface Mount
<b>Indoor/Outdoor Usage</b>	Indoor Only
<b>Assembly Required</b>	No (Fixture comes pre-assembled)

## 8. WARRANTY AND SUPPORT

---

Artemide products are manufactured to the highest quality standards. For specific warranty information regarding your Talo Mini 21 Halogen Wall Light, please refer to the warranty card included with your purchase or visit the official Artemide website.

If you require technical assistance, have questions about installation, or need to report a defect, please contact Artemide customer support:

- **Artemide Official Website:** [www.artemide.com](http://www.artemide.com)
- Refer to the website for regional contact information and support hours.