

[Manuals.plus](#) /

> [Finish](#) /

> Finish Jet-Dry Dishwasher Rinse Aid, Compatible with Dishwasher Detergent, Prevents Spots & Residues, Dries, Shine & Protects, 23 oz, 225 Washes.

Finish No Model

Finish Jet-Dry Dishwasher Rinse Aid Instruction Manual

Model: No Model | Brand: Finish

INTRODUCTION

The Finish Jet-Dry Dishwasher Rinse Aid is designed to enhance your dishwashing experience by providing superior drying, preventing spots and residues, and adding shine to your dishes and glassware. It works in conjunction with your dishwasher detergent to deliver optimal results, ensuring your dishes come out sparkling clean and dry.





Figure 1: Finish Jet-Dry Dishwasher Rinse Aid product bottle.

KEY BENEFITS

Finish Jet-Dry offers a 3-in-1 solution for your dishwashing needs:

- **Rinses:** Helps to thoroughly rinse away food residues and detergent.
- **Dries:** Provides 3X better drying compared to detergent alone, reducing wet dishes.
- **Shines:** Prevents water spots and film, leaving glasses and dishes with a brilliant shine.

3X BETTER DRYING*

BEFORE



AFTER

*VS DETERGENT ALONE

Figure 2: Visual representation of 3X better drying performance.

FINISH THE JOB WITH ***JET-DRY®*** **3IN1**



**SHINES
AND PROTECTS
GLASSES**

DRIES

**PREVENTS
SPOTS**

Figure 3: Achieve shinier glasses and dishes with Finish Jet-Dry.

SETUP AND FIRST USE

Before using Finish Jet-Dry, locate the rinse aid dispenser in your dishwasher. Most dishwashers are equipped with a dedicated compartment for rinse aid.

1. Open the rinse aid dispenser cap.
2. Carefully add the entire contents of the Finish Jet-Dry bottle into the dispenser.
3. Close the dispenser cap securely.

DID YOU KNOW?

YOUR DISHWASHER HAS ITS OWN RINSE-AID COMPARTMENT



● JET DRY WORKS WITH YOUR DISHWASHER

● REFILL MONTHLY

Figure 4: Filling the dishwasher's rinse aid compartment with Finish Jet-Dry.

OPERATING INSTRUCTIONS

Once filled, Finish Jet-Dry Rinse Aid will be automatically released during each rinse cycle of your dishwasher. For optimal cleaning and drying results, it is recommended to use Finish Jet-Dry in conjunction with a high-quality dishwasher detergent, such as Finish Ultimate dishwasher detergent pods.

- Load your dishwasher as usual.
- Add your preferred dishwasher detergent to its designated compartment.
- Start your dishwasher cycle.

USE TOGETHER FOR SPARKLING RESULTS!



FOR:

**THE
ULTIMATE
CLEAN**

DRYING

**PRACTICALLY
SPOTLESS
RESULTS**

Figure 5: For optimal results, use Finish Jet-Dry with Finish Ultimate dishwasher detergent.

MAINTENANCE

To maintain consistent performance and ensure your dishes remain spotless and dry, refill the rinse aid dispenser approximately once a month, or when the indicator on your dishwasher signals a low rinse aid level.



Figure 6: Monitor your dishwasher's rinse aid indicator and refill monthly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dishes are still wet or spotty after cycle.	Rinse aid dispenser is empty or low.	Refill the Finish Jet-Dry rinse aid dispenser.
Hard water marks or residue on dishes.	Insufficient rinse aid or very hard water.	Ensure dispenser is full. Consider using a dishwasher cleaner regularly if hard water is severe.
Glasses appear cloudy or dull.	Lack of shine enhancement.	Verify Finish Jet-Dry is being dispensed. It is specifically designed to protect glasses and enhance shine.



Figure 7: Finish Jet-Dry helps prevent residue and spots on dishes.

SPECIFICATIONS

- **Brand:** Finish
- **Item Form:** Liquid
- **Scent:** Liquid Original, Green Apple
- **Number of Items:** 1
- **Product Dimensions:** 2.19 x 3.84 x 8.81 inches
- **Item Weight:** 1.65 Pounds
- **Manufacturer:** Reckitt Benckiser
- **Country of Origin:** USA
- **Model Number:** No Model

SAFETY INFORMATION

CAUTION: EYE IRRITANT. Read precautions on back of product packaging before use.

For detailed ingredient information, please visit the manufacturer's website: www.rbnainfo.com.

Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

ADDITIONAL RESOURCES

For further information or support, please refer to the official Finish website or contact their customer service.

- Official Finish Store: [Visit the Finish Store on Amazon](#)
- Instructions for Use (PDF): [Download PDF](#)

© 2025 Finish. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question