### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > BFT MITTO B RCB02 Genuine Remote Control User Manual

### BFT 2613008

# **BFT MITTO B RCB02 Genuine Remote Control User Manual**

Model: 2613008

# 1. PRODUCT OVERVIEW

The BFT MITTO B RCB02 is a genuine 2-channel remote control designed for operating BFT gate and garage door automation systems. This compact and ergonomic device provides reliable control over your automated entry points. It features two distinct buttons for controlling different functions or multiple gates/doors.



Image 1.1: Front view of the BFT MITTO B RCB02 remote control, showing its two control buttons and the BFT logo.

• Model: D111904

Channels: 2-channel operationConnectivity: Radio Frequency

• Ergonomic Design: Designed for comfortable handling.

# 2. SETUP AND BATTERY INSTALLATION

# 2.1. Battery Requirements

The BFT MITTO B RCB02 remote control requires one LR44 battery for operation.

# 2.2. Battery Installation/Replacement

- 1. Locate the battery compartment on the remote control. This is typically on the back or side, secured by a small screw or a clip.
- 2. Using a small screwdriver or a coin, carefully open the battery compartment cover.
- 3. Remove the old battery (if replacing).
- 4. Insert the new LR44 battery, ensuring the positive (+) and negative (-) terminals are correctly aligned according to the markings inside the compartment.
- 5. Replace the battery compartment cover and secure it.

# 2.3. Programming the Remote Control

Programming the BFT MITTO B RCB02 remote control to your gate or garage door opener system typically involves a specific procedure that varies depending on the model of your BFT receiver unit. Please refer to the instruction manual provided with your BFT gate or garage door opener system for detailed programming steps. General programming methods often include:

- **Self-learning mode:** Activating a programming button on the receiver unit and then pressing a button on the new remote.
- Cloning from an existing remote: Using a working remote to transmit its code to the new remote.
- Using a programming device: For advanced installations, a dedicated programmer might be used.

Ensure the remote control is within range of the receiver during the programming process.

# 3. OPERATING INSTRUCTIONS

Once programmed, the BFT MITTO B RCB02 remote control is straightforward to operate.

- 1. **Identify Buttons:** The remote has two distinct buttons. Refer to your system's programming to know which button controls which function (e.g., open/close gate, pedestrian access, garage door).
- Activate Function: Point the remote control towards your gate or garage door opener system (if lineof-sight is required for your specific receiver) and press the desired button firmly for approximately one second.
- 3. **Observe Response:** The gate or garage door should begin its programmed action (open, close, stop).
- 4. **Range:** Operate the remote within the effective range of your receiver. Obstructions can reduce this range.

#### 4. MAINTENANCE

# 4.1. Battery Replacement

Replace the LR44 battery when the remote's operating range decreases significantly or if the indicator light (if present) does not illuminate when a button is pressed. Refer to Section 2.2 for battery installation instructions.

### 4.2. Cleaning

Clean the remote control with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the remote in water, as this can damage the internal electronics.

# 4.3. Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. Avoid dropping the remote or subjecting it to strong impacts.

# 5. TROUBLESHOOTING

#### · Remote not working:

- Check the battery. Replace it if it's old or depleted (refer to Section 2.2).
- Ensure the remote is properly programmed to your receiver (refer to Section 2.3).
- Verify that the receiver unit for your gate/garage door is powered on and functioning correctly.

### • Reduced operating range:

- · Replace the battery.
- Check for obstructions between the remote and the receiver.
- Ensure there are no sources of radio interference nearby.

### • Gate/door opens/closes unexpectedly:

This is unlikely to be caused by the remote itself unless a button is being accidentally pressed.
Check for external interference or issues with the main gate/door opener system.

If troubleshooting steps do not resolve the issue, contact a qualified BFT technician or your product supplier for assistance.

# 6. SPECIFICATIONS

Feature	Detail
Brand	BFT
Model Number	2613008 (D111904)
Channels	2
Connectivity Technology	Radio Frequency
Battery Type	1 x LR44 (required)
Color	Blue
Special Feature	Ergonomic
Item Weight	0.176 ounces
Product Dimensions	11.81 x 76.77 x 102.36 inches (Note: These dimensions appear to be for packaging or shipping; actual remote dimensions are significantly smaller.)

# 7. WARRANTY AND SUPPORT

For specific warranty information regarding your BFT MITTO B RCB02 remote control, please refer to the documentation provided at the time of purchase or contact your authorized BFT dealer or the retailer from whom you purchased the product. Warranty terms and conditions can vary by region and seller. For technical support or further assistance, please contact your local BFT service center or the official BFT website for contact details.

Manufacturer: Sice

#### Related Documents - 2613008



### BFT Mitto 2M/4M Remote Coding Instructions: A Comprehensive Guide

Learn how to program your BFT Mitto 2M and 4M remote controls for garage and gate openers. This guide covers coding for receivers with and without digital screens, including important safety warnings.



### BFT MITTO 2B Remote Coding Instructions | Retro Remotes

Step-by-step guide for coding BFT MITTO 2B remotes for gate openers, covering existing remote and receiver LCD screen methods. Includes troubleshooting tips.



# BFT MITTO COOL C4 Remote Control Transmitter - Technical Specifications and Safety

Official technical specifications, safety warnings, and compliance information for the BFT MITTO COOL C4 remote control transmitter, operating at 433.92 MHz. Includes battery information and FCC/Industry Canada compliance.




### BFT CLONIX1-2 & MITTO 2-4 433MHz Radio Control System Installation Guide

Comprehensive installation guide for the BFT CLONIX1-2 receiver and MITTO 2-4 433MHz radio control transmitters, covering programming, cloning, safety, and technical specifications for gate and door automation.



### BOTTICELLI BT AV 650 Overhead and Sectional Garage Door Automation Manual

Installation and user's manual for the BOTTICELLI BT AV 650 automation system for sectional and overhead garage doors. Includes technical specifications, installation instructions, safety warnings, and troubleshooting.



# BFT MITTO COOL C4 Remote Control - Safety, Specifications, and Compliance

Learn about the BFT MITTO COOL C4 remote control, including crucial safety warnings regarding battery ingestion, proper handling, technical specifications, and regulatory compliance information (FCC, CE, Industry Canada).