

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Lumisky](#) /

› [Lumisky 303091 Wireless LED Sphere Light User Manual](#)

## Lumisky 303091

# Lumisky 303091 Wireless LED Sphere Light User Manual

## INTRODUCTION

---

This manual provides essential instructions for the safe and efficient use of your Lumisky 303091 Wireless LED Sphere Light. The Bobby C50 is a versatile, rechargeable LED sphere light designed for both indoor and outdoor environments, including use in swimming pools. It features multicolor illumination, remote control operation, and a durable polyethylene construction.

## SAFETY INSTRUCTIONS

---

- Read all instructions before use and retain for future reference.
- Ensure the product is fully charged before its first use.
- Use only the provided induction charging station and power adapter.
- Do not attempt to open, modify, or repair the light sphere or charging station. This will void the warranty and may cause damage or injury.
- Keep the charging station dry. It is not waterproof.
- The light sphere is rated IP66, meaning it is protected against powerful water jets and is suitable for temporary immersion, such as floating in a pool. However, avoid prolonged submersion.
- Keep away from extreme temperatures and direct heat sources.
- Dispose of the product and its battery responsibly according to local regulations.

## PACKAGE CONTENTS

---

Verify that all items are present in the package:


- Lumisky 303091 LED Sphere Light (Bobby C50)
- Induction Charging Station
- Remote Control
- User Manual (this document)

## SETUP

---

### Charging the Sphere Light

1. Connect the power adapter to the induction charging station.
2. Place the Lumisky LED Sphere Light directly onto the induction charging station. Ensure proper alignment for charging to begin.
3. The light will indicate charging status (e.g., a specific LED color or pattern).
4. Allow 6-8 hours for a full charge. A fully charged sphere provides up to 12 hours of illumination.



The induction charging base for the Lumisky LED sphere light, featuring a DC 5V power input for wireless charging.

## OPERATING INSTRUCTIONS

---

### Power On/Off

Press the power button on the remote control or on the base of the sphere light to turn the unit on or off.

## Color Selection and Modes

Use the remote control to customize the lighting experience:

- **Color Buttons:** Select specific colors such as red, green, blue, white, or pink.
- **Brightness Adjustment:** Increase or decrease the light intensity. The light provides over 100 Lumens of illumination.
- **Mode Selection:** Choose between different dynamic lighting modes:
  - **Disco Mode:** Rapid color changes for an energetic ambiance.
  - **Zen Mode:** Slow, gradual color transitions for a relaxing atmosphere.

## Placement and Usage

The Lumisky LED Sphere Light is designed for versatile placement:

- **Indoor Use:** Place it in living rooms, bedrooms, or any indoor space to add a decorative touch and ambient lighting.
- **Outdoor Use:** Ideal for gardens, patios, terraces, or poolside areas. Its IP66 rating ensures resistance to splashes and rain.
- **Floating Use:** The sphere is designed to float on water, making it perfect for illuminating swimming pools or ponds.



Several Lumisky LED sphere lights illuminate a pool area at night, showcasing their vibrant colors and ability to float.



Lumisky LED sphere lights create an inviting ambiance in a pool setting during twilight, displaying various colors.



A collection of Lumisky LED sphere lights of varying sizes placed indoors, demonstrating their use as decorative lighting.

## MAINTENANCE

---

### Cleaning

To clean the sphere light, use a soft cloth with warm water and mild soap. Avoid abrasive cleaners or solvents that could damage the polyethylene material.

### Storage

If the light will not be used for an extended period, ensure it is fully charged before storing it in a cool, dry place. Recharge periodically to maintain battery health.

## TROUBLESHOOTING

---

- **Light does not turn on:**
  - Ensure the sphere is fully charged.
  - Check if the remote control battery needs replacement.
- **Remote control is not working:**

- Replace the battery in the remote control.
  - Ensure there is a clear line of sight between the remote control and the light sphere.
  - Confirm the remote control is within operational range.
- **Short battery life:**
    - Ensure the sphere is charged for the recommended 6-8 hours.
    - Battery life can vary based on brightness settings and selected color modes. Higher brightness and dynamic modes consume more power.

## SPECIFICATIONS

<b>Brand</b>	Lumisky
<b>Model Number</b>	303091
<b>Dimensions (L x W x H)</b>	50 x 50 x 50 cm
<b>Weight</b>	1.84 Kilograms
<b>Material</b>	Thick Rotomolded Polyethylene
<b>IP Rating</b>	IP66 (Protected against powerful water jets)
<b>Power</b>	5 Watts
<b>Battery Life</b>	Up to 12 hours
<b>Charging Time</b>	6-8 hours (via induction charging station)
<b>Light Source</b>	LED, Multicolor
<b>Included Components</b>	Induction charging station, remote control
<b>Energy Label</b>	G ( <a href="#">View Energy Label</a> )



The energy efficiency label for the Lumisky Bobby C50 LED sphere light, indicating its energy class as G.

## WARRANTY

The Lumisky 303091 Wireless LED Sphere Light comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

## SUPPORT

For further assistance, technical support, or warranty inquiries, please contact your retailer or the manufacturer directly. Refer to the product packaging or manufacturer's website for contact information.

