

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Franke](#) /

› [Franke FBBG2716 Stainless Steel Sink Grid Instruction Manual](#)

Franke FBBG2716

Franke FBBG2716 Stainless Steel Sink Grid

INSTRUCTION MANUAL

Introduction

This manual provides essential information for the proper installation, use, and maintenance of your Franke FBBG2716 Stainless Steel Sink Grid. This product is designed to protect the bottom of your sink from scratches and stains, extending its lifespan and maintaining its appearance. Please read these instructions carefully before using the product.

The Franke FBBG2716 sink grid is custom-fit for specific FrankeUSA sink models: **SC3322-1**, **SGR3322-1**, and **SP3322-1**. Ensure your sink model is compatible before installation.



Image 1: Full view of the Franke FBBG2716 Stainless Steel Sink Grid, showing the overall design and central drain opening.

Product Features

- **Stainless Steel Construction:** Durable and resistant to corrosion, ensuring long-lasting performance.
- **Sink Protection:** Effectively shields the sink bottom from scratches, dents, and stains caused by dishes, pots, and utensils.
- **PVC Feet:** Equipped with non-slip PVC feet that elevate the grid, preventing direct contact with the sink surface and allowing water to drain freely.
- **Multi-functional Design:** Can also be utilized as a cooling rack for baked goods, a dishware drainer, or a food preparation/rinse rack.
- **Custom-Fit:** Specifically designed to fit FrankeUSA sink models SC3322-1, SGR3322-1, and SP3322-1, ensuring optimal coverage and stability.

Setup and Installation

1. **Unpack the Grid:** Carefully remove the sink grid from its packaging. Inspect for any signs of damage.

2. **Clean Your Sink:** Ensure your sink is clean and free of debris before placing the grid.
3. **Position the Grid:** Gently lower the stainless steel sink grid into the bottom of your compatible FrankeUSA sink.
4. **Align with Drain:** Orient the grid so that the circular opening aligns with your sink's drain. The PVC feet should rest evenly on the sink surface.
5. **Verify Stability:** Ensure the grid sits flat and stable in the sink. Adjust if necessary.



Image 2: Close-up of a corner of the sink grid, illustrating the protective PVC feet.

Operating Instructions

Once installed, the Franke FBBG2716 Sink Grid operates passively to protect your sink. Place dishes, pots, and other items directly onto the grid. The elevated design allows water to flow freely to the drain, preventing items from sitting in standing water and reducing the risk of scratches or damage to the sink's finish.

For alternative uses:

- **Cooling Rack:** Place hot items directly on the grid to cool.
- **Dish Drainer:** Use it to air-dry washed dishes and utensils.

- **Food Prep/Rinse Rack:** Position items on the grid for washing or preparing food, allowing liquids to drain directly into the sink.

Maintenance and Care

To ensure the longevity and appearance of your Franke FBBG2716 Sink Grid, follow these simple maintenance guidelines:

- **Regular Cleaning:** Wipe the grid with a dry cloth regularly to remove food particles and water spots.
- **Deep Cleaning:** For more thorough cleaning, use a mild soap and warm water. Avoid abrasive cleaners, steel wool, or harsh chemicals, as these can damage the stainless steel finish.
- **Rinse and Dry:** After cleaning, rinse the grid thoroughly with clean water and dry it immediately with a soft cloth to prevent water spots and mineral buildup.
- **Inspect PVC Feet:** Periodically check the PVC feet for wear or damage. Replace if necessary to maintain proper elevation and sink protection.



Image 3: Detailed view of the sink grid's wire construction and PVC feet, highlighting areas for cleaning and inspection.

Troubleshooting

Most issues with a sink grid are minor and easily resolved.

- **Grid Does Not Fit:**

Solution: Verify that your sink is one of the compatible FrankeUSA models (SC3322-1, SGR3322-1, SP3322-1). This grid is custom-fit and may not work with other sink dimensions.

- **Grid Slides or is Unstable:**

Solution: Check if all PVC feet are present and properly attached. Ensure the sink surface is clean and dry where the feet rest. If feet are worn, they may need replacement.

- **Water Spots or Stains on Grid:**

Solution: This is common with stainless steel, especially in hard water areas. Clean regularly with a mild stainless steel cleaner or a mixture of vinegar and water, then rinse and dry immediately.

Specifications

Brand	Franke
Model Number	FBBG2716
Material	Stainless Steel
Color	Stainless Steel
Size	27 inches x 16.5 inches
Product Dimensions (D x W x H)	41.9D x 68.6W x 41.9H Centimeters
Item Weight	1.43 kg (1 kg 430 g)
Compatible Sink Models	SC3322-1, SGR3322-1, SP3322-1
UPC	039487153565
Manufacturer	Franke USA

Warranty Information

Franke products are manufactured to high-quality standards. For specific warranty terms and conditions applicable to your Franke FBBG2716 Stainless Steel Sink Grid, please refer to the warranty documentation provided at the time of purchase or visit the official Franke website. Warranty coverage typically addresses manufacturing defects under normal use.

Customer Support

If you have any questions, require assistance, or need to report an issue with your Franke FBBG2716 Sink Grid, please contact Franke customer service. You can typically find contact information on the official Franke

website or through your product retailer.

Franke Official Website: www.franke.com

© 2023 Franke. All rights reserved. Information in this manual is subject to change without notice.