



[Manuals.plus](#) /

> [San Jamar](#) /

> San Jamar Tear-N-Dry Essence T8090TBK Automatic Paper Towel Dispenser User Manual

## San Jamar T8090TBK

# San Jamar Tear-N-Dry Essence T8090TBK Automatic Paper Towel Dispenser User Manual

Model: T8090TBK

## INTRODUCTION

---

The San Jamar Tear-N-Dry Essence T8090TBK Automatic Paper Towel Dispenser provides a touchless and efficient solution for various environments, including bathrooms, kitchens, and restaurants. Constructed from durable plastic, this dispenser is designed for convenience and reliability in high-traffic areas. It utilizes infrared technology for hands-free dispensing of 10-inch paper towel portions, promoting hygiene and reducing waste. The dispenser features a durable, transparent, and theft-proof cover, allowing for easy monitoring of the paper roll status. It is compatible with standard 8-inch paper towels and operates on four D-cell batteries, ensuring long-term functionality with minimal maintenance.

## SAFETY INFORMATION

---

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- Ensure the dispenser is mounted securely to a stable wall surface to prevent accidental falls.
- Use only the specified D-cell batteries. Do not mix old and new batteries, or different types of batteries.
- Keep hands clear of the dispensing mechanism during operation to avoid injury.
- Do not expose the dispenser to excessive moisture or direct water spray.
- Keep out of reach of children to prevent misuse or injury.

## PACKAGE CONTENTS

---

The San Jamar Tear-N-Dry Essence T8090TBK Automatic Paper Towel Dispenser package includes:

- 1 x San Jamar Tear-N-Dry Essence T8090TBK Automatic Paper Towel Dispenser
- 1 x Instruction Manual
- Mounting hardware is **not included** and must be purchased separately.

- 4 x D-cell batteries are **not included** and must be purchased separately.

## SPECIFICATIONS

---

Feature	Specification
Model Number	T8090TBK
Material	Acrylonitrile Butadiene Styrene (Plastic)
Color	Black
Dimensions (L x W x H)	10"L x 14.75"W x 12.25"H (approximate)
Item Weight	1 Ounce (empty)
Mounting Type	Surface Mount
Power Source	4 x D-Cell Batteries (not included)
Towel Compatibility	Standard 8-inch paper towel rolls
Dispensing Length	10-inch portions

*Note: Dimensions are approximate and may vary slightly.*

## SETUP

---

### 1. Mounting the Dispenser

The dispenser must be mounted level for proper operation. Mounting hardware is not included.

1. Choose a suitable wall location, ensuring sufficient clearance for dispensing and maintenance.
2. Open the dispenser cover using the provided key.
3. Mark the desired mounting points on the wall using the dispenser's backplate as a template.
4. Drill pilot holes and insert appropriate wall anchors (if necessary) for your wall type.
5. Secure the dispenser to the wall using screws. Ensure it is firmly attached and level.

### 2. Battery Installation

The Tear-N-Dry Essence dispenser requires four D-cell alkaline batteries for operation. Ensure batteries are inserted with correct polarity.

1. Open the dispenser cover.
2. Locate the battery compartment, typically at the top rear of the dispenser's interior.
3. Insert four new D-cell batteries, observing the correct polarity (+/-) as indicated in the compartment.
4. Close the battery compartment cover securely.

THE BRAND THAT  
TAKES YOUR  
OPERATION  
FROM ROUTINE  
TO REMARKABLE.



DISPENSES STANDARD  
10-INCH SHEETS

REPLACEABLE DRIVE MODULE AND  
BATTERY-POWERED OPERATION

DISPENSER WORKS WITH A WIDE  
RANGE OF PAPER TOWEL ROLLS

*Image: Internal view of the dispenser, highlighting the battery compartment and paper roll loading area.*

### 3. Loading Paper Towel Rolls

The dispenser is compatible with standard 8-inch paper towel rolls of any brand and quality.

1. Open the dispenser cover using the key.
2. Place the new paper towel roll onto the roll holders inside the dispenser. Ensure the paper feeds from the bottom of the roll.
3. Thread the leading edge of the paper towel through the dispensing mechanism until it is visible at the bottom opening.
4. Close the dispenser cover and lock it with the key.

## For 8" (203mm) Paper Towel Rolls of Any Brand and Quality



*Image: Illustration of compatible 8-inch paper towel rolls.*

### OPERATING INSTRUCTIONS

---

The San Jamar Tear-N-Dry Essence T8090TBK is a touchless automatic dispenser. To dispense paper towels:

1. Place your hand or fingers directly below the dispensing opening where the sensor is located.
2. The dispenser will automatically activate and dispense a 10-inch portion of paper towel.
3. Gently pull down on the dispensed paper towel to tear it off.
4. If more paper is needed, repeat the process.

# CONSISTENT DELIVERY



*Image: A user demonstrating the touchless dispensing feature.*

*Video: This video demonstrates the operation of the San Jamar T809 commercial paper towel dispenser, showing how paper towels are dispensed automatically.*

## MAINTENANCE

---

### Cleaning

Regular cleaning helps maintain hygiene and the appearance of your dispenser.

- Wipe the exterior of the dispenser with a soft, damp cloth and mild soap.
- Avoid using abrasive cleaners or solvents, as these can damage the plastic finish.
- Ensure the sensor area is kept clean and free from obstructions for optimal performance.

### Refilling Paper Towels

When the paper towel roll is low or empty, replace it following these steps:

1. Unlock and open the dispenser cover.
2. Remove any remaining paper towel core or small roll.
3. Install a new 8-inch paper towel roll as described in the "Loading Paper Towel Rolls" section.
4. Close and lock the dispenser cover.

## Battery Replacement

When the batteries are low, the dispenser's performance may degrade (e.g., slower dispensing, inconsistent operation). Replace all four D-cell batteries simultaneously.

1. Unlock and open the dispenser cover.
2. Open the battery compartment cover.
3. Remove the old D-cell batteries.
4. Insert four new D-cell batteries, ensuring correct polarity.
5. Close the battery compartment cover and then the dispenser cover, locking it.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Paper towel not dispensing	Low or dead batteries Paper roll empty or jammed Sensor obstructed	Replace batteries Refill or clear paper jam Clean sensor area
Continuous dispensing	Sensor malfunction or obstruction	Clean sensor area. If problem persists, contact support.
Paper towel dispenses too slowly	Low batteries	Replace batteries
Dispenser cover will not close/lock	Paper roll not seated correctly Obstruction in the cover mechanism	Ensure paper roll is properly installed Check for any foreign objects and remove them

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact San Jamar customer service directly. Keep your purchase receipt as proof of purchase.

*Video: An overview of CFS Brands, the parent company of San Jamar, highlighting their commitment to quality and service in the food service industry.*