

[Manuals.plus](#) /

› [Michael Kors](#) /

› Michael Kors Bradshaw MK5799 Women's Chronograph Watch User Manual

Michael Kors MK5799

Michael Kors Bradshaw MK5799 Women's Chronograph Watch User Manual

INTRODUCTION

This manual provides detailed instructions for the Michael Kors Bradshaw MK5799 women's chronograph watch. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your timepiece.

SETUP

Unboxing

Carefully remove the watch from its packaging. Inspect the watch for any visible damage.



Image: The Michael Kors watch box, indicating the product's original packaging.

Initial Time Setting

Your Michael Kors Bradshaw watch is equipped with a quartz movement.

1. Pull the crown (the small knob on the side of the watch) out to position 2.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Push the crown back into position 1 to start the watch.



Image: Side view of the watch, highlighting the crown and chronograph pushers for setting and operation.

OPERATING YOUR WATCH

Chronograph Function

The chronograph function allows for precise time measurement. Your watch features three subdials:

- 24-hour time display.
- Minute counter for the chronograph.
- Second counter for the chronograph.

1. To start the chronograph, press the top pusher (A). The chronograph second hand will begin to move.
2. To stop the chronograph, press the top pusher (A) again. The elapsed time will be indicated by the chronograph hands.
3. To reset the chronograph, press the bottom pusher (B). The chronograph hands will return to their zero positions.




Image: Front view of the watch dial, showing the main hands, chronograph subdials, and date window.

Date Window

The watch features a date window. To set the date:

1. Pull the crown out to position 1 (first click).
2. Turn the crown clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown back into its original position.

Water Resistance

This watch is water resistant up to 100 meters (330 feet) or 10 ATM. This means it is suitable for bathing, swimming, snorkeling, and shallow diving. It is not recommended for high-impact water sports or deep-sea diving. Ensure the crown is fully pushed in before any water exposure.

MAINTENANCE

Cleaning

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

The watch is powered by a Lithium Metal battery. When the battery needs replacement, it is recommended to take the watch to an authorized Michael Kors service center or a reputable watchmaker to ensure proper sealing and water resistance.

Bracelet Adjustment

The stainless steel bracelet links can be removed or added for a customized fit. This procedure should be performed by a professional watchmaker to prevent damage to the bracelet or watch.



Image: Diagram illustrating the watch's dimensions, including case size (36mm) and strap/lug width (18mm), relevant for bracelet adjustments.

TROUBLESHOOTING

Watch Not Running

- Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
- The battery may be depleted. Refer to the "Battery Replacement" section.

Incorrect Time/Date

- Ensure the crown is fully pushed in after setting the time/date.
- If the time is consistently incorrect, the watch may require servicing.

Water Inside the Watch

If moisture appears inside the watch, immediately take it to an authorized service center. Do not attempt to open the watch yourself, as this will void the warranty and may cause further damage.

SPECIFICATIONS

Feature	Detail
Model Number	MK5799
Case Size	36mm
Case Material	Stainless Steel
Dial Color	Rose Gold
Crystal	Mineral
Band Material	Stainless Steel
Band Width	18mm
Movement	Quartz Chronograph
Water Resistance	10 ATM (100 meters / 330 feet)
Battery Type	Lithium Metal (included)

WARRANTY AND SUPPORT

Warranty Information

Your Michael Kors watch is covered by a limited warranty against manufacturing defects. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

Customer Support

For further assistance, service, or repairs, please contact Michael Kors customer support or visit an authorized service center. Contact information can typically be found on the official Michael Kors website or in your warranty documentation.

Online resources: www.michaelkors.com