

[Manuals.plus](#) /

> [Zanussi](#) /

> Genuine Zanussi ZJ1218 Washing Machine Door Seal Instruction Manual

## Zanussi ZJ1218

# Genuine Zanussi ZJ1218 Washing Machine Door Seal

Instruction Manual

## 1. INTRODUCTION

This manual provides essential information for the proper installation, maintenance, and troubleshooting of your Genuine Zanussi ZJ1218 Washing Machine Door Seal. This part is a critical component designed to prevent water leakage during the washing cycle and ensure the efficient operation of your appliance.

Using genuine replacement parts ensures compatibility and maintains the performance standards of your Zanussi washing machine.



Image 1: Genuine Zanussi ZJ1218 Washing Machine Door Seal. This image displays the circular, grey rubber seal designed for the washing machine door, featuring its distinct folds and grooves.

## 2. SETUP (INSTALLATION)

### 2.1 Safety Precautions

- Always disconnect the washing machine from the main power supply before beginning any installation or maintenance.
- Turn off the water supply to the washing machine.
- Wear appropriate personal protective equipment, such as gloves, if necessary.

### 2.2 Tools Required

- Screwdriver (Phillips and/or flathead)
- Pliers (optional, for spring clamps)
- Small container for screws/parts

### 2.3 Installation Steps

1. **Access the Seal:** Open the washing machine door. You may need to remove the front panel of the washing machine to gain full access to the seal and its retaining clamps. Consult your washing machine's specific service manual for panel removal instructions.
2. **Remove Outer Clamp:** Locate the outer retaining clamp (usually a spring-loaded wire or screw-tightened band) around the front of the door seal. Carefully remove this clamp.
3. **Detach Seal from Front:** Gently pull the front lip of the old door seal away from the washing machine's outer drum.
4. **Remove Inner Clamp:** Reach inside the drum and locate the inner retaining clamp that secures the seal to the inner drum or tub. Remove this clamp.
5. **Remove Old Seal:** Carefully pull the old door seal completely out of the washing machine. Note its orientation for reference.
6. **Clean Area:** Thoroughly clean the area where the new seal will be installed, removing any residue, mold, or debris.
7. **Install New Seal:** Position the new Zanussi door seal, ensuring any drainage holes or alignment marks on the seal match those on the washing machine drum. Carefully fit the inner lip of the seal onto the inner drum/tub.
8. **Secure Inner Clamp:** Reinstall the inner retaining clamp, ensuring it is securely seated around the seal and drum.
9. **Secure Outer Clamp:** Fit the outer lip of the seal onto the front of the washing machine opening. Reinstall the outer retaining clamp, ensuring the seal is evenly seated and taut.
10. **Reassemble:** Reattach any panels or components that were removed.
11. **Test:** Reconnect the water supply and power. Run a short, empty wash cycle to check for any leaks before normal use.

## 3. OPERATING (FUNCTIONALITY)

The door seal is a passive component that plays a crucial role in the washing machine's operation by creating a watertight barrier between the drum and the outer casing when the door is closed. A properly installed and maintained door seal ensures that water remains contained within the drum during wash and spin cycles, preventing leaks and protecting internal components.

Ensure the washing machine door closes firmly and completely, compressing the seal, before starting any wash program.

## 4. MAINTENANCE

---

Regular maintenance of the door seal is vital for its longevity and to prevent common issues such as mold growth and unpleasant odors.

### 4.1 Cleaning the Door Seal

- After each wash, wipe down the inside of the door seal with a clean cloth to remove any excess water, lint, or detergent residue.
- Periodically, clean the seal more thoroughly using a mild detergent solution or a mixture of white vinegar and water. Pay attention to the folds and crevices where residue can accumulate.
- For stubborn mold or mildew, a diluted bleach solution (1 part bleach to 10 parts water) can be used, but ensure to rinse thoroughly afterwards to prevent damage to the rubber.
- Leave the washing machine door ajar after use to allow air circulation and prevent moisture buildup, which can lead to mold and odors.

### 4.2 Inspection

Regularly inspect the door seal for signs of wear, tear, cracks, or foreign objects lodged within its folds. Even small tears can lead to leaks. If significant damage is observed, the seal should be replaced.

## 5. TROUBLESHOOTING

---

Common issues related to the door seal and their potential solutions:

- **Water Leaks:**
  - Check if the seal is properly seated and not twisted or dislodged.
  - Inspect the seal for any tears, holes, or cracks.
  - Ensure no foreign objects (e.g., small clothing items, coins) are trapped between the seal and the door.
  - Verify that the retaining clamps are securely in place.
- **Unpleasant Odors/Mold:**
  - Clean the seal thoroughly as described in the Maintenance section.
  - Ensure the door is left ajar after use to allow drying.
  - Run a hot wash cycle with a washing machine cleaner or white vinegar.
- **Difficulty Closing Door:**
  - Check if the seal is correctly aligned and not bulging excessively.
  - Ensure no items of clothing are caught in the door.

## 6. SPECIFICATIONS

---

Attribute	Value
Product Type	Washing Machine Door Seal

Brand	Zanussi
Model Compatibility	ZJ1218 (and other compatible models)
Manufacturer Part Number	1320041153
ASIN	B00COPSLCI

## 7. WARRANTY

---

This Genuine Zanussi ZJ1218 Washing Machine Door Seal is covered by the manufacturer's standard warranty. For specific details regarding warranty terms, duration, and claim procedures, please refer to the documentation provided with your original purchase or contact Zanussi customer service directly. Keep your proof of purchase for warranty claims.

## 8. SUPPORT

---

For technical assistance, installation queries, or further support regarding your Zanussi washing machine or this replacement part, please contact Zanussi customer support. You may also consult an authorized appliance service technician for professional installation or repair.

Please have your washing machine model number and the part's manufacturer part number (1320041153) ready when contacting support.