

Kohler K-72419-2BZ

KOHLER K-72419-2BZ Awaken Showerhead Instruction Manual

Model: K-72419-2BZ | Brand: KOHLER

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your KOHLER K-72419-2BZ Awaken Showerhead. Please read all instructions carefully before installation and use to ensure proper function and longevity of the product.

The Awaken showerhead is designed to deliver a superior showering experience with its advanced spray performance, offering three distinct spray types: wide coverage, intense drenching, and targeted spray. Its ergonomically designed thumb tab allows for smooth transitions between these spray modes. The sculpted sprayface and Oil Rubbed Bronze finish complement contemporary and minimalist bathroom designs.

SETUP AND INSTALLATION

The KOHLER K-72419-2BZ Awaken Showerhead is designed for easy installation onto a standard 1/2" 14 NPT inlet connection. No specialized tools are typically required beyond basic plumbing tools.

Required Components (Sold Separately)

- Shower arm
- Flange

Installation Steps

1. **Prepare the Shower Arm:** Ensure the shower arm is securely installed into the wall and has a 1/2" 14 NPT threaded connection. Apply plumber's tape to the threads of the shower arm.
2. **Attach the Showerhead:** Thread the Awaken showerhead onto the shower arm. Hand-tighten first, then use a wrench to tighten an additional 1/4 to 1/2 turn. Do not overtighten, as this can damage the connections.
3. **Check for Leaks:** Turn on the water supply and check for any leaks around the connection points. If leaks occur, tighten slightly more or reapply plumber's tape.



Image: Rear view of the Awaken showerhead, illustrating the standard threaded connection point for installation onto a shower arm.



Image: The KOHLER K-72419-2BZ Awaken Showerhead in Oil Rubbed Bronze, ready for use after installation.

OPERATING INSTRUCTIONS

The KOHLER Awaken Showerhead features three distinct spray functions, easily adjustable with a thumb tab located on the sprayface.

Spray Functions

- **Wide Coverage Spray:** Provides a full, enveloping spray for a complete rinse.
- **Intense Drenching Spray:** Delivers a powerful, invigorating stream for a thorough shower.
- **Targeted Spray:** A focused, concentrated spray ideal for rinsing specific areas or for a massage-like experience.

Adjusting Spray Modes

To switch between spray modes, simply move the thumb tab located on the edge of the showerhead's

sprayface. The internal mechanism will smoothly transition to the next spray pattern.



Image: The Awaken showerhead producing a wide, encompassing spray pattern.



Image: The Awaken showerhead delivering an intense, drenching spray for a powerful rinse.




Image: The Awaken showerhead providing a focused, targeted spray for specific rinsing needs.

CARE AND MAINTENANCE

Proper care and maintenance will ensure the long-lasting performance and appearance of your KOHLER Awaken Showerhead.

Cleaning the Sprayface

The showerhead features a **MasterClean sprayface** with an advanced design that resists mineral buildup. To clean, simply wipe the sprayface with a damp cloth. For stubborn mineral deposits, a mild solution of vinegar and water can be used. Avoid abrasive cleaners or scrubbing pads, as these can damage the finish.

Maintaining the Finish

The Oil Rubbed Bronze finish is designed to resist corrosion and tarnishing. To maintain its appearance, clean regularly with a soft, damp cloth. Do not use harsh chemicals, ammonia-based cleaners, or abrasive materials, as these can strip the finish and void the warranty.



Image: Key features highlighting the easy-clean sprayface and lasting finish of the Awaken showerhead.

TROUBLESHOOTING

If you encounter any issues with your KOHLER Awaken Showerhead, please refer to the following common problems and solutions:

- **Low Water Pressure:**
 - Check if the water supply valve is fully open.
 - Inspect the showerhead nozzles for mineral buildup. Clean as described in the Maintenance section.
 - Ensure there are no kinks in the shower arm or supply lines.
- **Leaking from Connection:**
 - Ensure the showerhead is securely tightened to the shower arm.
 - Verify that plumber's tape was applied correctly to the threads during installation. Reapply if necessary.
- **Difficulty Changing Spray Modes:**

- Ensure the thumb tab is free of obstructions or mineral buildup. Clean the sprayface thoroughly.
- If the issue persists, contact KOHLER customer support.

SPECIFICATIONS

Detailed technical specifications for the KOHLER K-72419-2BZ Awaken Showerhead:

Feature	Specification
Brand	Kohler
Model Number	K-72419-2BZ
Style	Showerhead
Color	Oil Rubbed Bronze
Material	Plastic
Finish Type	Oil Rubbed
Installation Type	Wall Mounted
Number of Settings	3 (Wide Coverage, Intense Drenching, Targeted)
Flow Rate	2.0 GPM (7.6 L/min) maximum
Efficiency	WaterSense certified, water-saving features
Item Dimensions (L x W)	4.75"L x 3.63"W
Item Weight	8 ounces
UPC	885612474698



Image: Dimensional drawing illustrating the sizes of different KOHLER Awaken showerhead models.

WARRANTY AND SUPPORT

Warranty Information

This KOHLER Awaken Showerhead is covered by the **KOHLER Faucet Lifetime Limited Warranty**. This warranty covers defects in material and workmanship for as long as the original consumer purchaser owns their home. Please refer to the official KOHLER warranty documentation for full terms and conditions, exclusions, and how to make a claim.

Customer Support

For technical assistance, replacement parts, or warranty inquiries, please contact KOHLER customer service:

- **Website:** www.kohler.com
- **Phone:** Refer to the contact section on the official KOHLER website for your region's specific phone number.

