

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Skip Hop](#) /

› [Skip Hop Treetop Friends Changing Pad Cover Model 276212 User Manual](#)

Skip Hop 276212

Skip Hop Treetop Friends Changing Pad Cover User Manual

Model: 276212

INTRODUCTION

This manual provides instructions for the proper use and care of your Skip Hop Treetop Friends Changing Pad Cover, Model 276212. Please read these instructions carefully before use and retain them for future reference.

SETUP INSTRUCTIONS

The Skip Hop Treetop Friends Changing Pad Cover is designed for easy installation on standard changing pads.

1. **Unpack the Cover:** Carefully remove the changing pad cover from its packaging.
2. **Prepare Changing Pad:** Ensure your changing pad is clean and dry before applying the cover.
3. **Install Cover:** Stretch the elasticized edges of the cover over the changing pad. Ensure the cover fits snugly around all sides of the pad.
4. **Secure Safety Straps:** If your changing pad includes safety straps, thread them through the designated openings in the cover to ensure they remain accessible and functional.



Image: The Skip Hop Treetop Friends Changing Pad Cover securely fitted onto a standard changing pad, showcasing its pattern and proper installation.

OPERATING INSTRUCTIONS

Once installed, the changing pad cover is ready for use. It provides a soft, comfortable, and hygienic surface for changing your baby. Always ensure the baby is supervised while on the changing pad.

CARE AND MAINTENANCE

Proper care will extend the life of your changing pad cover and maintain its quality.

- **Washing:** Machine wash cold with like colors.
- **Drying:** Tumble dry low.
- **Ironing:** Low iron if desired.
- **Bleaching:** Do not use chlorine bleach.



Image: Product packaging displaying the care instructions for the changing pad cover, including washing, drying, and ironing guidelines.

PRODUCT SPECIFICATIONS

| | |
|---------------------|-------------|
| Model Number | 276212 |
| Brand | Skip Hop |
| Material | 100% Cotton |

| | |
|---------------------------|---------------------------|
| Color | Multi |
| Pattern | Printed (Treetop Friends) |
| Product Dimensions | 32 x 16.5 x 6.5 inches |
| Item Weight | 1 pound |

WARRANTY AND SUPPORT

Specific warranty information for the Skip Hop Treetop Friends Changing Pad Cover is not provided in this manual. For detailed warranty terms, product support, or to contact customer service, please visit the official Skip Hop website or refer to the product packaging for contact information.

You can often find additional support and FAQs on the manufacturer's website: www.skiphop.com

