

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vivitek](#) /

› [Vivitek QUMI Q5 HD LED Pocket Projector User Manual](#)

Vivitek Q5

Vivitek QUMI Q5 HD LED Pocket Projector User Manual

Model: Q5

INTRODUCTION

Thank you for choosing the Vivitek QUMI Q5 HD LED Pocket Projector. This compact and versatile projector is designed for both work and entertainment, offering high-definition projection in a portable form factor. It features touch-sensitive controls and is compatible with a variety of devices, including digital cameras, laptops, smartphones, and tablets. The QUMI Q5 also includes a unique web browsing feature for enhanced connectivity. Please read this manual thoroughly before operating your projector to ensure proper use and to maximize its performance and lifespan.

SAFETY INFORMATION

Always observe the following safety precautions to prevent damage to the projector and to ensure your safety.

- Do not block the ventilation openings. Ensure adequate airflow around the projector.
- Do not expose the projector to rain or moisture to avoid fire or electric shock.
- Do not open the projector casing. Refer all servicing to qualified service personnel.
- Use only the power adapter supplied with the projector.
- Avoid looking directly into the projector lens when the lamp is on.
- Keep the projector away from heat sources and direct sunlight.

PACKAGE CONTENTS

Please check that all items are present in your package:

- Vivitek QUMI Q5 HD LED Pocket Projector
- Power Adapter
- Remote Control (with batteries)
- HDMI Cable
- VGA Cable
- User Manual (this document)
- Carrying Pouch

SETUP

1. Projector Placement

Place the projector on a stable, flat surface. Ensure there is sufficient space around the projector for ventilation. The distance from the screen will determine the image size. Adjust the projector's position until the desired image size is achieved.



Figure 1: Front view of the Vivitek QUMI Q5 projector. This image illustrates the compact design and the location of the lens and ventilation openings, crucial for proper placement.

2. Connecting Power

1. Connect the power adapter to the DC IN port on the projector.
2. Plug the other end of the power adapter into a wall outlet.
3. The power indicator light on the projector will illuminate.

3. Connecting Input Sources

The QUMI Q5 supports various input sources.

- **HDMI:** Connect an HDMI cable from your device (e.g., laptop, Blu-ray player) to the HDMI port on the projector.
- **VGA:** Connect a VGA cable from your device to the VGA port on the projector.
- **USB:** Insert a USB drive into the USB port to play media files directly.
- **Audio Out:** Connect external speakers or headphones to the Audio Out port if desired.

Figure 2: Diagram illustrating the various input/output ports on the Vivitek QUMI Q5. This would show the HDMI, VGA, USB, and Audio Out ports for connecting external devices.

OPERATING INSTRUCTIONS

1. Powering On/Off

- **Power On:** Press the Power button on the projector or the remote control. The power indicator will turn blue.
- **Power Off:** Press the Power button again. A confirmation message may appear; select "Yes" to shut down.

2. Adjusting Focus

Rotate the focus ring located near the lens until the projected image is sharp and clear.

Figure 3: Close-up view of the focus ring on the Vivitek QUMI Q5. This image would demonstrate how to manually adjust the focus for a clear projection.

3. Navigating the Menu

Use the touch-sensitive buttons on the projector or the arrow keys on the remote control to navigate through the on-screen menu. Press the "OK" or "Enter" button to select an option.

4. Selecting Input Source

Press the "Source" button on the remote control or navigate to the "Input Source" option in the main menu to select between HDMI, VGA, USB, or internal memory.

5. Web Browsing Feature

The QUMI Q5 includes a built-in web browser. To use this feature:

1. Ensure the projector is connected to a Wi-Fi network (if applicable, instructions for Wi-Fi setup would be here if more detail was available).
2. Navigate to the "Web Browser" application from the main menu.
3. Use the remote control or an external USB mouse/keyboard (if connected) to input URLs and navigate web pages.

MAINTENANCE

1. Cleaning the Lens

Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive cleaners or excessive force, as this can scratch the lens.

2. General Cleaning

Wipe the projector casing with a soft, dry cloth. For stubborn dirt, dampen the cloth slightly with water, then wipe dry immediately. Avoid using chemical cleaners.

3. Storage

When not in use for extended periods, store the projector in its carrying pouch in a cool, dry, and dust-free environment.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No image projected	<ul style="list-style-type: none">• Power cable not connected• Projector not powered on• Incorrect input source selected• Source device not sending signal	<ul style="list-style-type: none">• Check power connection• Press the Power button• Select the correct input source• Ensure source device is on and outputting signal
Image is blurry	<ul style="list-style-type: none">• Focus not adjusted• Projector too far/close to screen	<ul style="list-style-type: none">• Adjust the focus ring• Reposition the projector
No sound	<ul style="list-style-type: none">• Volume too low• External speakers not connected/powered• Source device volume low	<ul style="list-style-type: none">• Increase projector volume• Check external speaker connection and power• Increase volume on source device

SPECIFICATIONS

Model Number	Q5
Brand	Vivitek

Display Resolution (Native)	1280 x 800 (WXGA)
Display Resolution (Maximum)	1920 x 1080
Brightness	500 lumens
Contrast Ratio	10000:1
Aspect Ratio	16:10
Connectivity Technology	HDMI, USB, VGA
Special Feature	3D-Ready
Product Dimensions	1.27 x 6.3 x 4.03 inches
Item Weight	4 pounds

WARRANTY AND SUPPORT

Warranty Information

The Vivitek QUMI Q5 HD LED Pocket Projector comes with a **3-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Vivitek website.

Customer Support

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact Vivitek customer support.

- **Online Support:** Visit the official Vivitek website for FAQs, driver downloads, and support contact forms.
- **Telephone Support:** Refer to your product packaging or the Vivitek website for regional contact numbers.

When contacting support, please have your product model number (Q5) and purchase date available.

