John Deere BG20627

John Deere Original Equipment Weight Kit

MODEL: BG20627 INSTRUCTION MANUAL

1. Introduction

This instruction manual provides essential information for the safe and effective installation, operation, and maintenance of your John Deere Original Equipment Weight Kit, model BG20627. Please read this manual thoroughly before attempting to install or use the product. Retain this manual for future reference.

2. Product Overview

The John Deere Original Equipment Weight Kit BG20627 is designed to add ballast to compatible John Deere agricultural and lawn care equipment. Adding weight can improve traction, stability, and overall performance, especially when operating with front-mounted attachments such as snowblowers, front loaders, or when working on uneven terrain. This kit is an authentic John Deere OEM product, ensuring compatibility and quality.



Figure 1: John Deere Original Equipment Weight Kit BG20627. This image displays the primary components of the weight kit, designed for adding ballast to John Deere equipment.

3. Safety Information

Always prioritize safety when handling and installing equipment. Failure to follow safety instructions can result in serious injury or property damage.

- **Read All Instructions:** Before installation or operation, carefully read and understand all instructions in this manual and your equipment's operator's manual.
- **Personal Protective Equipment (PPE):** Wear appropriate PPE, including safety glasses and gloves, during installation.
- **Lifting Heavy Objects:** The weight kit components may be heavy. Use proper lifting techniques or seek assistance to prevent injury.
- **Secure Equipment:** Ensure the equipment is turned off, parked on a level surface, and the parking brake is engaged before beginning installation. Remove the ignition key.
- **Correct Tools:** Use only the recommended tools for installation.

- **Do Not Modify:** Do not modify the weight kit or any part of your John Deere equipment. Unauthorized modifications can compromise safety and performance.
- **Weight Limits:** Do not exceed the maximum weight capacity specified for your John Deere equipment. Refer to your equipment's operator's manual.

4. Package Contents

Upon opening the package, verify that all components are present and undamaged. If any parts are missing or damaged, contact your authorized John Deere dealer immediately.

- One (1) John Deere Original Equipment Weight Kit BG20627 (main bracket/component)
- Necessary mounting hardware (bolts, nuts, washers, if applicable)

5. Setup and Installation

Follow these general steps for installing the weight kit. Specific mounting locations and procedures may vary depending on your John Deere equipment model. Always consult your equipment's operator's manual for detailed instructions.

1. **Prepare Equipment:** Park your John Deere equipment on a firm, level surface. Turn off the engine, engage the parking brake, and remove the ignition key.
2. **Identify Mounting Points:** Locate the designated mounting points on your equipment for ballast weights. These are typically on the rear of the tractor or mower.
3. **Position Weight Kit:** Carefully lift and position the weight kit onto the designated mounting points. Ensure proper alignment with bolt holes.
4. **Secure Hardware:** Insert the provided mounting hardware (bolts, washers, nuts) through the weight kit and equipment mounting points. Hand-tighten all fasteners.
5. **Final Tightening:** Using appropriate wrenches, securely tighten all fasteners. Refer to your equipment's manual for specific torque specifications, if available. Ensure the weight kit is firmly attached and does not wobble.
6. **Inspect:** After installation, visually inspect all connections to confirm the weight kit is securely mounted.

6. Operating Instructions

Once the weight kit is installed, it will enhance your equipment's performance in various applications.

- **Improved Traction:** The added weight increases downward pressure on the drive wheels, improving traction, especially on slippery or uneven surfaces.
- **Enhanced Stability:** Ballast helps to counterbalance front-mounted implements, reducing the risk of tipping and improving overall stability during operation.
- **Smoother Operation:** Increased weight can lead to a smoother ride and more consistent ground contact for implements.
- **Weight Distribution:** Always consider the overall weight distribution of your equipment. If using front-mounted implements, rear ballast is crucial for balance.

7. Maintenance

Regular maintenance ensures the longevity and safe operation of your weight kit.

- **Periodic Inspection:** Regularly check all mounting hardware for tightness. Re-tighten any loose bolts or nuts to prevent the weight kit from becoming dislodged.
- **Cleanliness:** Keep the weight kit free from excessive dirt, debris, and corrosive materials. Clean with mild soap and water if necessary.
- **Damage Check:** Inspect the weight kit for any signs of damage, such as cracks, bends, or corrosion. Replace damaged components immediately.
- **Storage:** If the weight kit is removed from the equipment for storage, keep it in a dry, protected area to prevent rust and damage.

8. Troubleshooting

This section addresses common issues you might encounter with the weight kit.

- **Issue:** The weight kit feels loose or rattles during operation.
  Solution: Stop the equipment immediately. Inspect all mounting bolts and nuts. Re-tighten them to the specified torque. If the issue persists, check for damaged mounting points or hardware.
- **Issue:** Equipment still lacks traction or stability after installation.
  Solution: Verify that the weight kit is correctly installed and securely fastened. Ensure that the total weight added does not exceed the equipment's capacity. Consider if additional ballast is required or if the weight distribution needs adjustment according to your equipment's manual.
- **Issue:** Visible rust or corrosion on the weight kit.
  Solution: Clean the affected areas thoroughly. Apply a rust-inhibiting primer and paint suitable for outdoor metal components. Regular cleaning and proper storage can prevent future corrosion.

9. Specifications

Key specifications for the John Deere Original Equipment Weight Kit BG20627:

Attribute	Value
Model Number	BG20627
Manufacturer	John Deere
Product Dimensions	13 x 9 x 8.3 inches
Item Weight	7.5 pounds
ASIN	B00CSBT3QQ

10. Warranty and Support

This John Deere Original Equipment Weight Kit BG20627 is covered by John Deere's standard warranty for genuine parts. For specific warranty terms, claims, or technical support, please contact your authorized John Deere dealer or visit the official John Deere website. Always provide your model number (BG20627) and equipment details when seeking support.
For further assistance, you may visit the **John Deere Store on Amazon** or the official John Deere website.

© 2023 John Deere. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question