Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VITAPUR VWD1066BLS

Vitapur VWD1066BLS Water Dispenser User Manual

Model: VWD1066BLS | Brand: VITAPUR

1. Product Overview

The Vitapur VWD1066BLS is a bottom-load water dispenser designed to provide hot, room temperature, and cold water. It features easy-to-use push-button controls and an energy-saving kettle feature for on-demand hot water. This dispenser is compatible with standard 3- or 5-gallon water bottles.





Image 1.1: Front view of the Vitapur VWD1066BLS Water Dispenser, showcasing its black and stainless steel design.

2. Important Safety Information

Read all instructions before using this appliance to reduce the risk of fire, electric shock, or injury. Keep this manual for future reference.

- Always plug the dispenser into a grounded electrical outlet. Do not use extension cords.
- Do not operate the dispenser if the power cord or plug is damaged.
- Keep the dispenser away from direct sunlight and heat sources.
- Ensure proper ventilation around the unit. Maintain at least 10 cm (4 inches) clearance from walls.
- This dispenser heats water to high temperatures. Exercise caution to prevent burns, especially with children.
- The unit includes an anti-boil dry system to prevent damage if the hot water tank is empty.
- Do not immerse the dispenser, cord, or plug in water or other liquids.
- Unplug the dispenser before cleaning or performing any maintenance.

3. Setup and Installation

1. **Unpacking:** Carefully remove the dispenser from its packaging. Inspect for any damage.

2. **Placement:** Place the dispenser on a flat, level, and stable surface. Ensure it is in a cool, dry place away from direct sunlight and heat sources.
3. **Initial Cleaning:** Before first use, it is recommended to clean the internal water paths. Fill the water bottle compartment with clean water (or a mild bleach solution followed by thorough rinsing), dispense through all spigots until clear, and then drain completely. Run several liters of fresh water through the system to flush out any residue.
4. **Loading Water Bottle:** The VWD1066BLS is a bottom-load dispenser. Open the lower door of the dispenser. Insert the probe assembly into a 3- or 5-gallon water bottle. Slide the bottle into the compartment and close the door. The electronic sensors will monitor water levels.






Image 3.1: The bottom-load compartment of the water dispenser with the door open, illustrating how a water bottle is inserted.

5. **Power Connection:** Plug the dispenser into a grounded 120V AC outlet. Allow the unit to stand for at least 30 minutes before turning on the heating or cooling functions to allow the refrigerant to settle.

4. Operating Instructions

The Vitapur VWD1066BLS features intuitive push-button controls for dispensing water.

- **Cold Water:** Press the blue button to dispense cold water. The cold water indicator light will illuminate when the water has reached its optimal cold temperature.
- **Room Temperature Water:** Press the grey button to dispense room temperature water.
- **Hot Water (Kettle Feature):** Press the red button to activate the hot water kettle feature. This patented feature rapidly provides hot water on demand in under three minutes, using 70% less energy than traditional water dispensers that constantly reheat water. The hot water indicator light will show when the water is ready.



Image 4.1: Diagram explaining the energy-saving Kettle Feature, which heats water on demand in under 3 minutes.

To dispense water, place your cup or container under the desired spigot and press the corresponding button. Release the button to stop the flow.

5. Care and Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your water dispenser.

- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Drip Tray:** The drip tray should be emptied and cleaned regularly to prevent overflow and bacterial growth. Simply slide out the tray, empty the water, wash with mild soap and water, rinse thoroughly, and replace.
- **Internal Cleaning:** For thorough internal cleaning, unplug the unit. Prepare a cleaning solution of water and a small amount of bleach (e.g., 1 teaspoon of bleach per gallon of water). Pour the solution into the water bottle compartment or directly into the reservoir if accessible. Dispense the solution through all spigots. Let it sit for 15-20 minutes, then drain completely. Rinse the system by running several liters of fresh, clean water through all spigots until no bleach

odor remains.

- **Condenser Coils:** Periodically clean the condenser coils at the back of the unit with a brush or vacuum cleaner to ensure efficient cooling. Ensure the unit is unplugged before cleaning the coils.

6. Troubleshooting Guide

If you experience issues with your Vitapur VWD1066BLS dispenser, consult the following common problems and solutions:

Problem	Possible Cause	Solution
No water dispensing	Empty water bottle; Bottle not properly seated; Pump malfunction.	Replace water bottle; Ensure bottle is fully inserted and door is closed; Contact customer support if pump issue persists.
No cold water	Cooling system off; Compressor issue; Insufficient time for cooling.	Ensure cold water switch is on (if applicable); Allow 1-2 hours for initial cooling; Contact customer support if compressor is not working.
No hot water	Hot water switch off; Kettle feature not activated; Heating element issue.	Ensure hot water switch is on (if applicable); Press the red button to activate the kettle feature; Allow 3 minutes for heating; Contact customer support.
Unit is noisy	Normal compressor operation; Unit not level; Loose components.	Some noise during cooling/heating cycles is normal. Ensure unit is on a level surface; Check for any loose parts.
Water tastes strange	New unit odor; Contaminated water bottle; Unit needs cleaning.	Perform initial cleaning; Use fresh, clean water bottles; Perform regular internal cleaning.
Drip tray overflows	Tray is full.	Empty and clean the drip tray regularly.

7. Product Specifications

Feature	Detail
Brand	VITAPUR
Model Number	VWD1066BLS
Colour	Black
Material	Steel
Product Dimensions (D x W x H)	31.8 x 34.2 x 103.4 cm (12.5 x 13.5 x 40.7 inches)

Feature	Detail
Item Weight	20.4 kg (45 lbs)
Installation Type	Freestanding
Access Location	Bottom Load
Number of Settings	3 (Hot, Room, Cold)
Upper Temperature Rating (Hot)	212 Degrees Fahrenheit (100 Degrees Celsius)
Power Source	Corded Electric






Image 7.1: Dimensions of the Vitapur VWD1066BLS Water Dispenser.

8. Warranty and Support

For specific warranty details and customer support, please refer to the warranty card included with your product or contact the manufacturer directly. The manufacturer of this product is GHP Group ULC Home Canada -- Dropship.
When contacting support, please have your model number (VWD1066BLS) and purchase information readily available.

© 2025 Vitapur. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00CTPRS04

More documents and user manuals: **https://manuals.plus/**