



Manuals.plus /

› Orbegozo /

› Orbegozo BF 0140 Box Fan User Manual

Orbegozo BF 0140

Orbegozo BF 0140 Box Fan User Manual

Model: BF 0140

1. INTRODUCTION

Thank you for choosing the Orbegozo BF 0140 Box Fan. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before using the appliance and keep it for future reference.



Figure 1.1: Front view of the Orbegozo BF 0140 Box Fan.

The Orbegozo BF 0140 is a powerful and versatile box fan designed to provide optimal airflow and comfort in various indoor environments. It features a 40 cm blade diameter, three speed settings, a rotary diffuser for wide air distribution, and a convenient timer function.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the fan.

- Ensure the voltage indicated on the rating label matches your mains voltage.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug the fan from the outlet when not in use, when moving it, and before cleaning.
- Do not operate the fan with a damaged cord or plug, or after the fan malfunctions or has been dropped or damaged in any manner.
- Keep the fan out of reach of children and pets.
- Do not insert fingers or other objects through the grille when the fan is operating.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not use the fan near windows, curtains, or other objects that may obstruct airflow or be drawn into the fan.
- This appliance is for indoor use only.

3. PRODUCT COMPONENTS AND OVERVIEW

Familiarize yourself with the main parts of your Orbegozo Box Fan.



Figure 3.1: Detail of the control panel with speed and timer knobs.

- **Front Grille:** Protective cover for the fan blades.
- **Fan Blades:** Generate airflow.
- **Control Panel:** Houses the speed selector, timer, and rotary diffuser controls.
- **Rear Grille:** Air intake and motor protection.
- **Anti-slip Feet:** Provide stability and prevent movement during operation.



Figure 3.2: The Orbegozo BF 0140 Box Fan positioned in a living space.

4. SETUP

Follow these steps for the initial setup of your fan:

1. **Unpack:** Carefully remove the fan from its packaging. Retain the packaging for storage or future transport.
2. **Placement:** Place the fan on a firm, level surface. Ensure there is adequate space around the fan for proper airflow and to prevent obstruction of the grilles.
3. **Stability Check:** Verify that the anti-slip feet are securely positioned and the fan is stable.



Figure 4.1: Side profile of the fan, highlighting its stable base.



Figure 4.2: The fan's anti-slip feet ensure stability on various surfaces.

5. OPERATING INSTRUCTIONS

Your OrbeGozo Box Fan is designed for ease of use. Follow these steps to operate your fan:



Figure 5.1: The control panel features intuitive knobs for speed and timer, and buttons for grille movement.

5.1. Power On/Off and Speed Selection

- Plug the fan into a suitable electrical outlet.
- Turn the **Speed Selector** knob (labeled 0-1-2-3) to your desired speed setting:
 - **0**: Off
 - **1**: Low speed
 - **2**: Medium speed
 - **3**: High speed
- To turn off the fan, rotate the Speed Selector knob back to '0'.

5.2. Rotary Diffuser Function

The fan features a rotary diffuser that helps distribute air more widely across the room.

- Press the **MOVE** button on the control panel to activate the rotary diffuser. The internal grille will begin to rotate, oscillating the airflow.
- Press the **STOP** button to halt the rotation and direct airflow in a fixed direction.



Figure 5.2: The rotary diffuser ensures air distribution in both directions.

5.3. Timer Function

The integrated timer allows you to set the fan to operate for a specific duration, up to 120 minutes (2 hours).

- Rotate the **TIMER** knob to the desired operating time (e.g., 60 minutes, 120 minutes).
- The fan will automatically turn off once the set time has elapsed.
- To operate the fan continuously without the timer, set the timer knob to the 'I' position.



Figure 5.3: The fan provides consistent airflow for effective cooling.

6. MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your fan.

6.1. Cleaning

- Always unplug the fan from the power outlet before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- For dust accumulation on the grilles, use a vacuum cleaner with a brush attachment or compressed air to gently remove dust.
- Do not allow water to drip into the motor housing or other electrical components.
- Ensure the fan is completely dry before plugging it back in.

6.2. Storage

When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

7. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Fan not plugged in. Speed selector at '0'.	Check power outlet. Ensure fan is securely plugged in. Turn speed selector to 1, 2, or 3.
Weak or no airflow.	Grilles obstructed. Fan speed too low.	Clear any obstructions from grilles. Increase fan speed.
Unusual noise.	Fan not on a level surface. Loose parts or debris inside.	Place fan on a stable, flat surface. Unplug and inspect for loose parts or debris. If problem persists, contact customer support.
Rotary diffuser not working.	MOVE button not pressed. Mechanism obstructed.	Press the MOVE button. Unplug and check for any obstructions around the internal grille.

If the problem persists after trying these solutions, please contact Orbegozo customer support.

8. SPECIFICATIONS

Technical details for the Orbegozo BF 0140 Box Fan:




Figure 8.1: Key dimensions of the OrbeGozo BF 0140 Box Fan.

Feature	Detail
Model Number	BF 0140
Power	60 W
Voltage	230 V
Blade Diameter	40 cm
Dimensions (L x W x H)	18.6 x 48.9 x 52.5 cm
Weight	3.34 kg
Noise Level	44 dB
Timer	Up to 2 hours (120 minutes)
Speed Settings	3 (Low, Medium, High)
Special Features	Rotary diffuser, Anti-slip feet



60W Power



40cm Blade Diameter



2 Hour Timer



3 Speed Settings

9. WARRANTY AND SUPPORT

Orbegozo products are manufactured to high-quality standards and are guaranteed against manufacturing defects for a period specified by local consumer protection laws from the date of purchase. Please retain your proof of purchase for warranty claims.

This warranty does not cover damage caused by misuse, negligence, unauthorized repairs, or normal wear and tear.

Customer Support:

For technical assistance, warranty inquiries, or spare parts, please contact your local Orbegozo service center or visit the official Orbegozo website for contact information.

Website: www.orbegozo.com

