

[Manuals.plus](#) /

› [Furby](#) /

› Furby Boom Figure (Polka Dots) Instruction Manual

Furby A4332

Furby Boom Figure (Polka Dots) Instruction Manual

Model: A4332

[Introduction](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

The Furby Boom Figure (Polka Dots), Model A4332, is an interactive electronic pet designed to respond to user interaction. This device features personality changes based on treatment, dances to music, and communicates in its unique Furbish language. It integrates with the free Furby Boom app, allowing users to collect digital eggs, hatch virtual Furbblings, and engage in virtual play. This manual provides essential information for the setup, operation, and maintenance of your Furby Boom.



Image 1: The Furby Boom Figure in a polka dot pattern, featuring large eyes, a beak, and blue ears and feet.

2. SETUP

2.1 Battery Installation

Your Furby Boom requires **4 AA batteries** for operation. Batteries are not included with the product. Follow these steps to install them:

1. Locate the battery compartment on the underside of your Furby Boom.
2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 4 fresh AA alkaline batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Important: Always use new batteries of the same type. Do not mix old and new batteries, or different types of batteries. Remove batteries if the device will not be used for an extended period.

2.2 Initial Power-On

After installing batteries, your Furby Boom will typically activate automatically. If not, gently rock or interact with it

to wake it up.

2.3 App Download and Connection

To unlock the full interactive experience, download the free Furby Boom app on a compatible mobile device (tablet or smartphone). The app allows for virtual interactions and expands gameplay.

- Search for "Furby Boom" in your device's app store.
- Download and install the application.
- Ensure your device's volume is turned up and place it near your Furby Boom to facilitate communication between the physical toy and the app.



Image 2: A Furby Boom figure positioned next to a tablet displaying a digital egg, illustrating app interaction.

3. OPERATING YOUR FURBY BOOM

3.1 Basic Interactions

Your Furby Boom responds to various physical and auditory stimuli:

- **Petting:** Gently stroke its head or back.
- **Talking:** Speak to your Furby Boom. It will listen and respond in Furbish, and over time, may learn English words.
- **Shaking/Tilting:** Different movements can elicit various reactions.
- **Music:** Furby Boom may dance to music played nearby.

3.2 Personality Development

The personality of your Furby Boom evolves based on how you interact with it. Consistent positive or negative interactions will shape its character over time. It has more than twice as many possible responses as previous Furby models.

3.3 App Integration Features

The Furby Boom app enhances the play experience:

- **Hatching Furlblings:** Collect and hatch virtual Furlblings to populate a digital city within the app. There is a possibility of finding a golden Furlblings egg.
- **Virtual Care:** Use the app to provide virtual food, check-ups, and showers for your Furby Boom creature.
- **Games:** Play various games with your Furby Boom and its virtual Furlblings through the app.



Image 3: A user engaging with a Furby Boom figure while simultaneously interacting with the Furby Boom app on a tablet.

3.4 Naming and Social Interaction

Your Furby Boom can remember the name you give it. It can also recognize and remember the names of other Furby Boom figures it encounters, fostering social interactions between multiple units.



Image 4: Several Furby Boom figures, including the polka dot model, positioned near children using tablets, demonstrating multi-device and multi-Furby interaction.

4. MAINTENANCE

4.1 Cleaning

To clean your Furby Boom, use a soft, dry cloth. Do not immerse the toy in water or use harsh cleaning agents, as this can damage the electronic components and fabric.

4.2 Battery Replacement

When your Furby Boom's responses become sluggish or it stops functioning, it is likely time to replace the batteries. Refer to Section 2.1 for battery installation instructions.

4.3 Storage

Store your Furby Boom in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Furby Boom is not responding.	Low or dead batteries; device is asleep.	Replace batteries (see Section 2.1). Gently rock or interact with Furby to wake it up.

Problem	Possible Cause	Solution
App connection issues.	Device volume too low; app not updated; interference.	Ensure mobile device volume is high. Update the Furby Boom app to the latest version. Move away from other electronic devices that may cause interference.
Unexpected behavior or repetitive actions.	Temporary software glitch; personality shift.	Remove and reinsert batteries to perform a soft reset. Continue interacting with Furby to guide its personality development.

6. SPECIFICATIONS

Feature	Detail
Model Number	A4332
Product Dimensions	12.7 x 20.3 x 22.9 cm
Item Weight	454 g
Recommended Age	6 - 12 years
Batteries Required	4 AA batteries (not included)
Material	Plastic
Additional Features	Interactive Audio
Manufacturer	Furby

7. WARRANTY & SUPPORT

7.1 Warranty Information

Specific warranty details for the Furby Boom Figure (Polka Dots) are typically provided with the product packaging at the time of purchase. Please refer to the documentation included in your product box for comprehensive warranty terms and conditions. For further inquiries, contact the manufacturer directly.

7.2 Customer Support

For additional assistance, technical support, or product-related questions, please contact the manufacturer:

- **Manufacturer:** Furby
- **Contact Address:** PROVIDENCE, RI, 02903 US

You may also visit the official Furby website for FAQs, updated information, and further support resources.