

[Manuals.plus](#) /

> [Dell](#) /

> Dell Optiplex 755 SFF User Manual

Dell Optiplex 755

Dell Optiplex 755 SFF User Manual

Model: Optiplex 755

PRODUCT OVERVIEW

The Dell Optiplex 755 SFF is a small form factor desktop computer designed for robust performance in corporate and home environments. It is built with high-quality components to ensure reliability and longevity. This manual provides essential information for setup, operation, maintenance, and troubleshooting of your Dell Optiplex 755 SFF.





Image: Front-left view of the Dell Optiplex 755 SFF desktop computer, showcasing its compact design and front panel ports.

SETUP GUIDE

1. Unpacking and Placement

Carefully remove the computer from its packaging. Ensure all included accessories, such as the power cable, are present. Place the computer on a stable, flat surface with adequate ventilation. Avoid placing it in enclosed spaces or near heat sources.



Image: Rear view of the Dell Optiplex 755 SFF, highlighting the various input/output ports for connecting peripherals.

2. Connecting Peripherals

- **Power Cable:** Connect the power cable to the power supply unit at the rear of the computer and then to a grounded electrical outlet.
- **Monitor:** Connect your monitor to the appropriate video output port (VGA or DVI) on the back of the computer.
- **Keyboard and Mouse:** Connect your USB keyboard and mouse to any available USB ports.
- **Network:** For wired internet access, connect an Ethernet cable from your router or modem to the Ethernet port on the back of the computer.
- **Audio:** Connect speakers or headphones to the audio output jack (green) on the front or back panel.

3. Initial Power On

Press the power button located on the front panel of the computer. The system will boot up. Follow the on-screen instructions for the initial Windows setup, including language, region, and user account creation.

OPERATING INSTRUCTIONS

Using the Operating System

Your Dell Optiplex 755 SFF comes pre-installed with either Windows 7 or Windows 10 Professional (32-bit). Familiarize yourself with the operating system's interface, including the Start Menu, desktop icons, and taskbar.

Software Applications

The computer includes a trial version of Microsoft Office 365 and a standard open-source Office Suite. You can access these applications from the Start Menu. For additional software, use the Windows Store or install from trusted sources.

Optical Drive Usage

The integrated DVD player allows you to read and write CDs and DVDs. To open the tray, press the eject button on the drive itself or right-click the drive icon in 'This PC' and select 'Eject'.



Image: Front view of the Dell Optiplex 755 SFF, showing the optical drive bay and front panel connections.

MAINTENANCE

System Updates

Regularly check for and install operating system updates to ensure security and optimal performance. Access Windows Update through the Settings menu.

Cleaning

Keep the computer clean by regularly dusting the exterior with a soft, dry cloth. Ensure ventilation grilles are free from

dust buildup to prevent overheating. Do not use liquid cleaners directly on the components.

Data Backup

It is highly recommended to regularly back up important data to an external drive or cloud storage to prevent data loss.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Computer does not power on.	Power cable disconnected, faulty power supply.	Check power cable connections. Ensure outlet is functional.
No display on monitor.	Monitor cable loose, monitor off, incorrect input.	Verify monitor cable connection. Turn on monitor. Select correct input source on monitor.
DVD drive not opening/working.	Drive malfunction, software issue.	Restart the computer. Check device manager for driver issues. If problem persists, contact support.
Slow performance.	Too many programs running, low disk space, malware.	Close unnecessary programs. Free up disk space. Run antivirus scan.

SPECIFICATIONS

Processor: 2.66 GHz Pentium (Intel Core 2 Duo)

RAM: 2 GB DDR2

Hard Drive: 160 GB HDD (Serial ATA)

Graphics Coprocessor: Intel GMA 3100

Optical Drive: DVD Player

Operating System: Windows 10 Pro (or Windows 7) 32-bit

Dimensions (LxWxH): 16 x 8 x 12 inches

Weight: 17.1 pounds

Color: Black

WARRANTY AND SUPPORT

This refurbished Dell Optiplex 755 SFF typically comes with a 90-day warranty from the seller. For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact the seller directly. Refer to your purchase documentation for specific contact information.

Additional support resources may be available through Dell's official website for general product information, drivers, and manuals for the Optiplex 755 series.

For protection plans, options such as a 3-Year Protection Plan or Complete Protect are available for purchase separately. Please refer to the product listing for details on these extended service options.