

[Manuals.plus](#) /

› [Globo](#) /

› Globo 0306 Ceiling Fan Instruction Manual

## Globo 306

# Globo 0306 Ceiling Fan Instruction Manual

**MODEL: 306**

**Brand: Globo**

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Globo 0306 Ceiling Fan. This ceiling fan features a matte nickel finish, five MDF wengé blades, and an integrated light with remote control functionality. It is designed to provide both air circulation and illumination for your living spaces.

Please read this manual thoroughly before installation and use to ensure proper function and to prevent injury or damage. Keep this manual for future reference.

### Important Safety Information

- Always disconnect power at the main circuit breaker before installing, cleaning, or performing any maintenance on the fan.
- Installation must be performed by a qualified electrician or a person with appropriate electrical knowledge.
- Ensure the mounting structure is strong enough to support the fan's weight (approximately 7.42 kg) and can withstand the fan's movement.
- Do not insert objects into the path of the rotating blades.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## 2. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, contact your retailer or Globo customer support.

- Ceiling Fan Motor Housing (Matte Nickel)

- Fan Blades (MDF Wengé, 5 pieces)
- Light Kit with White Glass Shade
- Remote Control Unit
- Mounting Bracket and Hardware
- 1 x R7s 80 Watt, 230 V Halogen Lamp
- Instruction Manual



Figure 2.1: Globo 0306 Ceiling Fan main unit.

### 3. SETUP AND INSTALLATION

This section outlines the general steps for installing your ceiling fan. Specific wiring diagrams and detailed instructions are typically provided in a separate installation guide included with the product. Always follow local electrical codes.

#### Installation Steps:

1. **Prepare the Installation Site:** Ensure the power is off at the circuit breaker. Select a suitable location on the ceiling that can support the fan's weight and allow for proper blade clearance.
2. **Install the Mounting Bracket:** Securely attach the mounting bracket to a ceiling joist or a fan-rated electrical box.
3. **Perform Electrical Connections:** Connect the fan's wiring to the household electrical supply according to the provided wiring diagram. Ensure all connections are secure and insulated.
4. **Mount the Fan Motor Housing:** Carefully lift the fan motor housing and attach it to the mounting bracket.
5. **Attach the Fan Blades:** Securely fasten each of the five MDF wengé blades to the motor housing using the provided screws.
6. **Install the Light Kit:** Connect the light kit's wiring and attach the light fixture to the bottom of the fan motor housing. Insert the R7s 80 Watt bulb and secure the white glass shade.
7. **Test Operation:** Restore power at the circuit breaker and test the fan and light functions using the remote control.




Figure 3.1: Example of the ceiling fan installed in a room environment.

## 4. OPERATION

Your Globo 0306 Ceiling Fan is operated using the included remote control. Ensure batteries are correctly installed in the remote control unit.

### Remote Control Functions:

- **ON/OFF Button:** Turns the fan on or off.
- **LIGHT ON/OFF Button:** Controls the integrated light.
- **Speed Control Buttons (HI, MED, LOW):** Adjusts the fan speed to High, Medium, or Low settings.
- **Forward/Reverse Rotation Switch:** Located on the fan motor housing (or sometimes on the remote, depending on model variation). This switch changes the direction of blade rotation.

- *Summer Mode (Counter-clockwise)*: Creates a downdraft, producing a cooling breeze.
- *Winter Mode (Clockwise)*: Creates an updraft, circulating warm air trapped near the ceiling.



Figure 4.1: Remote control and its functions for the ceiling fan.

## 5. MAINTENANCE

Regular maintenance will help prolong the life and performance of your ceiling fan.

### Cleaning:

- Always turn off the power to the fan before cleaning.
- Wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.

- Clean the glass shade periodically with a mild glass cleaner.

**Light Bulb Replacement:**

- Ensure the power is off and the bulb has cooled down before attempting to replace it.
- Carefully remove the glass shade.
- Replace the R7s 80 Watt, 230 V halogen lamp with a new one of the same type and wattage.
- Reattach the glass shade securely.

**Blade Care:**

- Periodically check that all blade screws are tight. Loose screws can cause wobbling and noise.
- If the fan wobbles, ensure all blades are balanced. Balancing kits are often available from fan retailers.

**6. TROUBLESHOOTING**

If you encounter issues with your ceiling fan, refer to the following common problems and solutions:

| Problem                    | Possible Cause                                                                                 | Solution                                                                                                                               |
|----------------------------|------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Fan does not start         | No power supply<br>Remote control battery low/dead<br>Incorrect wiring                         | Check circuit breaker and wall switch<br>Replace remote control batteries<br>Verify wiring connections (consult electrician if unsure) |
| Fan wobbles excessively    | Loose blade screws<br>Unbalanced blades<br>Loose mounting bracket                              | Tighten all blade screws<br>Use a blade balancing kit<br>Ensure mounting bracket is securely fastened to the ceiling                   |
| Light does not work        | Bulb burnt out<br>Loose wiring connection<br>Light switch on remote off                        | Replace bulb<br>Check light kit wiring (ensure power is off)<br>Press the LIGHT ON/OFF button on the remote                            |
| Remote control not working | Dead batteries<br>Obstruction between remote and receiver<br>Remote not paired (if applicable) | Replace batteries<br>Ensure clear line of sight<br>Refer to specific pairing instructions (if provided with remote)                    |

If the problem persists after attempting these solutions, please contact Globo customer support or a qualified service technician.

**7. SPECIFICATIONS**

Technical specifications for the Globo 0306 Ceiling Fan:

- **Model Number:** 306
- **Dimensions (Diameter x Height):** 132 cm x 37.2 cm (52 inches x 14.6 inches)
- **Weight:** 7.42 kg (16.36 lbs)
- **Material:** Metal (Matte Nickel finish), MDF (Wengé blades), White Glass
- **Light Source:** 1 x R7s 80 Watt, 230 V Halogen Lamp (included)
- **Light Output:** 1300 Lumens
- **Color Temperature:** 2900 Kelvin
- **Energy Efficiency Class:** C
- **Power Supply:** 230 V
- **Fan Speeds:** 3 (Low, Medium, High)
- **Rotation:** Reversible (Forward/Reverse for summer/winter modes)
- **Included Components:** Remote control



Figure 7.1: Dimensional overview of the ceiling fan.

## 8. WARRANTY INFORMATION

Globo products are manufactured to high-quality standards. For detailed information regarding the warranty period, terms, and conditions applicable to your Globo 0306 Ceiling Fan, please refer to the warranty card included with your purchase or visit the official Globo website. Keep your proof of purchase for warranty claims.

## 9. CUSTOMER SUPPORT

For technical assistance, spare parts, or further inquiries regarding your Globo 0306 Ceiling Fan, please contact Globo customer support. Contact details, including phone numbers and email addresses, can typically be found on the official Globo website ([www.globo-lighting.com](http://www.globo-lighting.com)) or your purchase documentation.

When contacting support, please have your model number (306) and purchase date readily available.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B00D7FOZVK>

More documents and user manuals: <https://manuals.plus/>