

[Manuals.plus](#) /

› [Globo](#) /

› Globo 56206-1T LED Desk Lamp Instruction Manual

Globo 56206-1T

Globo 56206-1T LED Desk Lamp Instruction Manual

Model: 56206-1T

INTRODUCTION

Thank you for choosing the Globo 56206-1T LED Desk Lamp. This manual provides essential information for the safe and efficient use of your new lamp. Please read these instructions carefully before installation and operation, and retain them for future reference.

The Globo 56206-1T is a practical and modern chrome-plated desk lamp featuring a flexible arm for adjustable light direction. It provides pleasant and effective warm white LED lighting, easily controlled by an on/off switch.

IMPORTANT SAFETY INSTRUCTIONS

- **Read all instructions:** Before assembly and use, carefully read and understand all instructions.
- **Electrical Safety:** Ensure the power supply voltage matches the lamp's requirements (220-240V, 50-60Hz). Do not use if the cable or plug is damaged.
- **Indoor Use Only:** This lamp is designed for indoor use in dry locations. Do not expose to water or high humidity.
- **Stable Surface:** Always place the lamp on a stable, flat surface to prevent tipping.
- **Cleaning:** Disconnect from power before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **No User Serviceable Parts:** The LED light source is integrated and not user-replaceable. Do not attempt to disassemble or repair the lamp. Contact qualified personnel for service.
- **Heat:** The LED light source may become warm during operation. Avoid touching the light source directly when in use.

PACKAGE CONTENTS

Please check the package for the following items:

- Globo 56206-1T LED Desk Lamp (1 unit)
- Integrated LED light source (1 unit)
- Instruction Manual (this document)



Image 1: Full view of the Globo 56206-1T LED Desk Lamp. Shows the chrome finish, flexible arm, and round base.

SETUP AND INSTALLATION

The Globo 56206-1T LED Desk Lamp comes largely pre-assembled. Follow these steps for quick setup:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Positioning:** Place the lamp on a stable, flat, and dry surface, such as a desk or table. Ensure there is enough space for the flexible arm to be adjusted.
3. **Connect Power:** Insert the power plug into a suitable electrical outlet (220-240V, 50-60Hz).



Image 2: Close-up view of the lamp head and flexible arm, highlighting the satin acrylic diffuser.

OPERATING INSTRUCTIONS

- Power On/Off:** Locate the on/off switch on the lamp's cable or base (depending on specific model variation). Press the switch to turn the lamp on or off.
- Adjusting Light Direction:** The lamp features a flexible arm. Gently bend and position the arm to direct the light as desired. Avoid excessive force or bending the arm beyond its natural range of motion.

The integrated LED provides a warm white light at 3000 Kelvin with a luminous flux of 200 lumens, ideal for reading or task lighting.

CARE AND MAINTENANCE

- Cleaning:** Always unplug the lamp from the power outlet before cleaning. Use a soft, dry, lint-free cloth to wipe the chrome finish and acrylic diffuser. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the finish or electrical components.
- Storage:** If storing the lamp, ensure it is clean and dry. Store it in its original packaging in a cool, dry place to protect it from dust and damage.
- LED Replacement:** The LED light source is integrated and designed for a long lifespan (approx. 20,000 hours). It is not user-replaceable. If the LED fails, the entire lamp should be replaced or serviced by a qualified technician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in.	Ensure the power plug is fully inserted into a working outlet.
	Power outlet is not active.	Test the outlet with another device.
	On/off switch is off.	Press the on/off switch to the 'on' position.
	Faulty LED or internal wiring.	If the issue persists, contact customer support. Do not attempt to repair.
Light flickers or is dim.	Unstable power supply.	Try plugging the lamp into a different outlet.
	LED nearing end of life.	If the issue persists, contact customer support.

PRODUCT SPECIFICATIONS

Model Number	56206-1T
Brand	Globo
Type	Desk Lamp
Material	Metal, Acrylic
Color	Chrome
Dimensions (W x H)	24 x 43 cm (approx. 25.5 x 10.01 x 43 cm including base)

Weight	500 g
Cable Length	150 cm
Light Source	Integrated LED
Power Consumption	3 Watt
Luminous Flux	200 Lumens
Color Temperature	3000 Kelvin (Warm White)
Rated Lifetime	Approx. 20,000 hours
Power Supply	220-240V, 50-60Hz
Energy Efficiency Class	A

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official Globo website. Keep your proof of purchase for warranty claims.

Manufacturer: Globo

Model Number: 56206-1T

Date of First Availability: January 15, 2020

© 2024 Globo. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00D7JI25G>

More documents and user manuals: <https://manuals.plus/>