



Manuals.plus /

› Hasbro /

› Hasbro Gaming Trouble Board Game Instruction Manual

Hasbro A5064

Hasbro Gaming Trouble Board Game Instruction Manual

Model: **A5064** | Brand: **Hasbro**

INTRODUCTION

The Trouble board game offers racing, chasing, and peg-popping fun for 2 to 4 players, aged 5 and up. The game features the iconic Pop-O-Matic bubble for rolling the die, adding an element of excitement to each turn. Players aim to move all their game pieces around the board and into their Finish zone while strategically bumping opponents' pegs back to the start. This edition includes options for classic gameplay or a more challenging version with Power Up spaces, making it a versatile choice for family game nights.

SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.

WHAT'S IN THE BOX

- Gameboard with integrated Pop-O-Matic die roller
- 16 Plastic Pegs (4 colors, 4 pegs per color)
- Instructions

SETUP

1. Place the gameboard on a flat, stable surface.
2. Each player chooses a color and takes all 4 pegs of that color.
3. Place your 4 pegs in the matching colored **HOME** area on the gameboard.
4. Determine the first player. The youngest player typically goes first, or players can roll the die to see who gets the highest number.



Image: The Trouble game board with all colored pegs placed in their respective home areas, ready for play.

HOW TO PLAY (OPERATING INSTRUCTIONS)

Objective

Be the first player to move all 4 of your pegs from your HOME area, around the game path, and into your matching colored **FINISH** zone.

Gameplay

1. **Starting a Peg:** To move a peg out of your HOME area and onto your **START** space, you must roll a **6**. If you roll a 6, place one of your pegs on your START space and take another turn.
2. **Moving Pegs:** On your turn, press the Pop-O-Matic bubble to roll the die. Move any one of your pegs forward along the path the number of spaces indicated on the die. Movement is always clockwise.
3. **Landing on an Opponent's Peg:** If you land on a space occupied by an opponent's peg, that opponent's peg is "bumped" and must return to their HOME area.
4. **Power Up Spaces (Optional Rule):** If playing with Power Up spaces, landing on these spaces may grant special abilities or require specific actions as detailed in the game's included instructions.
5. **Entering the Finish Zone:** Once your peg has completed a full circuit around the board, it can enter your matching colored FINISH zone. You must roll the exact number to move a peg into the FINISH zone.
6. **Winning the Game:** The first player to successfully move all 4 of their pegs into their FINISH zone wins the game!



Image: Players engaging with the Pop-O-Matic die roller during a game of Trouble.

MAINTENANCE

To ensure the longevity of your Trouble board game, follow these simple maintenance tips:

- **Cleaning:** Wipe the gameboard and plastic pegs with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, but avoid excessive moisture.
- **Storage:** Store all game components in the original box when not in use to prevent loss or damage. Keep the game in a cool, dry place away from direct sunlight or extreme temperatures.
- **Handling:** Handle the Pop-O-Matic bubble gently to ensure its continued functionality. Avoid applying excessive force.

TROUBLESHOOTING

Die Not Popping Correctly

If the die inside the Pop-O-Matic bubble does not pop or roll properly, ensure that the game unit is on a flat surface and that the bubble is pressed firmly and quickly. Avoid pressing slowly or with insufficient force. If the issue persists, check for any debris or foreign objects inside the bubble (though it is sealed).

Lost Game Pieces

The game includes 16 pegs. If pegs are lost, replacement pegs may be available from Hasbro customer service or generic game pieces can be used as substitutes. Always store pegs securely in the provided bag or box.

SPECIFICATIONS

Product Dimensions	1.61 x 10.51 x 10.51 inches
Item Weight	11.2 ounces
Item Model Number	A5064
Manufacturer Recommended Age	5 - 15 years
Language	English
Manufacturer	Hasbro

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Hasbro Customer Service directly. Refer to the contact information provided on the product packaging or visit the official Hasbro website for assistance.

Official Hasbro Website: www.hasbro.com