

[Manuals.plus](#) /

› [Bose](#) /

› Bose SoundLink Mini Bluetooth Speaker User Manual

Bose SLink Mini

Bose SoundLink Mini Bluetooth Speaker User Manual

Model: SLink Mini | Brand: Bose

INTRODUCTION

The Bose SoundLink Mini Bluetooth Speaker delivers advanced audio performance in a compact design. This portable speaker is engineered to provide a full-range listening experience with deep bass, making it ideal for various settings. It features easy Bluetooth connectivity and comes with essential accessories for charging and use.

Key features include:

- Advanced audio performance for a full-range listening experience.
- Compact and portable design for easy transport.
- Seamless Bluetooth connectivity for wireless audio streaming.
- Includes a charge cradle and wall adapter for convenient power.

WHAT'S IN THE BOX

Upon unboxing your Bose SoundLink Mini, you should find the following items:

- Bose SoundLink Mini Bluetooth Speaker
- Charge Cradle
- Wall Adapter



Figure 1: Contents of the Bose SoundLink Mini package, including the speaker, charge cradle, and wall adapter.

SETUP

1. Charging the Speaker

Before initial use, fully charge your SoundLink Mini speaker. The battery provides up to 12 hours of playback on a full charge, with a charging time of approximately 4 hours.

1. Connect the wall adapter to the charge cradle.
2. Place the SoundLink Mini speaker onto the charge cradle. Ensure the speaker is properly seated for charging to begin.
3. Alternatively, you can plug the wall adapter directly into the speaker's power port located on the side.



Figure 2: The Bose SoundLink Mini speaker, ready for charging or use.

2. Bluetooth Pairing

Pair your speaker with a Bluetooth-enabled device (e.g., smartphone, tablet) to stream audio wirelessly.

1. Press the **Power** button on the speaker to turn it on.
2. Press and hold the **Bluetooth** button until the Bluetooth indicator light blinks blue, indicating it's in pairing mode.
3. On your device, enable Bluetooth and select "Bose SoundLink Mini" from the list of available devices.
4. Once connected, the Bluetooth indicator light will turn solid white.



Figure 3: Pairing the SoundLink Mini with a smartphone for wireless audio.

OPERATING THE SPEAKER

The SoundLink Mini features intuitive controls located on the top panel:

- **Power Button:** Turns the speaker on or off.
- **Volume Down (-):** Decreases the audio volume.
- **Volume Up (+):** Increases the audio volume.
- **Mute Button:** Mutes or unmutes the audio.
- **Bluetooth Button:** Initiates Bluetooth pairing mode or connects to the last paired device.
- **AUX Button:** Switches to the auxiliary input mode.

Auxiliary Input

For devices without Bluetooth, use the 3.5mm auxiliary input port. Connect one end of a 3.5mm audio cable (not included) to your device's headphone jack and the other end to the AUX port on the speaker. Press the **AUX** button to switch to auxiliary mode.

MAINTENANCE

To ensure the longevity and optimal performance of your Bose SoundLink Mini speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Avoid using abrasive cleaners, solvents, or sprays.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Charge it regularly, even if not in constant use.
- **Protection:** While durable, the speaker is not waterproof. Protect it from moisture and extreme temperatures.

TROUBLESHOOTING

Problem	Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the speaker to the charge cradle or directly to the wall adapter.
Cannot pair via Bluetooth.	Make sure the speaker is in pairing mode (blinking blue light). Check your device's Bluetooth settings and ensure it's discoverable. Try forgetting the device on your phone and re-pairing.
No sound or low volume.	Check the volume levels on both the speaker and your connected device. Ensure the correct input source (Bluetooth or AUX) is selected.
Sound distortion.	Reduce the volume on both the speaker and your device. Ensure the speaker is not too far from the Bluetooth source (max 30 feet/9 meters).

SPECIFICATIONS

Feature	Detail
Model Name	FBA_SLink Mini
Speaker Type	Outdoor (Portable)
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	9 Meters (30 Feet)
Battery Life	12 Hours
Charging Time	4 Hours
Item Weight	1.48 Pounds
Product Dimensions	2.3"D x 7.1"W x 2.1"H
Audio Output Mode	Stereo
Power Source	Battery Powered
Included Components	Charge cradle, wall adapter



Figure 4: Physical dimensions of the SoundLink Mini speaker.

WARRANTY AND SUPPORT

Warranty Information

The Bose SoundLink Mini Bluetooth Speaker comes with a Limited Warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including coverage details and duration.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please visit the official Bose support website or contact their customer service. Keep your proof of purchase handy for any inquiries.

Important Safety Information: Do Not Recycle. Product is Fragile.

© 2025 Bose Corporation. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I obtain an original replacement battery for the Bose SoundLink Mini (1st Generation)?

To obtain an original replacement battery for your Bose SoundLink Mini (1st Generation), you should follow these steps:Contact Bose Support: Since the 1st Generation SoundLink Mini is an older model, the most reliable way...

[Read full answer](#)