

## Franke 115.0028.208

# Franke Old England Kitchen Faucet Instruction Manual

MODEL: 115.0028.208

### 1. Important Safety Information

Please read this manual carefully before installation and use. Retain this manual for future reference.

- Ensure all local plumbing and building codes are followed during installation.
- Turn off the main water supply before beginning any installation or maintenance.
- Use appropriate tools and wear safety glasses to prevent injury.
- If you are unsure about any part of the installation, consult a qualified plumber.

### 2. Package Contents

Verify that all components are present before starting installation:

- Franke Old England Kitchen Faucet (Model 115.0028.208)
- 40 mm Ceramic Cartridge (pre-installed)
- Connection Hoses (400 mm long)
- Mounting Hardware

### 3. Specifications

Feature	Specification
Manufacturer	Franke
Model Number	115.0028.208

Product Dimensions	29 x 22 x 3.5 cm
Item Weight	2.38 kg
Color	Brown (Ramato/Copper Finish)
Finish	Copper
Material	Copper (Faucet Body), Ceramic (Handle Material)
Installation Method	Single-hole / Deck Mounting
Number of Handles	1
Spout Height	290 mm (Total Height) / 209 mm (Height to Outlet)
Spout Type	Fixed, Swivel (up to 360 degrees)
Mounting Hole Diameter	35 mm
Connection Hoses Length	400 mm
Noise Class	I

#### 4. Setup and Installation

This section provides general guidelines for installing your Franke Old England kitchen faucet. Specific installation steps may vary based on your sink and countertop configuration.

- 1. Prepare the Mounting Area:** Ensure the mounting surface is clean and dry. The required mounting hole diameter is 35 mm.
- 2. Install the Faucet:** Insert the faucet base into the mounting hole. From underneath the sink, secure the faucet using the provided mounting hardware (washer and nut). Tighten securely but do not overtighten.
- 3. Connect Water Supply:** Attach the 400 mm long flexible connection hoses to your hot and cold water supply lines. Ensure all connections are hand-tightened, then use a wrench for a final quarter-turn. Do not overtighten.
- 4. Check for Leaks:** Slowly turn on the main water supply. Check all connections for leaks. If leaks are present, gently tighten the connections until they stop.
- 5. Flush the System:** Once installed, remove the aerator from the spout and turn on both hot and cold water for a few minutes to flush out any debris from the water lines. Reinstall the aerator.



An image showing the Franke Old England kitchen faucet. It features a classic design with a curved spout and a single lever handle with a white ceramic accent, all in a rich copper finish.

## 5. Operating Instructions

The Franke Old England kitchen faucet features a single lever for controlling water flow and temperature, and a fixed spout that swivels.

- **Water Flow:** Lift the lever handle to increase water flow. Push it down to decrease or stop the flow.
- **Water Temperature:** Move the lever handle to the left for hot water and to the right for cold water. Adjust the position between left and right to achieve the desired temperature.
- **Spout Rotation:** The faucet spout can be rotated up to 360 degrees to direct water flow as needed within your sink area.

## 6. Maintenance

Regular cleaning and maintenance will help preserve the appearance and functionality of your faucet.

- **Cleaning the Finish:** Clean the copper finish regularly with a soft cloth and mild soap and water. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- **Aerator Maintenance:** If water flow becomes restricted, the aerator may be clogged. Unscrew the aerator from the end of the spout, clean any debris, and rinse thoroughly before reattaching.
- **Cartridge Care:** The 40 mm ceramic cartridge is designed for durability. If you experience persistent drips or leaks from the handle, the cartridge may need to be replaced. Consult a professional for cartridge replacement.

## 7. Troubleshooting

Refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valve; kinked supply line.	Clean aerator; ensure shut-off valves are fully open; check supply lines for kinks.
Faucet Leaks from Spout	Worn cartridge; debris in cartridge.	Replace or clean the ceramic cartridge.
Leaks from Base of Faucet	Loose mounting nut; improper seal.	Tighten mounting nut; ensure proper sealing during installation.
Difficulty Adjusting Temperature	Cartridge issue; unbalanced water pressure.	Inspect or replace cartridge; check water pressure to hot and cold lines.

## 8. Warranty and Support


Franke products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Franke website.






For technical assistance, spare parts, or further inquiries, please contact Franke customer support through their official channels.



© 2025 Franke. All rights reserved. Model 115.0028.208.

### Related Documents - 115.0028.208

	<p><a href="#">Franke Sinks: Global Contacts and Installation Guide</a></p> <p>Find Franke kitchen sink contact information worldwide and access installation and maintenance guidance, including product details for the Franke Maris MRX 110-40.</p>
---	--

 <p>The cover of the Franke Sinks Installation and User Manual features a technical line drawing of a kitchen sink with its drain assembly. The text is in multiple languages, including English, German, and Arabic. The Franke logo is prominently displayed at the bottom right.</p>	<p><a href="#">Franke Sinks Installation and User Manual</a></p> <p>Comprehensive installation and user manual for Franke sinks, covering various models and installation types. Includes safety guidelines, care instructions, and global contact information.</p>
 <p>The cover of the Franke Orbit Kitchen Faucet Installation and Service Manual shows a close-up of the Orbit faucet's handle and spout. The text is in multiple languages, including English, German, and Arabic. The Franke logo is at the bottom right.</p>	<p><a href="#">Franke Orbit Kitchen Faucet Installation and Service Manual</a></p> <p>This manual provides detailed installation and service instructions for the Franke Orbit kitchen faucet, covering various models and multilingual support.</p>
 <p>The cover of the Franke Pola Kitchen Faucet: Installation and Service Manual displays the Pola faucet, which has a high-arc, pull-down spout. The text is in multiple languages, including English, German, and Arabic. The Franke logo is at the bottom right.</p>	<p><a href="#">Franke Pola Kitchen Faucet: Installation and Service Manual</a></p> <p>Comprehensive installation and service manual for the Franke Pola series of kitchen faucets, providing detailed instructions and technical specifications for various models.</p>
 <p>The cover of the Franke EOS NEO Kitchen Faucet Installation and Service Manual shows the EOS NEO faucet, a modern design with a curved spout. The text is in multiple languages, including English, German, and Arabic. The Franke logo is at the bottom right.</p>	<p><a href="#">Franke EOS NEO Kitchen Faucet Installation and Service Manual</a></p> <p>Comprehensive guide for installing and servicing the Franke EOS NEO kitchen faucet, including model details, step-by-step instructions, technical specifications, and maintenance tips.</p>
 <p>The cover of the Franke EOS NEO Kitchen Faucet Installation and Service Manual shows the EOS NEO faucet, a modern design with a curved spout. The text is in multiple languages, including English, German, and Arabic. The Franke logo is at the bottom right.</p>	<p><a href="#">Franke EOS NEO Kitchen Faucet Installation and Service Manual</a></p> <p>Comprehensive installation and service manual for the Franke EOS NEO kitchen faucet, detailing installation steps, periodic checks, and operating data for Swivel Side and Pull Down Spray models.</p>