

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Bahco](#) /

› [Bahco 36 Nail Puller 8-Inch Instruction Manual](#)

Bahco BH36

Bahco 36 Nail Puller 8-Inch Instruction Manual

Model: BH36

INTRODUCTION

The Bahco 36 Nail Puller is a specialized hand tool designed for efficient and safe removal of nails from various materials, such as wood crates and decking. Constructed from high-performance alloy steel, it features a comfortable, non-slip thermoplastic grip handle for enhanced user control. The tool is anti-corrosion treated and incorporates a patented internal spring mechanism that keeps the jaws open, facilitating quick operation. Its wide striking area allows for use with a hammer, providing additional leverage when needed.



Figure 1: Full view of the Bahco 36 Nail Puller, showcasing its design and grip.

SAFETY INFORMATION

Always prioritize safety when using hand tools. Failure to follow these guidelines may result in injury or damage to the tool or workpiece.

- **Wear appropriate personal protective equipment (PPE)**, including safety glasses or goggles, to protect against flying debris.
- **Inspect the tool before each use** for any signs of damage, wear, or loose components. Do not use a damaged tool.
- **Ensure a stable and secure grip** on the handle during operation.
- **Keep hands and fingers clear** of the jaws and striking area during use.
- **Use the correct tool for the job.** This nail puller is designed for nail removal; do not use it for prying, cutting, or other unintended purposes.
- **Store the tool safely** in a dry place, away from children and unauthorized users.

PRODUCT OVERVIEW

The Bahco 36 Nail Puller consists of several key components designed for effective nail extraction.

- **Jaws:** The primary gripping mechanism for securing the nail head.
- **Handle:** Ergonomically designed with a thermoplastic grip for comfort and control.
- **Striking Area:** A reinforced flat surface at the pivot point, designed to be struck with a hammer for added force.
- **Internal Spring:** A patented mechanism that keeps the jaws open, ready for use.



Figure 2: Close-up view of the nail puller's jaws, showing the gripping mechanism.



Figure 3: Close-up view of the striking area, designed for use with a hammer.

SETUP

The Bahco 36 Nail Puller is designed for immediate use and requires no assembly. Before first use, and periodically thereafter, ensure the tool is clean and free from debris.

1. **Unpack the tool:** Carefully remove the nail puller from its packaging.
2. **Inspect for damage:** Check the jaws, handle, and pivot point for any manufacturing defects or shipping damage. If any damage is found, do not use the tool and contact customer support.
3. **Familiarize yourself with the tool:** Hold the tool and understand its weight and balance. Practice opening and closing the jaws to feel the spring mechanism.

OPERATING INSTRUCTIONS

Follow these steps for effective and safe nail removal:

1. **Position the Jaws:** Place the open jaws of the nail puller around the head of the nail you wish to remove. Ensure the jaws are fully seated under the nail head.
2. **Grip the Nail:** Squeeze the handles firmly to close the jaws, securing a tight grip on the nail head. The patented internal spring will assist in keeping the jaws open for initial positioning.
3. **Apply Leverage:** With a firm grip, rock the tool back and forth or side to side to begin loosening the nail. The design of the tool provides leverage to pull the nail out.
4. **Use a Hammer (Optional):** For stubborn or deeply embedded nails, position the striking area of the nail puller against the surface and gently tap it with a hammer. This can help drive the jaws further under the nail head or provide initial movement. *Do not strike the handle or jaws directly.*

5. **Extract the Nail:** Once the nail is loose, continue to apply leverage by rocking the tool or pulling the handle upwards until the nail is fully extracted from the material.
6. **Dispose of Nails:** Safely dispose of removed nails to prevent injury.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Bahco 36 Nail Puller.

- **Cleaning:** After each use, wipe down the tool with a clean, dry cloth to remove dirt, dust, and debris. For stubborn grime, a mild detergent and water can be used, followed by thorough drying.
- **Lubrication:** Periodically apply a small amount of light machine oil to the pivot point to ensure smooth operation of the jaws and spring mechanism.
- **Storage:** Store the nail puller in a dry environment to prevent rust and corrosion. Keep it away from excessive moisture and extreme temperatures.
- **Inspection:** Regularly inspect the jaws for wear or damage. While made from high-performance alloy steel, prolonged heavy use can cause wear. If the jaws become significantly worn or damaged, the tool's effectiveness may be reduced.

TROUBLESHOOTING

If you encounter issues with your Bahco 36 Nail Puller, consider the following common solutions:

- **Nail slips from jaws:**
 - Ensure the jaws are fully seated under the nail head.
 - Apply more pressure to the handles to secure a tighter grip.
 - For very small or headless nails, this tool may not be suitable.
- **Difficulty extracting stubborn nails:**
 - Use a hammer on the striking area to help loosen the nail or drive the jaws deeper.
 - Increase leverage by adjusting your grip or the angle of the tool.
- **Jaws feel stiff or sticky:**
 - Clean the pivot point and jaws thoroughly to remove any accumulated debris.
 - Apply a small amount of light machine oil to the pivot point.

If problems persist, contact Bahco customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	Bahco
Model Number	BH36
Part Number	FBA_BAH36
Item Weight	1.01 pounds (approx. 0.46 kg)

Feature	Detail
Product Dimensions	11.02 x 11.02 x 7.09 inches (approx. 28 x 28 x 18 cm)
Material	Alloy Steel
Item Package Quantity	1
Number Of Pieces	1
Measurement System	Inch

WARRANTY INFORMATION

Bahco products are manufactured to high standards and are designed for durability. For specific warranty terms and conditions applicable to your Bahco 36 Nail Puller, please refer to the official Bahco website or contact Bahco customer service. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For technical assistance, spare parts, or general inquiries regarding your Bahco 36 Nail Puller, please contact Bahco customer support through their official channels:

- **Website:** Visit the official Bahco website for support resources, FAQs, and contact forms.
- **Contact Information:** Refer to the packaging or the official Bahco website for regional contact numbers or email addresses.

When contacting support, please have your product model number (BH36) and purchase details readily available.

