



[Manuals.plus](#) /

› [AdvPro](#) /

› AdvPro Custom Neon Light Sign Instruction Manual

## AdvPro veg310-r

# AdvPro Custom Neon Light Sign Instruction Manual

Model: veg310-r

## INTRODUCTION

---

Thank you for purchasing the AdvPro Custom Neon Light Sign. This manual provides essential information for the safe and proper installation, operation, and maintenance of your new sign. Please read this manual thoroughly before use and retain it for future reference.

## SAFETY INFORMATION

---

To ensure safe operation and prevent damage, please observe the following precautions:

- Always disconnect the power supply before cleaning or performing any maintenance.
- Do not expose the sign to water or excessive moisture. This product is designed for indoor use only.
- Avoid placing the sign in direct sunlight or near heat sources, as this may affect its lifespan and performance.
- Handle the sign with care. The acrylic panel can be scratched or damaged if dropped or mishandled.
- Ensure the power adapter is compatible with your local voltage and current requirements.
- Keep out of reach of children and pets.
- Do not attempt to open or modify the sign. Refer all servicing to qualified personnel.

## PACKAGE CONTENTS

---

Please check the package contents upon receipt to ensure all items are present and undamaged:

- AdvPro Custom Neon Light Sign (1 unit)
- Power Adapter (1 unit)
- Hanging Chain (1 unit)

## SETUP

---

Follow these steps to set up your AdvPro Custom Neon Light Sign:

1. **Unpacking:** Carefully remove the sign and all accessories from the packaging. Inspect for any visible damage.
2. **Placement:** Choose a suitable indoor location for your sign. Ensure the surface is stable and can support the weight of the sign. Avoid areas with high humidity or direct exposure to water.
3. **Hanging (Optional):** If you wish to hang the sign, attach the provided hanging chain to the pre-drilled holes or hanging points on the sign's frame. Securely hang the sign from a sturdy hook or fixture on the wall or ceiling.
4. **Power Connection:** Connect the power adapter cable to the input port on the sign. Then, plug the power adapter into a standard electrical outlet.



**Figure 1:** The AdvPro Custom Neon Light Sign showing the clear acrylic panel, the engraved design, and the aluminum bar with a hanging chain attached at the top. This image illustrates how the sign can be suspended.

## OPERATING

---

Once the sign is properly set up and connected to power, it will illuminate automatically. There are no additional controls for brightness or color on this model.



**Figure 2:** The AdvPro Custom Neon Light Sign featuring a heart outline with a pug dog's face inside, and the name "ADA" below, all illuminated in a soft glow against a dark background. This image demonstrates the sign's appearance when powered on.



**Figure 3:** A close-up view of the AdvPro Custom Neon Light Sign, showing a heart outline with a pug dog's face inside, and the word "SAMPLE" illuminated in a vibrant red. This image highlights the illuminated effect and the clarity of the engraved design.

## MAINTENANCE

---

Proper care will extend the life of your neon sign:

- **Cleaning:** Before cleaning, always unplug the sign from the power outlet. Use a soft, dry, lint-free cloth to gently wipe the acrylic surface. For stubborn smudges, slightly dampen the cloth with water. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the acrylic.
- **Dusting:** Regularly dust the sign to prevent accumulation, which can diminish its brightness.
- **Storage:** If storing the sign for an extended period, disconnect it from power and store it in a dry, cool place, preferably in its original packaging to protect it from dust and physical damage.

## TROUBLESHOOTING

---

If you encounter issues with your sign, refer to the following table:

Problem	Possible Cause	Solution
Sign does not light up.	No power connection.	Ensure the power adapter is securely plugged into both the sign and a working electrical outlet. Test the outlet with another device.
Sign flickers or dims.	Loose connection or power fluctuation.	Check all connections. Try plugging into a different outlet. If the issue persists, the power adapter or sign may require professional inspection.
Sign is scratched or damaged.	Physical impact.	Handle with care. Scratches on the acrylic are typically cosmetic and do not affect functionality. For significant damage, contact customer support.

## SPECIFICATIONS

---

Feature	Detail
---------	--------

Feature	Detail
Model	veg310-r
Brand	AdvPro
ASIN	B00DB7016M
Manufacturer	ADV PRO
Power Source	AC Power Adapter (included)
Intended Use	Indoor Use Only

## WARRANTY AND SUPPORT

---

AdvPro stands behind the quality of its products. For information regarding warranty coverage, technical support, or replacement parts, please refer to the contact information provided with your purchase or visit the official AdvPro website. Please have your model number (veg310-r) and ASIN (B00DB7016M) ready when contacting support.

For further assistance, you may visit the AdvPro Store on Amazon:[AdvPro Store](#)