

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AOC](#) /

› [AOC E2070Swn 19.5-inch LED Widescreen Monitor User Manual](#)

AOC E2070Swn

AOC E2070Swn 19.5-inch LED Widescreen Monitor User Manual

INTRODUCTION

This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your AOC E2070Swn 19.5-inch LED Widescreen Monitor. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Figure 1: Front view of the AOC E2070Swn monitor, showcasing its 19.5-inch LED display and compact design.

SETUP INSTRUCTIONS

1. Unpacking

Carefully remove all components from the packaging. Ensure the following items are present:

- AOC E2070Swn Monitor
- Monitor Stand (Base and Neck)
- Power Cable
- VGA Cable
- User Manual (this document)
- Driver CD (for software installation)

2. Assembling the Stand

1. Attach the stand neck to the monitor panel. Ensure it clicks securely into place.
2. Attach the stand base to the stand neck. Tighten any screws if provided, usually located at the bottom

of the base.



Figure 2: Rear view of the AOC E2070Swn monitor, illustrating the stand's attachment area and ventilation.

3. Connecting Cables

- 1. Power Connection:** Connect the power cable to the monitor's power input port and then to a power outlet.
- 2. Video Connection:** Connect one end of the VGA cable to the VGA port on your computer's graphics card and the other end to the VGA input port on the monitor.



Figure 3: Detailed view of the monitor's rear panel, highlighting the VGA input and power connector for cable attachment.

4. Initial Power-On

Press the power button located on the monitor. The monitor should power on and display an image from your connected computer. If no image appears, ensure all cables are securely connected and the computer is powered on.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the power button on the front or bottom bezel of the monitor to turn it on or off.

2. On-Screen Display (OSD) Menu

The monitor features an On-Screen Display (OSD) menu for adjusting various settings. Use the physical buttons, typically located on the bottom right bezel, to navigate and select options within the OSD menu.

3. Adjusting Display Settings

Through the OSD menu, you can adjust settings such as:

- **Brightness:** Controls the overall luminance of the screen.
- **Contrast:** Adjusts the difference between the brightest and darkest areas of the image.
- **Color Temperature:** Modifies the color balance (e.g., Warm, Cool, sRGB).
- **Input Select:** Manually switch between available video inputs (if multiple are present).

For advanced display settings and optimal resolution configuration, it is recommended to install the drivers and software provided on the included CD. These tools allow for fine-tuning of display parameters directly from your computer's operating system.

MAINTENANCE

1. Cleaning the Monitor

To clean the monitor screen and casing:

- Always turn off the monitor and unplug the power cord before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a non-abrasive screen cleaner.
- Avoid using alcohol, ammonia, or abrasive cleaners, as these can damage the screen surface.
- Wipe gently; do not apply excessive pressure to the screen.

2. General Care

- Avoid placing the monitor in direct sunlight or near heat sources.
- Ensure adequate ventilation around the monitor to prevent overheating.
- Do not place heavy objects on the monitor or its cables.

TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common problems and solutions:

- **No Image on Screen:**
 - Ensure the monitor's power cable is securely connected to both the monitor and a working power outlet.
 - Verify the video cable (VGA) is firmly connected to both the monitor and the computer.
 - Confirm the computer is powered on and not in sleep mode.
 - Press the monitor's power button to ensure it is turned on.
- **Image is Distorted or Unclear:**
 - Check the video cable for any damage or loose connections.
 - Adjust the monitor's resolution settings through your computer's display settings to match the monitor's native resolution (e.g., 640 x 480).
 - Use the OSD menu to perform an auto-adjustment or manually adjust brightness, contrast, and phase settings.
- **Monitor Power LED is Off:**
 - Ensure the power cable is properly connected and the power outlet is functional.

- Press the power button on the monitor.

If the problem persists after attempting these solutions, please contact AOC customer support for further assistance.

SPECIFICATIONS



Figure 4: Dimensional overview of the AOC E2070Swn monitor, indicating height, width, and depth.

Feature	Detail
Brand	AOC
Model Number	E2070Swn
Screen Size	19.5 Inches
Display Type	LED Widescreen
Resolution	640 x 480
Aspect Ratio	16:9
Video Input	1 x VGA Port
Voltage	220 Volts
Wattage	18 Watts
Product Dimensions (LxWxH)	52.07 x 10.67 x 11.43 cm

Feature	Detail
Item Weight	3.18 kg

WARRANTY AND SUPPORT




Warranty Information


This AOC E2070Swn monitor comes with a **3-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures repair or replacement of the product under normal usage conditions. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or any other inquiries regarding your AOC monitor, please visit the official AOC support website or contact their customer service department. Refer to the contact information provided with your product packaging or on the AOC official website.

Related Documents - E2070Swn

	<p><u>AOC C27G2Z3/BK 27-Inch Monitor Quick Start Guide</u></p> <p>This document provides a quick start guide for the AOC C27G2Z3/BK 27-inch monitor, detailing setup, connectivity, on-screen display controls, and technical specifications.</p>
	<p><u>AOC C27G42E Gaming Monitor: Quick Start Guide & Specifications</u></p> <p>Get started with your AOC C27G42E 27-inch gaming monitor. This guide covers setup, connections, OSD controls, and detailed technical specifications for optimal performance.</p>
	<p><u>AOC SPX24V2 User Manual - Setup, Operation, and Specifications</u></p> <p>Comprehensive user manual for the AOC SPX24V2 display, covering safety, setup, operation, media playback, file management, troubleshooting, and technical specifications. Visit www.aoc.com for more information.</p>
	<p><u>AOC 22B2H LED Monitor User Manual and Specifications</u></p> <p>Detailed user manual and technical specifications for the AOC 22B2H 21.5-inch Full HD LED monitor. Learn about setup, OSD menu adjustments, connectivity options (VGA, HDMI), software features (i-Menu, e-Saver, Screen+), and compliance.</p>

	<p>AOC GK500 Mechanical Gaming Keyboard User's Guide</p> <p>Comprehensive user guide for the AOC GK500 Mechanical Gaming Keyboard. Covers package contents, specifications, device layout, installation and usage of AOC G-Tools software for profile management, button assignment, macro programming, RGB lighting effects (Light FX), and sensitivity settings, along with safety and maintenance guidelines.</p>
	<p>Instrukcja obsługi AOC Q27G4SRU - Monitor Gamingowy</p> <p>Szczegółowa instrukcja obsługi dla monitora gamingowego AOC Q27G4SRU, zawierająca informacje o instalacji, konfiguracji, ustawieniach, rozwiązywaniu problemów i specyfikacjach technicznych.</p>