

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [QUNDA](#) /

> [KT-E08 Universal Remote for All Major Brands of Mini Split AC Instruction Manual](#)

QUNDA KT-E08

KT-E08 Universal Remote for All Major Brands of Mini Split AC

MODEL: KT-E08 | BRAND: QUNDA

Product Overview

Thank you for choosing the QUNDA KT-E08 Universal Remote. This product is designed to provide convenient control for your mini split air conditioner. The KT-E08 incorporates new patent technologies, offering a user-friendly experience suitable for all ages.

This universal air conditioner remote control is equipped with 6000 codes, making it compatible with approximately 98% of domestic and international air conditioners, including old and new types. It features a clock, timer on/off, and room temperature display.

Important Notes:

- This remote may not have all the functions of your original remote.
- The temperature display on this model is in **Celsius degrees only**. There is no option to switch to Fahrenheit.





Figure 1: KT-E08 Universal A/C Remote Control. This image displays the remote's layout, including the LCD screen, temperature buttons, mode, fan, swing, vane, timer, and numeric keys.

Setup

Battery Installation

Insert two AAA (UM-4, R03) batteries into the battery compartment, ensuring correct polarity as indicated inside the cabin.

Code Input (Manual Search)

To program the remote, you can manually input a code from the provided code table:

1. Locate your air conditioner brand in the code table. Multiple code groups may be listed for each brand. Try the first group; if it does not work, proceed to the next. For example, for AUCMA, you might try 0288, then 0289 if needed.
2. Press the "SELECT" key. The code on the LCD screen will flash.
3. Enter the 4-digit code using the numeric keys. As you press each digit, the flashing will stop momentarily. Once all four digits are entered, the code input is complete.
4. Aim the remote at your air conditioner and press the "One Key" button. Check if the air conditioner responds. If it works, the setting is successful. If not, try another code group until it functions correctly.




Universal A/C Remote Control

KT-E08 Brand Code Table

6000 IN 1

Brand	Model Code	Brand	Model Code	Brand	Model Code
ALPIN	0252-0253, 1276, 1789	HISENSE	0332-0335, 0517, 1856, 2895	Sabro	0435, 0506-0508, 0947, 3578
AUCMA	0288-0296, 0462, 1826, 3534	HITACHI	0118-0126, 1656, 2173	SAWO DENKI	0212-0215, 0724, 2262
AUX	0297-0300, 0451, 1834, 3011	HUABAO	0336-0344, 2384, 2903, 4905	SAMPO	0424-0426, 1448, 2385, 5450
BANSHEN	0264, 1288, 2824	HUAKE	0408, 0620, 1501, 3480	SAMSUNG	0188-0196, 0516, 0518, 1212
BOERKA	0383, 0434, 0436, 0437, 3506	HUAMEI	0402, 0460-0465, 2962, 3986	SANYO	0046-0095, 0529, 0530, 1070
CARRIER	0203-0209, 0456-0458, 0482-0486, 0563-0565	HUALING	0317-0325, 0452, 2365, 3524	SASUKI	0254, 0470, 1494, 2814
CHANGHONG	0301-0308, 2349, 3890, 4905	HUIFENG	0370, 2418, 3442	SHANGLING	0384-0388, 0444-0445, 3407
CHIGO	0379-0382, 0515, 1912, 2940	HUIKANG	0368, 0441-0443, 1978, 3440	SHANXING	0392, 0449, 0612, 0904, 1985
CHOFU	0184-0187, 1208, 2233, 4330	HYUNDAI	0202, 0433, 0480, 0551, 3552	SHARP	0096-0106, 0525, 1122
CHUNLAN	0345-0350, 0450, 0453, 3522	JDC	0373, 0440, 2488, 3957	SHENGFENG	0376, 0480, 0888, 1911
CORONA	0155-0163, 0459, 2204, 3531	JIANGNAN	0432, 1456, 3607, 4906-4915	SHINCO	0351-0354, 0454-0456, 3935
CONROWA	0377, 0889, 1315, 2937	JINTAR	0414, 1950, 3998, 4655-4669	SHUANGLU	0376, 0404-0407, 0480, 1400
CONSUL	0463, 1999, 3535, 4335-4650	JINSONG	0389-0391, 0446-0448, 3463	SHUAIKANG	0288, 0800, 5450-5643
DAEWOO	0203-0209, 0406, 1430, 3792	JOHNSON	0245, 0492, 2028, 3829	SONGGE	0428-0429, 2988, 3501
DAIKIN	0171-0183, 0566, 0567, 0583	KANGLI	0374-0375, 1911, 2442	SOVA	0409-0410, 1433, 2457
DOCTOR	0221, 0449, 1473, 3805	KELON	0282-0287, 0473, 0485-0488	SUMMER	0427, 1963, 5644-5700
DONGBAO	0355-0361, 1897, 2918, 4652	KLIMATAIR	0225, 0226, 0452, 3297	SUNDURG	0257, 0505, 1529, 2305
DONGXINBAO	0413, 1505, 3485, 4700-4768	KOLIN	0416-0418, 2466, 3488	SWAN	0434, 0515, 0524, 2994
Electrolux	0216-0220, 0569, 1244	KONKA	0397, 0457-0459, 3017	TADIRAN	0246-0251, 0759, 1787, 3701
FEDDERS	0528, 4804, 4820-4900	LG	0197-0200, 0514, 0572, 2248	TATUNG	0419-0420, 2380, 3491
FRESTECH	0277, 0519, 0520, 2325	LIANGYU	0233, 0451, 1987, 3817	TCL	0273-0281, 0570, 0786
FUJITSU	0127-0137, 0464, 0552-0554	LITTLE DUCK	0015-0020, 0530, 1039	TECO	0256, 0473-0475, 1497, 3840
FUNAI	0430, 0481, 3041, 3502	LOREN-SEBO	0255, 0471, 0472, 2007, 3327	TIANDI	0415, 1438, 3899, 5720-5738
GALANZ	0371, 0372, 0521, 1908, 2931	MACQUAY	0234-0237, 0465, 1489, 2794	TOSHIBA	0107-0117, 0489, 0561, 0562, 1001
GENERAL	0127-0137, 0464, 2000, 3712	MICOM	0415, 1438, 2465, 3487	TRANE	0227-0232, 0739, 1101, 1768
GENOQIAO	0244, 0291, 1268, 2851	MIDEA	0260-0265, 0526, 1801, 2820	UNI-AIR	0222-0224, 0450, 1986
GLEE	0398, 0399, 2446, 2969, 5290	mitsubishi	0001-0045, 0476-0479, 0562, 0563, 0568, 0582, 5000	WANBAC	0138-0154, 0483, 0652, 0995
GOLDSTAR	0201, 0466-0469, 1737, 3539	NORITZ	0431, 0943, 2991, 5005-5256	WEILI	0393-0396, 1420, 1932
GREE	0309-0316, 0482, 0512, 0513	OMEGA	0559	Whirlpool	0164-0170, 0502, 1526, 3748, 0461, 0693, 3800-5996
HAIER	0266-0272, 0453-0455	National	0138-0154, 0483, 2714, 3722	XILENG	0411, 0412, 0824, 1947
		PANASONIC	0378, 1914, 3982, 5257-5259	XINLE	0400, 0401, 0913, 2960
		PANDA	0378, 1914, 3982, 5257-5259	YANGZI(YAIR)	0403, 1427, 2451
		PHILCO	0210-0211, 0487, 0488, 1234	YINYAN	0258-0259, 0326-0331, 0838
		PROTON	0421-0423, 0934, 2981	YORK	0238-0243, 0751, 1778
		RAYBO	0362-0367, 2410, 3435, 5278	ZHEN BAO	0127-0137, 0464, 2000, 3711
		ROWA	0369, 0438-0439, 0527, 0531		

Figure 2: KT-E08 Brand Code Table. This table lists numerous air conditioner brands and their associated 4-digit programming codes.

Automatic Search

If you do not know your air conditioner's brand or if it is not listed in the code table, follow these steps:

1. Point the remote control towards your air conditioner. Press and hold the "SELECT" key for 5 seconds, then release. The remote will enter auto-search mode, continuously emitting signals. The code on the display will flash and increase.
2. When your air conditioner receives the signal and emits a buzzer sound, press any key on the remote to confirm the code.
3. Aim the remote at the air conditioner again and press the "One Key" button. If it works, the setting is successful. If not, repeat these steps until the remote operates your equipment.

Operating Instructions

Basic Functions

- **Temperature Adjustment:** Use the "TEMP+" and "TEMP-" buttons to increase or decrease the temperature.
- **Mode Selection:** Press the "MODE" button to cycle through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Fan Speed:** Use the "FAN" button to adjust the fan speed.
- **Swing/Vane:** Use the "SWING" and "VANE" buttons to control the air deflector's movement.
- **One Key Operation:** For quick operation, simply aim the remote at your air conditioner and press the "One Key" button. The remote will automatically set the temperature to 26°C in summer or 20°C in winter, based on the current ambient temperature. You can then adjust the temperature manually if desired.
- **Room Temperature Display:** Press the "TEMP" button to display the current room temperature. It will revert to the setting temperature after 5 seconds. This function allows the remote to act as a thermometer.

Clock Setup

1. Press the "CLOCK" button. The clock display will start blinking.
2. Use the "TIME+" or "TIME-" buttons to set the current time.
3. Press the "CLOCK" button again to stop blinking and complete the time setting. If you do not press the "TIME" button, the time will be set automatically after 5 seconds.

Timer ON and OFF

You can set the timer for the air conditioner to turn on or off, regardless of its current state.

1. **Timer ON:** Press the "TM ON" button. The LCD will display the clock signal and time blinking. Use the "TIME/CODE" "+" or "-" buttons to adjust to the desired turn-on time. The time will be confirmed after 5 seconds.
2. **Timer OFF:** Press the "TM OFF" button. The LCD will display the clock signal and time blinking. Use the "TIME/CODE" "+" or "-" buttons to adjust to the desired turn-off time. The time will be confirmed after 5 seconds.

Note:

- The timer can be set for a 00-24 hour period.
- Pressing the "TM ON" or "TM OFF" button twice continuously will cancel the timing.
- For timing settings to work effectively, the remote control must be aimed at the air conditioner within effective distance.

Maintenance

Battery Replacement

If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which could damage the device. Replace batteries when the LCD display becomes dim. Always use new batteries; do not mix new and old batteries. After battery replacement, it is generally not necessary to reset the model code.

General Care

Keep the remote control clean and dry. Avoid exposing it to extreme temperatures, humidity, or direct sunlight. Do not drop or subject the remote to strong impacts.

Troubleshooting

Remote Not Working or Inconsistent Operation

- **Check Batteries:** Ensure batteries are correctly installed and have sufficient charge. Replace them if the LCD is dim.
- **Re-enter Code:** If the remote stops working, try re-entering the 4-digit code for your air conditioner.
- **Line of Sight:** Ensure there are no obstructions between the remote controller and the air conditioner. The remote's operation is effective only when the air conditioner receives the signal.
- **Timer Issues:** If the timer function is not working, verify that there is no obstruction between the remote and the air conditioner.

Temperature Display in Celsius Only

As stated in the product overview, this model displays temperature in Celsius degrees only. There is no function to switch to Fahrenheit.

Specifications

Feature	Detail
Model Number	KT-E08

Controllable Distance	Greater than 8 meters (machine dependent)
Battery Model	2 x AAA (UM-4, R03)
Dimensions (L x W x D)	133mm x 45mm x 23mm (5.24 x 1.77 x 0.91 inches)
Weight (Excl. Batteries)	Approx. 52g (1.83 ounces)
Compatible Devices	Most major Ductless mini splits
Special Feature	Numeric code input, compatible with major brand ductless air conditioners, has 6000 codes

Warranty and Support

The manufacturer reserves the final explanatory right regarding this product. Any alterations to the design and model may occur without further notification.

For further assistance or inquiries, please refer to the product packaging or contact the seller/manufacturer directly.