

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Husqvarna](#) /
- > [Husqvarna 532001370 Lawn Tractor Thrust Washer Instruction Manual](#)

Husqvarna 532001370

Husqvarna 532001370 Lawn Tractor Thrust Washer

Genuine Original Equipment Manufacturer (OEM) Part

INTRODUCTION

This manual provides essential information for the Husqvarna 532001370 Lawn Tractor Thrust Washer. This is a genuine Original Equipment Manufacturer (OEM) part, ensuring proper fit and function for your equipment. Please read these instructions carefully before installation to ensure safe and correct usage.

IMPORTANT SAFETY INFORMATION

Always follow appropriate safety practices when installing the washer 532001370. Ensure the equipment is turned off and cooled down, and disconnect the spark plug wire or battery to prevent accidental starting. Wear appropriate personal protective equipment, such as gloves and eye protection. If you are unsure about any step, consult a qualified technician.

PRODUCT OVERVIEW

The Husqvarna 532001370 is a thrust washer designed for use in lawn tractors. A thrust washer is a flat bearing that prevents axial movement between rotating and stationary parts, reducing friction and wear. This specific washer is a critical component for maintaining the correct spacing and smooth operation of various moving parts within your lawn tractor's deck assembly.



Image: The Husqvarna 532001370 Lawn Tractor Thrust Washer, a small, flat, metallic ring designed to reduce friction and manage axial loads in mechanical assemblies.

COMPATIBILITY

This thrust washer (part number 532001370) is compatible with a wide range of lawn tractor models from Husqvarna, Poulan, and Weed Eater. It is also a functional equivalent to prior parts including 1370H, 532001370, 532-001370, and 5320013-70. Always verify compatibility with your specific model number before installation. Refer to your equipment's owner's manual for exact part requirements.

Compatible models include: 917276030, 917299150, 917299151, 3487A79, 96026000201, YT48CS-502130, 917254490, 624A70, 917276022, 917276021, LOGTH2548A, 917276020, 917276140, 917299160, 917276380, 96092000900, 917101340R-1987, WE261, 917254480, 917258960, 917258961, 917258962, 917275287, 917276013, 917293970, 917299253, 917299252, 917276052, 917276051, 184956, 917276050, 917299130, 917299250, 917204080, 917204081, 624A58, PPRTH5A, AYP8209A79, GTH2654, 917276041, 917276040, 917299020, HITCH ADAPTER KIT TX220AR, 917204090.

Does your part fit?



Many replacement parts
look the same
but won't fit your model.

Don't be fooled!

Check your
model number
before you buy.

Image: A red stop sign graphic with text advising users to check their model number for compatibility before purchasing, as many replacement parts may look similar but not fit.

INSTALLATION

Installing a thrust washer typically involves disassembling the component it supports, replacing the old washer, and reassembling. Specific steps vary depending on your lawn tractor model and the exact location of the washer. Always consult your lawn tractor's service manual for detailed, model-specific instructions.

1. **Preparation:** Park the lawn tractor on a level surface, engage the parking brake, and turn off the engine. Disconnect the spark plug wire or remove the battery to prevent accidental starting.
2. **Access:** Depending on the washer's location (e.g., deck spindle, steering column), you may need to remove covers, belts, or other components to gain access.
3. **Removal:** Carefully remove the worn or damaged thrust washer. Note its orientation and position for correct reinstallation.
4. **Cleaning:** Clean the area where the new washer will be installed, removing any debris, rust, or old grease.

5. **Installation:** Place the new Husqvarna 532001370 thrust washer in its correct position. Ensure it sits flush and is properly aligned.
6. **Reassembly:** Reassemble all components in reverse order of disassembly. Ensure all fasteners are tightened to the manufacturer's specifications.
7. **Testing:** After reassembly, perform a functional check to ensure all parts move freely and correctly before operating the lawn tractor.

OPERATING

This thrust washer is a passive mechanical component and does not require operational instructions. Its function is integral to the proper operation of the larger assembly it is part of.

MAINTENANCE

The Husqvarna 532001370 thrust washer is designed for durability and typically requires no routine maintenance beyond ensuring the surrounding components are properly lubricated as per your lawn tractor's maintenance schedule. Inspect the washer for wear during any related service.

TROUBLESHOOTING

As a simple mechanical component, the thrust washer itself does not typically require troubleshooting. If issues arise, such as excessive play or noise in the assembly where the washer is located, inspect the washer for wear or damage. Ensure it is correctly installed and that all surrounding components are in good working order. Refer to your lawn tractor's service manual for specific troubleshooting guides related to the assembly.

SPECIFICATIONS

Specification	Detail
Part Number	532001370
Product Dimensions	2.54 x 2.54 x 2.54 cm; 2 g
Material	Metal
Manufacturer	Husqvarna
Bearing Number	532001370
Bearing Type	Ball Bearing
Compatible Lubricant	Grease
Specification Met	OEM

WARRANTY AND SUPPORT

This genuine Husqvarna OEM part is subject to the manufacturer's standard warranty. For specific warranty details or technical support, please refer to the documentation provided with your lawn tractor or contact Husqvarna customer service directly. Keep your purchase receipt for warranty claims.