Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Westek LTAPE6CCHBCC

Westek LTAPE6CCHBCC LED Color Changing Tape Light with Remote, 6-feet User Manual

1. Introduction

This manual provides instructions for the installation, operation, and maintenance of the Westek LTAPE6CCHBCC LED Color Changing Tape Light. This product is designed to provide adjustable color lighting for various indoor applications, including hallways, coves, cabinets, and architectural elements. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

- Read all instructions carefully before installing and operating the tape light.
- This product is intended for indoor use only. Do not expose to water or high humidity.
- Ensure the power source is disconnected before installation or maintenance.
- Do not attempt to repair or modify the product. Refer all servicing to qualified personnel.
- Avoid direct eye exposure to the LED light source.
- Keep out of reach of children.

3. Package Contents

Verify that all components are present in the package:

- LED Color Changing Tape Light (6-feet)
- Remote Control
- Power Adapter

4. Product Features

- **Adjustable Color Lighting:** Offers 16 distinct color settings.
- **Dynamic Modes:** Includes 4 settings for flashing and fading effects.
- **Remote Control:** Allows for easy adjustment of brightness, speed, and color settings.
- **Customizable Length:** Designed with predetermined cut points every 4 inches for length customization.

- **Easy Installation:** Features 3M high-bond adhesive backing for peel-and-stick application.
- **Connectivity:** Includes a special connector to link light sections or navigate corners.
- **Energy Efficient:** Utilizes LED technology for reduced electricity consumption.

5. Setup and Installation

1. **Prepare the Surface:** Ensure the installation surface is clean, dry, and smooth. Dust, grease, or moisture can affect adhesive performance.
2. **Measure and Cut (Optional):** If a shorter length is desired, measure the required length and cut the tape light only at the designated cut marks (typically every 4 inches). Cutting at other points may damage the circuit and render the section unusable.
3. **Apply the Tape Light:** Carefully peel off the protective backing from the 3M adhesive tape. Press the tape light firmly onto the desired surface, ensuring even contact along its entire length.
4. **Connect Power:** Plug the power adapter into the tape light connector, then plug the power adapter into a standard electrical outlet.



Image 1: The Westek LED Color Changing Tape Light unrolled, showing the LED strip and connector.

6. Operation

The Westek LED Color Changing Tape Light is operated using the included remote control.



Image 2: The Westek LED Color Changing Tape Light shown with its remote control.

Remote Control Functions:

- **Power Button:** Turns the tape light ON or OFF.
- **Color Selection Buttons:** Select from 16 static color options.
- **Brightness Adjustment:** Increase or decrease the intensity of the selected color.
- **Mode Buttons:** Cycle through 4 dynamic modes (e.g., flash, strobe, fade, smooth) for color changing effects.
- **Speed Adjustment:** Adjust the speed of the dynamic color changing modes.

Note: Ensure the remote control has working batteries and is pointed towards the tape light's receiver for optimal functionality.

7. Maintenance

- **Cleaning:** Gently wipe the tape light with a dry, soft cloth. Do not use abrasive cleaners or solvents, as these may damage the product.
- **Adhesive:** If the adhesive begins to lose its grip, ensure the surface is clean and dry. For long-term adhesion, additional mounting clips (not included) may be used.

- **Storage:** When not in use for extended periods, store the tape light in a cool, dry place.

8. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power to the unit. Remote control batteries are dead or incorrectly inserted.	Check power adapter connection to outlet and tape light. Replace remote control batteries, ensuring correct polarity.
Colors are not changing or remote is unresponsive.	Remote control batteries are low. Obstruction between remote and receiver.	Replace remote control batteries. Ensure a clear line of sight between the remote and the tape light's receiver.
Tape light adhesive is not sticking.	Surface was not clean or dry during installation.	Ensure the surface is thoroughly cleaned and dried before application. For improved adhesion, consider using additional mounting clips.
Only a section of the tape light is working.	Damage to the tape light circuit, possibly from incorrect cutting.	Ensure cuts were made only at designated marks. If damage occurred, the affected section may need replacement.

9. Specifications

- **Brand:** Westek
- **Model:** LTAPE6CCHBCC
- **Indoor/Outdoor Usage:** Indoor
- **Light Source Type:** LED
- **Power Source:** Corded Electric
- **Voltage:** 3 Volts
- **Wattage:** 12 watts
- **Length:** 6-feet
- **Control Method:** Remote Control
- **Item Weight:** 11.2 ounces
- **Product Dimensions (Packaging):** 11.2 x 8.6 x 10.4 inches

10. Warranty and Support

The Westek LTAPE6CCHBCC LED Color Changing Tape Light comes with a**2-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
For warranty claims, technical support, or any questions regarding your product, please contact Westek customer service. Refer to the product packaging or the official Westek website for current contact information.

© 2023 Westek. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00DGHTLOK

More documents and user manuals: **https://manuals.plus/**