

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PureMounts](#) /

› [PureMounts PM-LM-TS32EB Tilting and Flat Ultra-Thin Wall Mount for TV and Monitor up to 94 cm/37" VESA200 Black User Manual](#)

PureMounts PM-LM-TS32EB

PureMounts PM-LM-TS32EB Tilting and Flat Ultra-Thin Wall Mount User Manual

Brand: PureMounts

Model: PM-LM-TS32EB

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and proper installation, operation, and maintenance of your PureMounts PM-LM-TS32EB Tilting and Flat Ultra-Thin Wall Mount. This mount is designed to securely hold televisions and monitors up to 94 cm (37 inches) with VESA200 compatibility. Please read all instructions carefully before beginning installation.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity specified for this mount. Overloading can result in serious injury or equipment damage.
- **Mounting Surface:** Ensure the wall or mounting surface can safely support the combined weight of the mount and the display. Consult a qualified professional if unsure.
- **Tools:** Use appropriate tools for installation. Incorrect tools can cause damage or injury.
- **Assembly:** Assemble the mount exactly as instructed. Improper assembly can lead to instability.
- **Children:** Keep children away from the installation area. Small parts can be a choking hazard.
- **Cables:** Route all cables properly to prevent pinching or tripping hazards.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain secure.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning installation. Refer to the packaging for a complete and detailed list of included parts. Typically, the package includes:

- Wall Plate Assembly
- TV/Monitor Bracket

- Mounting Hardware (screws, anchors, washers, spacers)
- Instruction Manual

4. SETUP AND INSTALLATION

Before installation, ensure you have all necessary tools and that the mounting surface is suitable.

4.1 Tools Required

- Pencil
- Stud Finder (for wood stud walls)
- Drill with appropriate drill bits
- Level
- Phillips Head Screwdriver
- Socket Wrench (if applicable)
- Measuring Tape

4.2 Mounting Surface Preparation

Identify the type of wall you are mounting to (e.g., wood stud, concrete, brick). Different wall types require specific anchors and installation methods. Ensure there are no hidden electrical wires or plumbing in the drilling path.

4.3 Wall Plate Installation

1. Determine the desired height for your display.
2. Position the wall plate against the wall and use a level to ensure it is perfectly horizontal. Mark the drilling locations with a pencil.
3. Drill pilot holes at the marked locations using the appropriate drill bit size for your wall type and anchors.
4. Insert wall anchors (if required for your wall type).
5. Secure the wall plate to the wall using the provided screws and washers. Tighten all fasteners firmly, but do not overtighten.

4.4 TV/Monitor Bracket Installation

1. Carefully place your TV/monitor face down on a soft, clean surface to prevent screen damage.
2. Identify the VESA mounting holes on the back of your display.
3. Attach the TV/monitor bracket to the back of your display using the appropriate screws, washers, and spacers from the provided hardware kit. Ensure the screws are not too long, which could damage internal components.
4. Tighten all screws securely.

4.5 Attaching TV/Monitor to Wall Mount

With assistance, carefully lift the TV/monitor with the attached bracket and hook it onto the wall plate assembly. Ensure the bracket is properly seated and secured to the wall mount. Engage any safety locking mechanisms if present.



Image 1: The PureMounts PM-LM-TS32EB wall mount, illustrating its articulated arm and the ability to swivel and tilt the attached display. Arrows indicate the range of motion for both the arm and the VESA plate.

5. OPERATING THE MOUNT

The PM-LM-TS32EB mount offers flexibility for optimal viewing angles.

5.1 Adjusting Tilt

To adjust the vertical tilt of your display, gently grasp the top and bottom edges of the TV/monitor and carefully tilt it to the desired angle. The mount is designed for smooth tilting motion. Ensure the tilt mechanism is secure after adjustment.

5.2 Adjusting Swivel

To swivel your display horizontally, gently push or pull the side of the TV/monitor to rotate it along the articulated arm. The mount allows for a wide range of horizontal movement to achieve the best viewing position. Avoid excessive force.

6. MAINTENANCE

- **Cleaning:** Clean the mount with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Regular Checks:** Periodically (e.g., every 6 months) inspect all mounting screws and connections to ensure they are still tight and secure. Re-tighten if necessary.
- **Movement:** If the mount's movement becomes stiff or loose, check for any obstructions or consult the manufacturer's support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Mount feels unstable or wobbly.	Loose mounting screws or inadequate wall support.	Ensure all wall plate screws are securely tightened. Verify the wall can support the weight. Re-install if necessary.
Difficulty adjusting tilt or swivel.	Joints are too tight or there is an obstruction.	Check for any obstructions. Some mounts have adjustable tension screws; refer to specific product diagrams if applicable. Do not force movement.

Problem	Possible Cause	Solution
TV/Monitor is not level.	Wall plate installed unevenly.	Remove the TV/monitor, loosen wall plate screws, adjust with a level, and re-tighten.

8. SPECIFICATIONS

Model:	PM-LM-TS32EB
Compatible Devices:	Monitor, Television
Mounting Type:	Wall Mount
Movement Type:	Tilting, Swiveling
Material:	Alloy Steel
Maximum Screen Size:	94 cm / 37 inches
VESA Compatibility:	VESA200 (e.g., 200x200mm, 100x100mm, 75x75mm)

9. WARRANTY AND SUPPORT

For warranty information, technical support, or to inquire about replacement parts, please refer to the documentation included with your product or visit the official PureMounts website. Specific warranty terms may vary by region and retailer.

Manufacturer: PureMounts

Website: www.puremounts.de (Example link, actual link may vary)