

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ARCTIC](#) /

› [ARCTIC S113 BT Portable Bluetooth Speaker User Manual](#)

ARCTIC S113BT

ARCTIC S113 BT Portable Bluetooth Speaker User Manual

Model: S113BT | Brand: ARCTIC

INTRODUCTION

The ARCTIC S113 BT is a portable Bluetooth speaker designed for wireless audio streaming. It features NFC for quick one-touch pairing and Bluetooth 4.0 for reliable, high-quality sound transmission. With its built-in 1200 mAh Lithium Polymer battery, it provides up to 8 hours of music playback, making it ideal for on-the-go use. This manual provides instructions for setting up, operating, and maintaining your speaker.

PACKAGE CONTENTS

Verify that all items are present in your package:

- ARCTIC S113 BT Portable Bluetooth Speaker x 1
- 3.5 mm Audio Cable (30 cm) x 1
- Micro USB Charging Cable (80 cm) x 1
- Carrying Case x 1
- User Manual x 1



Image: Contents of the ARCTIC S113 BT package, showing the speaker, a 3.5mm audio cable, a micro USB charging cable, and a grey carrying case.

PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Image: Top view of the ARCTIC S113 BT speaker, highlighting the control buttons: Volume Down (-), Play/Pause/Call Answer (square), and Volume Up (+).

- **Volume Down (-) Button:** Decreases volume.
- **Play/Pause/Call Answer (Square) Button:** Plays or pauses music, answers or ends calls.
- **Volume Up (+) Button:** Increases volume.



Image: Side panel of the ARCTIC S113 BT speaker, showing the 'LINE IN' 3.5mm audio port, the 'POWER' micro USB charging port, and the 'ON/OFF' switch.

- **LINE IN Port:** 3.5mm audio input for wired connection.
- **POWER Port:** Micro USB port for charging the speaker.
- **ON/OFF Switch:** Powers the speaker on or off.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided Micro USB cable to connect the speaker's POWER port to a USB power source (e.g., computer USB port, USB wall adapter).

- The LED indicator will show charging status (refer to product documentation for specific LED behavior).
- A full charge typically takes a few hours.



Image: The ARCTIC S113 BT speaker with a micro USB cable plugged into its charging port on the side.

2. Powering On/Off

- To power on, slide the **ON/OFF** switch to the 'ON' position. The LED indicator will light up.
- To power off, slide the **ON/OFF** switch to the 'OFF' position. The LED indicator will turn off.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing (Wireless Connection)

The S113 BT speaker can be paired with your Bluetooth-enabled device (smartphone, tablet, laptop) using either NFC or standard Bluetooth pairing.

NFC One-Touch Pairing:

1. Ensure NFC is enabled on your smartphone and the speaker is powered on.
2. Gently tap your NFC-enabled smartphone against the NFC area of the speaker (usually indicated by an NFC logo or located on the top surface).
3. Your smartphone will prompt you to confirm the pairing. Accept the connection.
4. Once paired, the speaker will be ready to play audio from your device.



Image: A smartphone being tapped on the top surface of the ARCTIC S113 BT speaker, demonstrating the NFC one-touch pairing process.

Standard Bluetooth Pairing:

1. Power on the speaker. It will automatically enter Bluetooth pairing mode (the LED indicator will flash, indicating it's discoverable).
2. On your device, go to Bluetooth settings and enable Bluetooth.
3. Search for available devices. Select "ARCTIC S113 BT" from the list.
4. If prompted for a password, enter "0000" (if applicable).
5. Once paired, the LED indicator will change (e.g., solid blue), and you will hear a confirmation tone.

2. Audio Playback

- **Wireless:** After successful Bluetooth pairing, start playing music on your connected device. Audio will stream through the speaker.
- **Wired (LINE IN):** Connect one end of the 3.5mm audio cable to your audio source's headphone jack and the other end to the speaker's LINE IN port. The speaker will automatically switch to wired mode.
- **Volume Control:** Use the + and - buttons on the speaker or your connected device to adjust the volume.
- **Play/Pause:** Press the **Square** button to play or pause music.

3. Call Handling (for Bluetooth connected devices)

- **Answer Call:** When a call comes in, press the **Square** button once to answer.
- **End Call:** During a call, press the **Square** button once to end the call.
- **Reject Call:** Press and hold the **Square** button for approximately 2 seconds to reject an incoming call.

MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or moisture.
- Store the speaker in its carrying case when not in use to protect it from dust and scratches.
- If not used for extended periods, charge the battery at least once every three months to prolong its lifespan.

TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the Micro USB cable.
Cannot pair via Bluetooth.	<ul style="list-style-type: none"> ◦ Ensure the speaker is in pairing mode (LED flashing). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device. ◦ Forget "ARCTIC S113 BT" from your device's Bluetooth list and try pairing again. ◦ Ensure no other devices are currently connected to the speaker.
No sound or low volume.	<ul style="list-style-type: none"> ◦ Check the volume level on both the speaker and your connected device. ◦ Ensure the speaker is properly paired or connected via the LINE IN cable. ◦ If using LINE IN, ensure the cable is fully inserted and functional.
NFC pairing not working.	<ul style="list-style-type: none"> ◦ Ensure NFC is enabled on your smartphone. ◦ Make sure your smartphone is tapping the correct NFC area on the speaker. ◦ Try standard Bluetooth pairing as an alternative.

SPECIFICATIONS

Feature	Detail
Model Number	S113BT-PIK

Feature	Detail
Audio Output Channels	2.0
Driver Size	3.81 cm (1.5")
Rated RMS Power	6 W (2x3W)
Frequency Range	30 - 20000 Hz
Impedance	4 Ohm
Connectivity Technology	Bluetooth 4.0, NFC, Wired (3.5mm LINE IN)
Battery Type	Built-in Lithium-ion Polymer (1200 mAh)
Playback Time	Up to 8 hours
Standby Time	Up to 700 hours
Dimensions (L x W x H)	17.15 x 8.26 x 6.35 cm
Weight	385.55 grams
Manufacturer	Arctic
Country of Origin	Germany

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official ARCTIC website or contact their customer service. The product typically comes with a manufacturer's warranty covering defects in materials and workmanship.

You can find more information and support at: www.arctic.ac

A specific product page for the S113 BT might be available at: m.s113bt.arctic.ac