Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- CODi /
- > CODi Powerbank Charger A03022 User Manual

CODi A03022

CODi Powerbank Charger A03022 User Manual

Model: A03022

1. Introduction

Thank you for purchasing the CODi Powerbank Charger A03022. This portable backup charger is designed to provide reliable power for your smartphones, MP3 players, tablets, and other compatible devices. Please read this manual carefully before using the product to ensure proper operation and maintenance.

2. PRODUCT FEATURES

- Slim and Elegant Design: A portable backup charger designed for strong charging capabilities.
- Integrated Cable Management: Features a smart design that keeps the USB-A to Micro USB cable neatly in place when not in use, enhancing portability.
- Extended Charging Time: Provides approximately 6 hours of charging time for your device before the power bank itself needs recharging.
- High Capacity: Equipped with a 5200 mAh Lithium-Ion battery.
- Universal Compatibility: Compatible with smartphones, MP3 players, tablets, and more via USB connection.

3. PACKAGE CONTENTS

Please check the package for the following items:

- CODi Powerbank Charger A03022
- User Manual (this document)

Note: Charging cables for specific devices (other than the integrated Micro USB) are not included.

4. SETUP

4.1 Initial Charge of the Powerbank

Before first use, it is recommended to fully charge your CODi Powerbank Charger A03022.

- 1. Locate the integrated USB-A connector on the power bank. This connector is designed to fold out from the device.
- 2. Connect the USB-A connector to a powered USB port (e.g., computer USB port, USB wall adapter, or car charger).
- 3. The power bank will begin charging. An indicator light (if present, typically near the power button) will show the charging status. Refer to the "Operating Instructions" section for details on indicator lights.
- 4. Once fully charged, disconnect the power bank from the USB power source.



Figure 4.1: CODi Powerbank Charger A03022 showing its compact design and integrated cables. The USB-A connector is visible at the top left, ready for charging the power bank itself, while the Micro USB cable is tucked into the bottom right.

5. OPERATING INSTRUCTIONS

5.1 Charging Your Device

- 1. Locate the integrated Micro USB cable on the power bank. This cable is designed to fold out from the device.
- 2. Connect the Micro USB connector to the charging port of your compatible smartphone, MP3 player, or tablet.
- 3. The power bank should automatically begin charging your device. If not, press the power button on the power bank (if available, typically a small button near the indicator light).
- 4. Monitor your device's charging indicator. Once your device is fully charged, disconnect it from the power bank.

5.2 Power Indicator Light

The CODi Powerbank Charger A03022 features a power indicator light, typically a small LED, which provides information about the power bank's status:

- Solid Light: Indicates the power bank is actively charging a device or is being charged itself.
- Flashing Light: May indicate low battery on the power bank or a charging error.
- No Light: The power bank is off, fully discharged, or fully charged and disconnected.

Note: Specific light patterns may vary slightly. Refer to the product's physical markings for precise indications.

6. MAINTENANCE

- Cleaning: Use a soft, dry cloth to clean the surface of the power bank. Do not use liquid cleaners or aerosols.
- Storage: Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care: To prolong battery life, fully charge the power bank at least once every three months, even if not in use. Avoid fully discharging the battery frequently.
- **Handling:** Do not drop, puncture, or disassemble the power bank. This can damage the internal components and void the warranty.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging device.	Power bank battery is empty. Cable not properly connected. Device is not compatible. Power bank is off.	Recharge the power bank. Ensure the Micro USB cable is securely connected to both the power bank and your device. Verify your device uses a Micro USB port for charging. Press the power button on the power bank to activate it.
Power bank not recharging.	USB power source is not active. USB-A cable not properly connected. Faulty cable or power source.	Ensure the USB port you are using is powered (e.g., try a different port or wall adapter). Ensure the integrated USB-A cable is securely connected to the power source. Try a different USB wall adapter or computer USB port.
Indicator light flashing erratically.	Low battery. Internal error.	Recharge the power bank. Disconnect and reconnect the power bank. If the issue persists, contact customer support.

8. SPECIFICATIONS

Model Number	A03022
Brand	CODi
Battery Capacity	5200 mAh
Battery Type	Lithium Ion
Input/Output Voltage	5 Volts

Connector Type	Integrated USB-A (input), Integrated Micro USB (output)
Color	Black
Dimensions (L x W x H)	10.39 x 1.98 x 5.49 cm (4.09 x 0.78 x 2.16 inches)
Weight	136.08 g (0.3 lbs)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the CODi official website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may visit: www.codi.com

© 2023 CODi. All rights reserved.

Manual Version: 1.0

Related Documents - A03022



CODi Acquisitions, LLC. - USA Agent for Service of Process - CLARO Bluetooth Headset

Official designation of CODi Acquisitions, LLC. as the USA Agent for Service of Process for the CLARO Bluetooth+Wireless Stereo Headset, FCC ID: 2A7KX-A04619, Model: A04619. Includes applicant and agent obligations and contact details.



CODi 10,000mAh PowerBank Charger with Quick Charge™

Discover the CODi 10,000mAh PowerBank Charger with Quick Charge™ for fast, portable power. This slim charger offers up to 70 hours of battery, dual USB and USB-C output, and supports multiple charges for smartphones.



CODi Aquila HD 1080P Fixed Focus Webcam - Product Overview & Specs

Discover the CODi Aquila HD 1080P Fixed Focus Webcam (A05024). This webcam offers 1080p resolution, 30 FPS, a 90° field of view, and a built-in microphone, making it ideal for clear video conferencing. It features USB 2.0 connectivity and is compatible with Windows, Mac, and Chrome.



CODi A04619 User Manual and FCC Compliance Information

User manual and FCC compliance statement for the CODi A04619 device, detailing operational conditions and regulatory adherence.



WOCKODER Turntable User Manual and Guide

Comprehensive guide to operating the WOCKODER Turntable, covering features like LP playback, USB, Bluetooth, and card playback, along with setup, adjustments, and warranty information.



Bluetex Health Technology Heated Throw Constructional Data Report

This report details the constructional data for Bluetex Health Technology's Heated Throw, including product specifications, critical components, test results, and safety instructions, adhering to UL 964 and CSA C22.2 standards.

Documents - CODi - A03022



[pdf] Specifications Dimension Guide Warranty Accessories Borchure

CODi Carrying Case Accessories Power Ad C1230 PC Canada 1030355115 content etilize Manufacturer Brochure |||

Large Accessory Caddy CODi s Large Accessory Caddy reduces clutter by neatly organizing PC and table ... Cable A01046 - USB 3.0 4-Port Hub A02001 - Key Cable Lock A03021 - 100W Universal Power Adapter **A03022** - PowerBank Charger A05013 - 2.4GHz Wireless Mouse A09010 - Screen Cleaner Combination Kit ...

lang:en score:23 filesize: 350.96 K page_count: 1 document date: 2015-05-27



[pdf] Specifications Datasheet Dimension Guide Warranty Accessories Borchure CODi C1230 Product Data Sheet Brochure Large Accessory Caddy Notebooks accessories carrying case black and red f55687af f8bc 430b a250 557acc1ae798 cdn cnetcontent f5 56 ||| Large Accessory Caddy CODi s Large Accessory Caddy reduces clutter by neatly organizing PC and table ... Cable A01046 - USB 3.0 4-Port Hub A02001 - Key Cable Lock A03021 - 100W Universal Power Adapter A03022 - PowerBank Charger A05013 - 2.4GHz Wireless Mouse A09010 - Screen Cleaner Combination Kit ... lang:en score:22 filesize: 495.99 K page_count: 1 document date: 2015-03-19



[pdf] Specifications Datasheet Dimension Guide Warranty Accessories Borchure CODi C1230 Product Data Sheet Brochure Large Accessory Caddy Notebooks accessories carrying case black and red 3af21aa9 a40d 427b a9d3 bfb35714473f cdn cnetcontent 3a f2 ||| Large Accessory Caddy CODi s Large Accessory Caddy reduces clutter by neatly organizing PC and table ... Cable A01046 - USB 3.0 4-Port Hub A02001 - Key Cable Lock A03021 - 100W Universal Power Adapter A03022 - PowerBank Charger A05013 - 2.4GHz Wireless Mouse A09010 - Screen Cleaner Combination Kit ... lang:en score:22 filesize: 497.18 K page_count: 1 document date: 2019-05-28



[pdf] Specifications Dimension Guide Warranty Accessories

Small Accessory Caddy CNET Content SolutionsCODi s reduces clutter by neatly organizing PC and tablet accessories in one convenient spot The stores easily one eff3c536 b845 408c a6dc 858d74a6fe67cdn cnetcontent ef f3 eff3c536 858d74a6fe67 |||

Small Accessory Caddy CODi s Small Accessory Caddy reduces clutter by neatly organizing PC and table ... Cable A01046 - USB 3.0 4-Port Hub A02001 - Key Cable Lock A03021 - 100W Universal Power Adapter A03022 - PowerBank Charger A05013 - 2.4GHz Wireless Mouse A09010 - Screen Cleaner Combination Kit ... lang:en score:18 filesize: 490.51 K page count: 1 document date: 2015-03-19