

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Prym](#) /

> [Prym Tent Snap Fasteners with Parker Screws, 10-Piece Set, Model 4111050, 15mm - Instruction Manual](#)

Prym 4111050

Prym Tent Snap Fasteners with Parker Screws - Model 4111050 (15mm)

Instruction Manual

1. PRODUCT OVERVIEW

This manual provides instructions for the Prym Tent Snap Fasteners, Model 4111050. This set includes 10 screw-in snap fasteners designed for replacing or repairing snaps on tent vestibules, boat covers, or similar heavy-duty applications. The fasteners are 15mm in diameter and come with all necessary components for installation.

390 211

Preisgruppe · Price group · Catégorie de prix

BB



10

'Yacht & Caravan'

Druckknöpfe anschraubbar

Press fasteners with screws

Ø 15 mm

Boutons pression à visser



Image 1: The product packaging for Prym Tent Snap Fasteners, highlighting the 10-piece set, 15mm diameter, and the included mounting tool.

What's Included:

- 10 snap fasteners with parker screws

- Mounting tool
- Suitable for tent fronts and other heavy-duty applications

2. SAFETY INFORMATION

Warning: Keep small parts away from children to prevent choking hazards.

3. INSTALLATION INSTRUCTIONS

Follow these steps to properly install the Prym snap fasteners. A basic understanding of hand tools may be beneficial.

Step 1: Identify Components

Each snap fastener consists of four main parts: the cap (decorative top), the socket (spring-loaded female part), the stud (male part), and the parker screw. The set also includes a plastic mounting tool to aid in assembly.



Image 2: This image displays all individual components of the snap fastener set. You will find the decorative cap, the spring-loaded socket, the stud, the parker screw, and the plastic setting tool used for assembly.

Step 2: Prepare the Material

Determine the exact location for the snap fastener on your fabric or material. Use an appropriate tool (e.g.,

an awl or punch, not included) to create a small hole if necessary, ensuring it is suitable for the snap's post. For the screw-in stud, mark the screw location on the rigid surface.

Step 3: Attach the Snap Cap and Socket

Place the cap on one side of the fabric and the socket on the other, aligning them through the prepared hole. Use the provided mounting tool to securely crimp the cap and socket together onto the fabric. Place the cap face down on the tool's base, position the fabric and socket, then use the other part of the tool (or a hammer with the tool) to apply even pressure until the parts are securely joined.



Image 3: A detailed view of the snap fastener components, including the cap, socket, and the metal part of the setting tool. This tool is used to secure the snap parts onto the fabric.

Step 4: Install the Stud with Parker Screw

For the other side of the snap, typically on a rigid surface like wood or plastic, position the stud and screw it into place using the parker screw. Ensure the stud is firmly attached and aligned with the previously installed cap and socket.

Step 5: Test the Fastener

Once both parts are installed, connect them to ensure a secure and functional snap. The snap should engage and disengage smoothly.

4. USAGE

These snap fasteners are designed for secure attachment and detachment. To open, pull firmly but gently on the material near the snap. To close, align the cap and stud and press them together until you hear a distinct click, indicating a secure connection.

5. MAINTENANCE

Care Instructions:

- Machine washable at 95 °C.
- Do not bleach.
- Dry cleaning with perchloroethylene or heavy gasoline is permissible.
- Iron at moderate temperature.
- Tumble dry at normal temperature.

Regular cleaning according to these instructions will help maintain the longevity and appearance of the fasteners. Avoid harsh chemicals that may corrode the brass material.

6. TROUBLESHOOTING

Snap does not hold securely:

- Ensure both parts of the snap (cap/socket and stud/screw) are correctly installed and fully crimped onto the material or screwed into the surface.
- Verify that the stud is firmly screwed into its base and not loose.
- Check for any debris or damage within the snap mechanism that might prevent a secure connection.

Difficulty in snapping/unsnapping:

- Ensure proper alignment of the cap and stud before pressing them together.
- If new, snaps may be stiff initially; they should loosen with regular use.
- Avoid excessive force, which can damage the snap or the surrounding material.

7. SPECIFICATIONS

Brand	Prym
Model Name	4111050
Item Model Number	390211
ASIN	B00DOXC1JS
Diameter	15 Millimeters
Number of Pieces	10

Material	Brass
Product Dimensions	15L x 15W millimeters
Recommended Uses	Sport and leisure wear, heavy-duty use
Assembly Required	No (assembly of components is part of installation)
Batteries Required	No

8. SUPPORT INFORMATION

For further assistance or inquiries regarding your Prym Tent Snap Fasteners, please contact Prym customer service. When contacting support, please refer to the product Model Name 4111050 and ASIN B00DOXC1JS for efficient service.

You can find more information and contact details on the official Prym website or through your retailer.