#### Manuals+

Q & A | Deep Search | Upload

## manuals.plus /

- > Coleman /
- > Coleman Instant Canopy Accessory Panel 7x5 User Manual

#### Coleman 2000012374

# Coleman Instant Canopy Accessory Panel 7x5 User Manual

Model: 2000012374

#### INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Coleman Instant Canopy Accessory Panel 7x5. Please read this manual thoroughly before use to ensure safe and effective operation. This accessory panel is designed to provide additional sun and wind protection for compatible Coleman Instant Canopies (sold separately).

# SAFETY INFORMATION

Always prioritize safety when using outdoor equipment. Failure to follow these instructions may result in injury or damage to the product.

- Keep a safe distance from heat sources. Do not use in areas with fire risk.
- Secure the canopy and accessory panel firmly in place before use, especially in windy conditions.
- This panel provides UV protection, but prolonged exposure to direct sunlight should still be avoided. Protect your skin and eyes from the sun.
- Ensure the canopy frame is stable and properly erected before attaching the accessory panel.
- Do not use the accessory panel as a primary shelter in severe weather conditions.

## PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- Coleman Instant Canopy Accessory Panel (7x5 feet)
- Attachment hardware (if applicable, e.g., clips, hooks)

Note: The Coleman Instant Canopy frame is sold separately and is required for use with this accessory panel.

# **SETUP INSTRUCTIONS**

Follow these steps to attach the accessory panel to your Coleman Instant Canopy.

1. **Prepare the Canopy:** Ensure your Coleman Instant Canopy is fully erected and securely anchored according to its own instruction manual.



Image: A Coleman Instant Canopy with the accessory panel installed, offering shade to individuals seated below. This illustrates the panel's function when properly set up.

- 2. **Unfold the Panel:** Carefully unfold the Coleman Instant Canopy Accessory Panel. Identify the top and bottom edges, and the attachment points (e.g., hooks, loops, or Velcro straps).
- 3. **Attach Top Edge:** Align the top edge of the accessory panel with the canopy's frame or designated attachment points. Secure the panel using the integrated hooks, loops, or Velcro straps provided. Ensure a snug fit along the top.



Image: A close-up view of the Coleman Instant Canopy Accessory Panel, demonstrating its attachment to the canopy frame. The green fabric provides a visual representation of the product.

4. **Secure Side Edges:** Work your way down the sides of the panel, attaching it to the canopy legs or frame using the remaining attachment points. Ensure the panel is taut to prevent flapping in the wind.



Image: An angled view of the Coleman Instant Canopy with a single accessory panel installed. This perspective highlights how the panel integrates with the canopy structure.

5. **Final Adjustment:** Once all attachment points are secured, check the panel for proper tension and alignment. Adjust as necessary. The panel should cover the desired area of the canopy.



Image: The Coleman Instant Canopy with its accessory panel fully set up in an outdoor environment, demonstrating its appearance and function in a typical use scenario.

# **OPERATION AND USE**

The accessory panel is designed to enhance your canopy experience by providing additional protection.

- Sun Protection: The panel features UVGuard<sup>™</sup> protection, blocking a significant portion of the sun's harmful UV
  rays. Position the panel on the side facing the sun for maximum shade.
- Wind Protection: The panel helps to reduce wind exposure within the canopy area. Ensure it is securely fastened to prevent it from being dislodged by gusts.
- Privacy: The panel can also offer increased privacy, depending on its placement.

Important: This panel is an accessory and does not provide structural support to the canopy. Always ensure the main canopy structure is stable.

## CARE AND MAINTENANCE

Proper care will extend the life of your accessory panel.

- **Cleaning:** Clean the panel with a mild soap solution and a soft cloth or sponge. Rinse thoroughly with clean water. Do not use harsh detergents, bleach, or abrasive cleaners.
- Drying: Ensure the panel is completely dry before folding and storing to prevent mildew and odor.
- Storage: Store the panel in a cool, dry place, away from direct sunlight and extreme temperatures.
- Inspection: Periodically inspect the fabric and attachment points for any signs of wear or damage. Repair minor tears promptly to prevent them from worsening.

## **TROUBLESHOOTING**

Problem	Possible Cause	Solution
Panel sags or flaps excessively.	Insufficient tension or loose attachment points.	Re-secure all attachment points, ensuring the panel is pulled taut. Check for proper canopy frame setup.
Difficulty attaching the panel.	Incorrect orientation or canopy not fully extended.	Ensure the canopy is fully erected. Verify the panel's orientation (top/bottom, inside/outside).
Panel appears damaged after use.	Exposure to extreme weather or sharp objects.	Inspect for tears or punctures. Small tears can be repaired with a fabric repair kit. Avoid using in severe weather.

#### **SPECIFICATIONS**

• Model: 2000012374

• **Dimensions:** 7 x 5 feet (approximately 2.1 x 1.5 meters)

• Material: Blended Fabric

UV Protection: UVGuard™ (50+ UPF)
 Weight: Approximately 227 g (0.5 lbs)

• Compatibility: Designed for Coleman Instant Canopies (2.8 x 1.5 m or 7 x 5 ft models)

• Part Number: 2000012374

• UPC: 076501096842

# WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Coleman website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Coleman Official Website: www.coleman.com

Note: Warranty terms and conditions may vary by region.



© 2024 Coleman. All rights reserved.

This manual is for informational purposes only. Coleman reserves the right to make changes to products and specifications without notice.

#### Related Documents - 2000012374



## Coleman Propane Camp Stove Model 5435-700 Parts and Diagram

Detailed parts list and diagram for the Coleman Propane Camp Stove, Model 5435-700. Includes specifications and part numbers for easy identification and replacement.



#### Auvent Gonflable Coleman Air: Manuel d'Utilisation et Guide d'Installation



Instructions détaillées pour l'installation, l'utilisation et l'entretien de votre auvent gonflable Coleman Air. Inclut des avertissements de sécurité et des conseils de réparation.



## Coleman Instant Tent Setup and Storage Guide

Comprehensive instructions for setting up, staking, securing guylines, disassembling, and storing your Coleman Instant Tent with SH, 4 Legs. Includes important safety warnings and care tips.



## Coleman 360 Light & Sound Lantern: FCC & IC Compliance Information

Detailed FCC and Industry Canada (IC) compliance statements, RF exposure warnings, and operational guidelines for the Coleman 360 Light & Sound Lantern (Model 2000033083R).



CONSUMERUSER. This instruction manual contains important information necessary for the contains important information necessary for the contains important information necessary for the contains a contain co

# Coleman Sportster II Dual Fuel Stove: User Manual and Safety Guide

Comprehensive instruction manual for the Coleman Sportster II Dual Fuel Stove (Model 533 Series). Learn about safe operation, assembly, maintenance, troubleshooting, and warranty for this versatile outdoor camping stove.



## Coleman 90467E Bahamas AirJet Spa Owner's Manual

This manual provides instructions for the setup, use, maintenance, and troubleshooting of the Coleman 90467E Bahamas AirJet Spa. It includes important safety information, parts checks, installation guides, and error code explanations.