Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pibbs 3800BLK

Pibbs Twin Turbo 3800 Ionic & Ceramic Hair Dryer User Manual

Model: 3800BLK | Brand: Pibbs

Important Safety Information

Please read all safety instructions before using the appliance. Failure to follow these instructions may result in electric shock, fire, or injury.

- Keep out of reach of children.
- Do not use near water sources, such as bathtubs, showers, basins, or other vessels containing water.
- Keep the power plug and cord away from heated surfaces.
- Do not use while bathing.
- Always unplug the appliance immediately after use.

Product Features

- **Ionic and Ceramic System:** Produces negative ions and utilizes exotic ceramics for healthier, shinier hair.
- **Powerful Motor:** 2100 Watt motor, Made in Italy.
- **Multiple Settings:** 2 speeds and 4 temperature settings for versatile styling.
- **Cold Air Microswitch:** Provides immediate cold air for setting styles.
- **Low Noise:** Built-in silencer for reduced operating noise.
- **Fast Drying:** Up to 60% faster drying time.
- **Ozone Friendly:** Designed with no harmful emissions.
- **Flexible Cable:** Highly flexible 3-meter power cable.
- **Durable Nozzles:** Includes two unbreakable nozzles.
- **Energy Saving:** Efficient design for quick drying and energy conservation.

Setup

Before first use, ensure all packaging materials are removed. Inspect the hair dryer for any visible damage. If any damage is found, do not use the appliance and contact customer support.

Attaching the Nozzles

1. Select the desired nozzle (narrow or wide) for your styling needs.
2. Align the nozzle with the front opening of the hair dryer.
3. Gently push the nozzle onto the hair dryer until it clicks securely into place.
4. Ensure the nozzle is firmly attached before operating the appliance.



Figure 1: The two included nozzles for the Pibbs Twin Turbo 3800 hair dryer. These nozzles help concentrate airflow for targeted drying and styling.

Operating Instructions

The Pibbs Twin Turbo 3800 hair dryer is designed for efficient and professional hair drying. Familiarize yourself with the controls before use.

Powering On and Off

- Plug the power cord into a suitable electrical outlet.
- Locate the main power switch on the handle.
- Slide the switch to the 'ON' position to start the hair dryer.
- To turn off, slide the switch back to the 'OFF' position.

Adjusting Speed and Temperature

The hair dryer features separate controls for speed and temperature, allowing for customized drying.

- **Speed Settings:** Use the speed switch (usually marked with 'I' and 'II' or similar) to select between two airflow speeds. 'I' is for gentle drying, 'II' is for fast drying.
- **Temperature Settings:** Use the temperature switch (usually marked with symbols for cool, warm, hot) to select one of four heat levels.

Using the Cold Air Shot

The immediate cold air microswitch is ideal for setting your hairstyle and adding shine.

- While the hair dryer is running, press and hold the cold air button (often red or blue) to instantly switch to cool air.
- Release the button to return to the previously selected heat setting.





Figure 2: Side view of the Pibbs Twin Turbo 3800 hair dryer, highlighting the ergonomic design and control switches for speed and temperature.





Figure 3: Rear view of the Pibbs Twin Turbo 3800 hair dryer, illustrating the air intake filter and the placement of the control switches on the handle.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your hair dryer.

Cleaning the Air Intake Filter

The rear filter prevents hair and dust from entering the motor. Clean it regularly to maintain airflow and prevent overheating.

1. Ensure the hair dryer is unplugged from the power outlet and completely cool.
2. Gently twist or pull off the rear filter cover (refer to Figure 3 for location).
3. Remove any accumulated hair or lint using a soft brush or by hand.
4. If necessary, wipe the filter with a damp cloth and allow it to dry completely before reattaching.
5. Replace the filter cover by aligning it and twisting or pushing until it locks.

General Cleaning and Storage

- Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Never immerse the hair dryer in water or any other liquid.
- Store the appliance in a cool, dry place, away from moisture and direct sunlight.
- Do not wrap the power cord tightly around the appliance, as this can damage the cord.

Troubleshooting

If you encounter any issues with your Pibbs Twin Turbo 3800 hair dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply; faulty outlet; power switch off.	Check if the plug is securely inserted. Try a different outlet. Ensure the power switch is in the 'ON' position.
Weak airflow or overheating.	Blocked air intake filter; internal component issue.	Clean the air intake filter as described in the Maintenance section. If the problem persists, contact customer support.
Unusual noise during operation.	Debris in the motor; internal fan issue.	Unplug the hair dryer and check for any visible obstructions. If the noise continues, contact customer support.

If the problem cannot be resolved using these steps, please contact Pibbs customer support for assistance.

Specifications

Feature	Detail
Brand	Pibbs
Model Number	3800BLK
Power Source	Corded Electric
Wattage	2100 watts
Material	Ceramic
Product Dimensions	0.04 x 0.04 x 0.04 inches
Item Weight	2.11 Pounds
UPC	799665011765

Warranty and Support

For warranty information or technical support, please contact Pibbs customer service. Details regarding specific warranty periods and coverage may be found on the product packaging or the official Pibbs website.
Always refer to the manufacturer's official channels for the most accurate and up-to-date support information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00DQD847Y

More documents and user manuals: **https://manuals.plus/**