

[Manuals.plus](#) /

> [SEIKO](#) /

> SEIKO Series 5 Automatic Silver Dial Men's Watch SNKL58 Instruction Manual

## SEIKO SNKL58

# SEIKO Series 5 Automatic Silver Dial Men's Watch SNKL58 Instruction Manual

Model: SNKL58

Brand: SEIKO

## INTRODUCTION

This manual provides essential information for the proper use and care of your SEIKO Series 5 Automatic Silver Dial Men's Watch, model SNKL58. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece. The watch features a silver-tone dial, yellow gold-plated stainless steel case and band, and an automatic movement with 30 meters / 100 feet water resistance.

## PRODUCT OVERVIEW



Front view of the SEIKO Series 5 Automatic Silver Dial Men's Watch SNKL58, showcasing the silver-tone dial with gold-plated hands and markers, and a yellow gold-plated stainless steel case and band.



Rear view of the SEIKO SNKL58 watch, displaying the transparent case back that reveals the automatic movement.



The watch is presented in a standard SEIKO packaging box.

The SEIKO Series 5 SNKL58 is an automatic mechanical watch, meaning it is powered by the motion of your wrist and does not require a battery. It features a day-date display and a durable Hardlex crystal. The watch is designed for everyday wear and offers a classic aesthetic.

## SETUP

---

### Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch) out to the second click position.
2. **Set the time:** Rotate the crown to move the hands clockwise until the desired time is displayed. Ensure to set the correct AM/PM by observing the day-date change. If setting the time between 9 PM and 4 AM, it is recommended to first set the time outside this window (e.g., to 6 AM) to avoid damaging the date mechanism, then adjust the date, and finally set the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its normal position.

### Setting the Day and Date

1. **Pull out the crown:** Gently pull the crown out to the first click position.
2. **Set the date:** Rotate the crown clockwise to adjust the date.

3. **Set the day:** Rotate the crown counter-clockwise to adjust the day. The day display may offer multiple languages (e.g., English and Spanish).
4. **Push in the crown:** Once the day and date are set, push the crown back into its normal position.

## OPERATING YOUR AUTOMATIC WATCH

Your SEIKO Series 5 watch is an automatic mechanical timepiece. It is powered by the natural motion of your wrist. When worn regularly, the mainspring will be wound automatically, providing continuous operation.

- **Initial Winding:** If the watch has stopped, gently swing it from side to side in a horizontal arc for about 30 seconds to initiate movement. This will provide enough power for it to start ticking.
- **Power Reserve:** A fully wound Seiko 5 automatic watch typically has a power reserve of approximately 40 hours. If the watch is not worn for an extended period, it will stop. Simply repeat the initial winding process to restart it.
- **Water Resistance:** The SNKL58 model has a water resistance of 30 meters (100 feet). This rating means the watch is suitable for splashes or brief immersion in water, but it is not recommended for swimming, diving, or showering. Avoid operating the crown while the watch is wet.

## MAINTENANCE

- **Cleaning:** Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dirt and moisture. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not expose your watch to solvents, detergents, perfumes, or cosmetics, as these can damage the case, bracelet, or gaskets.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the movement's accuracy and the watch's water resistance.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones) as magnetism can affect the accuracy of mechanical watches. If your watch becomes magnetized, it may need to be demagnetized by a professional.
- **Servicing:** For optimal performance, it is recommended to have your automatic watch serviced by an authorized SEIKO service center every 3-5 years.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped or runs intermittently.	Insufficient winding (not enough wrist movement).	Gently swing the watch from side to side for about 30 seconds to initiate movement. Wear the watch regularly for at least 8-10 hours a day.
Time is inaccurate (running fast or slow).	Exposure to strong magnetic fields; needs regulation.	Keep away from magnetic sources. If problem persists, consult an authorized service center for demagnetization or regulation.
Day/Date not changing correctly.	Set during the "forbidden zone" (9 PM - 4 AM); mechanism issue.	Avoid setting day/date between 9 PM and 4 AM. If issue continues, professional inspection is required.
Moisture or condensation inside the crystal.	Water resistance compromised; extreme temperature change.	Immediately take the watch to an authorized service center. Do not attempt to dry it yourself.

## SPECIFICATIONS

---

- **Model Number:** SNKL58K
- **Movement:** Automatic (Self-winding)
- **Jewels:** 21 Jewels
- **Case Material:** Yellow Gold-plated Stainless Steel
- **Case Diameter:** 38 mm
- **Case Thickness:** 11 mm
- **Dial Color:** Silver-tone
- **Crystal:** Hardlex
- **Band Material:** Yellow Gold-plated Stainless Steel
- **Clasp Type:** Fold Over with Safety Release
- **Water Resistance:** 30 meters (100 feet)
- **Functions:** Day, Date, Hour, Minute, Second

## WARRANTY AND SUPPORT

---

Your SEIKO watch is backed by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For any service, repairs, or inquiries, please contact an authorized SEIKO service center or the retailer from whom you purchased the watch.

Protection plans are available for extended coverage:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan covering eligible past and future purchases)

For more information, visit the official SEIKO Store: [SEIKO Store on Amazon](#).