

[manuals.plus](#) /

› [Fossil](#) /

› [Fossil Men's Coachman Quartz Stainless Steel and Leather Chronograph Watch CH2891 User Manual](#)

Fossil CH2891

Fossil Men's Coachman Quartz Stainless Steel and Leather Chronograph Watch CH2891 User Manual

Model: CH2891

INTRODUCTION

This manual provides comprehensive instructions for the proper use and care of your Fossil Men's Coachman Quartz Stainless Steel and Leather Chronograph Watch, Model CH2891. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Image: Front view of the Fossil Men's Coachman Chronograph Watch, featuring a black dial with orange accents and a brown leather cuff strap.

SETUP

Setting the Time

1. Pull the crown (the knob on the side of the watch) out to position 2.
2. Turn the crown to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into position 0.

Setting the Date

1. Pull the crown out to position 1.
2. Turn the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the automatic date change mechanism.
3. Once the date is set, push the crown back into position 0.

Battery Information

This watch requires 1 Lithium Metal battery (included). For battery replacement, it is recommended to consult a professional watch technician to ensure proper sealing and water resistance.

OPERATING THE CHRONOGRAPH

The Fossil Coachman watch features a chronograph function with three sub-dials for enhanced timekeeping.





Image: Detailed view of the watch dial, highlighting the three chronograph sub-dials and date window.

Chronograph Functions:

- **Start/Stop:** Press the top pusher (button) to start and stop the chronograph.
- **Reset:** With the chronograph stopped, press the bottom pusher to reset all chronograph hands to zero.
- **Sub-dials:** The three sub-dials track minutes, seconds, and 24-hour time, providing full chronograph functionality.

MAINTENANCE

Leather Strap Care

The genuine leather cuff strap is designed for comfort and durability. To maintain its quality:

- Avoid prolonged exposure to water, direct sunlight, and harsh chemicals.
- Clean the strap with a soft, dry cloth. For deeper cleaning, use a specialized leather cleaner and conditioner.
- Allow the strap to air dry completely if it gets wet.




Image: Rear view of the watch, showcasing the genuine leather strap and its attachment to the watch case.

Water Resistance

This watch is water resistant up to 100 meters (330 feet), or 10 ATM. This makes it suitable for bathing, swimming, or snorkeling. However, it is **not** designed to withstand the pressure of scuba diving. Always ensure the crown is fully pushed in before exposing the watch to water.

TROUBLESHOOTING

- **Watch Not Running:** Check if the crown is fully pushed into position 0. If the watch still does not run, the battery may need replacement.
- **Incorrect Time/Date:** Refer to the "Setting the Time" and "Setting the Date" sections in this manual to re-adjust.
- **Chronograph Not Resetting:** Ensure the chronograph is stopped before pressing the reset pusher. If issues persist, professional servicing may be required.

SPECIFICATIONS

Feature	Detail
Model Number	CH2891
Case Size	44mm
Band Width	22mm
Case Material	Stainless Steel
Strap Material	Genuine Leather (Calfskin)
Movement	Quartz Chronograph
Crystal	Hardened Mineral
Water Resistance	10 ATM (100m / 330ft)
Functions	Chronograph (minutes, seconds, 24-hour), Date Window
Product Dimensions	5.91 x 5.91 x 5.91 inches; 3.39 ounces



Image: Men's Case Size Guide, illustrating different watch diameters and case thicknesses for reference.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An overview of the Fossil Men's Coachman Quartz Stainless Steel and Leather Casual Watch, highlighting its design and features.

WARRANTY AND SUPPORT


Your Fossil watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For further assistance, product registration, or service inquiries, please visit the official Fossil website or contact their customer support.

You can visit the official Fossil Store for more information:[Fossil Store on Amazon](#)

© 2023 Fossil. All rights reserved. This manual is for informational purposes only.

Related Documents - CH2891

	<p>Fossil World Timer Solar Watch Warranty Information and User Manual</p> <p>Comprehensive warranty information and user guide for the Fossil World Timer Solar Watch, covering time and date settings, chronograph, countdown timer, alarm, world time, compass, solar power, and water resistance.</p>
	<p>Fossil Smartwatch Quick Start Guide</p> <p>Get started with your Fossil smartwatch. This guide covers initial setup, charging, and connecting to your phone using the Android Wear app. It also includes essential health, safety, and regulatory information.</p>
	<p>Fossil Q Smartwatch Quick-Start Guide</p> <p>A quick-start guide for the Fossil Q Smartwatch, covering navigation, charging, notifications, apps, and staying connected.</p>

	<p>Fossil Watch Instruction Manuals: Analog, Digital, Automatic, and Multifunction Models</p> <p>Comprehensive guide to operating and setting various Fossil watch models, including analog, digital, analog-digital, automatic, mechanical, multifunction, chronograph, and stopwatch types. Covers time, date, alarm, and other functions.</p>
	<p>Fossil Q Hybrid Smartwatch Quick-Start Guide</p> <p>Get started with your Fossil Q Hybrid Smartwatch. This guide covers setup, notifications, battery replacement, strap changes, activity tracking, and staying connected. Learn to customize buttons and troubleshoot connectivity issues.</p>
	<p>Fossil DW13F3 Smartwatch Warranty and Information</p> <p>Comprehensive warranty, safety, and regulatory information for the Fossil DW13F3 Smartwatch, provided by Fossil Group, Inc. Learn about product coverage, safe usage, and compliance.</p>