

Casio BGA-170-9BDR

Casio Baby-G BGA-170-9BDR Watch User Manual

Model: BGA-170-9BDR

INTRODUCTION

This manual provides essential information for the proper use and care of your Casio Baby-G BGA-170-9BDR wristwatch. Please read these instructions carefully to ensure optimal performance and longevity of your watch. This watch is designed for women and features both analog and digital displays, along with robust shock resistance and 100-meter water resistance.

SETUP

Initial Time Setting

Upon first use or after a battery change, you may need to set the current time and date. Refer to the detailed instructions in the official Casio module manual for your specific model (BGA-170) for precise button operations. Generally, you will use the adjustment buttons (usually located on the sides of the watch case) to navigate through settings modes and adjust hours, minutes, seconds, year, month, and day.

Battery Information

Your watch comes with one Lithium-metal battery already installed. The battery provides power for the watch's functions. When the battery runs low, the display may dim or functions may become erratic. It is recommended to have the battery replaced by a qualified watch technician to ensure water resistance is maintained.



Image: Front view of the Casio Baby-G BGA-170-9BDR watch, showcasing its yellow resin band and case, and the white dial with large, stylized numbers.

OPERATING

Basic Timekeeping

The watch displays time in both analog (hands) and digital formats. The analog hands show the current hour and minute, while the digital display provides additional information such as seconds, day of the week, and date. Ensure the time is synchronized between the analog and digital displays after setting.

Using the Backlight

To illuminate the watch face in low-light conditions, press the light button (typically located on the upper right or lower right side of the watch case). The backlight will activate for a few seconds, making the

display visible. This model features a bright LED backlight.



Image: Close-up of the Casio Baby-G BGA-170-9BDR watch face with its green LED backlight activated, clearly showing the time and day of the week in the dark.

Other Functions

Your Baby-G watch may include various functions such as a stopwatch, countdown timer, multiple alarms, and world time. Consult the full Casio module manual for detailed instructions on how to access and operate each specific function using the watch's buttons.

MAINTENANCE

Cleaning

To clean your watch, wipe it with a soft, dry cloth. For stubborn dirt, use a soft cloth dampened with water and a mild neutral detergent, then wipe dry. Avoid using volatile agents like thinner, gasoline, alcohol, or chemical cleaners, as they can damage the resin components and finish.

Water Resistance

This watch is water resistant up to 100 meters (10 BAR). This means it is suitable for swimming, showering, and snorkeling. However, avoid operating buttons while the watch is submerged in water or wet, as this can compromise the water resistance. After exposure to saltwater, rinse the watch with fresh water and wipe it dry.

Battery Replacement

When the battery needs replacement, it is highly recommended to take your watch to an authorized Casio service center or a reputable watch repair shop. This ensures that the correct battery type is used and that the watch's water resistance gasket is properly inspected and replaced if necessary.



Image: Rear view of the Casio Baby-G BGA-170-9BDR watch, showing the stainless steel case back and the yellow resin band with its buckle.

TROUBLESHOOTING

Incorrect Time Display

If the analog or digital time is incorrect, refer to the 'Initial Time Setting' section under Setup and the official Casio module manual to re-adjust the time. Ensure both analog and digital displays are synchronized.

Digital Display Blank or Dim

A blank or dim digital display often indicates a low battery. Arrange for battery replacement as soon as possible. If the issue persists after battery replacement, contact customer support.

Buttons Not Responding

If buttons are unresponsive, check if the watch is in a special mode (e.g., locked mode, if applicable). If not, a low battery could be the cause. If the problem continues, professional inspection may be required.

SPECIFICATIONS

- **Model Number:** BGA-170-9BDR
- **Brand:** Casio
- **Department:** Women
- **Display Type:** Analog-Digital
- **Movement Type:** Japanese Quartz
- **Power Source:** Battery (1 Lithium-metal, included)
- **Water Resistance:** 100 Meters (10 BAR)
- **Case Material:** Plastic (Resin)
- **Crystal Material:** Mineral Glass
- **Case Diameter:** Approximately 50 Millimeters

- **Case Thickness:** Approximately 14 Millimeters
- **Band Width:** Approximately 16 Millimeters
- **Band Color:** Yellow
- **Dial Color:** White
- **Clasp Type:** Buckle
- **Product Dimensions:** 9.8 x 11 x 9.8 cm; 45 g

WARRANTY

This Casio Baby-G BGA-170-9BDR watch comes with a 2-year warranty provided by Amazon.com, facilitated by Asurion. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation provided at the time of purchase or contact Amazon.com customer service.



Image: An example of a warranty card. Please refer to your specific Amazon.com warranty details for accurate coverage.

SUPPORT

For further assistance, detailed operating instructions, or service inquiries, please refer to the official Casio website or contact Casio customer support directly. You may also contact Amazon.com customer service for warranty-related questions or product support.

Casio Official Website: www.casio.com

Amazon.com Customer Service: Visit the 'Help' section on the Amazon.com website.