

Sony MH750

Sony MH750 Stereo 3.5mm Headset Instruction Manual

Model: MH750

INTRODUCTION

Thank you for choosing the Sony MH750 Stereo 3.5mm Headset. This manual provides essential information for the proper setup, operation, and maintenance of your headset. Please read these instructions carefully before use and retain them for future reference.

PACKAGE CONTENTS

Your Sony MH750 Stereo 3.5mm Headset package typically includes:

- Sony MH750 Stereo 3.5mm Headset
- Various sizes of ear tips (small, medium, large)
- Cable clip



Image: Sony MH750 headset components, including the main headset unit and a separate bag containing ear tips and a cable clip.

SETUP

1. **Select Appropriate Ear Tips:** Choose the ear tips that provide the most comfortable and secure fit for your ears. A good seal is crucial for optimal sound quality and bass response. Gently pull off the pre-installed ear tips and push on the desired size.
2. **Connect to Device:** Insert the 3.5mm jack of the headset firmly into the headphone port of your audio device (e.g., smartphone, tablet, MP3 player). Ensure the connection is secure.



Image: The Sony MH750 headset, showing the earbuds, inline microphone/control, and 3.5mm jack.

3. **Positioning:** Place the earbuds comfortably into your ears. The left earbud is typically marked with an 'L' and the right with an 'R'. Adjust the cable for comfort, using the included cable clip if desired to secure it to clothing.

OPERATING INSTRUCTIONS

Audio Playback

Once connected, your device should automatically route audio through the headset. Adjust the volume using your device's volume controls.

Call Management (Inline Control Button)

The MH750 headset features an inline control button for managing calls and media playback. Functionality may vary depending on your connected device and operating system.

- **Single Press:** Answer/End a call, Play/Pause music.
- **Double Press:** Skip to the next track (for music playback).
- **Triple Press:** Go back to the previous track (for music playback).

Note: Some devices may not fully support all inline control functions. If you experience issues with the answer/end button, please refer to your device's manual for headset compatibility.

Microphone Usage

The integrated microphone allows for hands-free communication during calls. Position the microphone close to your mouth for clear voice transmission.

MAINTENANCE

- **Cleaning:** Regularly clean the ear tips with a soft, dry cloth. For deeper cleaning, remove the ear tips and wash them gently with mild soap and water, ensuring they are completely dry before reattaching. Do not use harsh chemicals or abrasive materials on any part of the headset.
- **Storage:** When not in use, store the headset in a clean, dry place, away from extreme temperatures and direct sunlight. Avoid tangling the cable by coiling it loosely.
- **Handling:** Avoid pulling on the cable to disconnect the headset from your device. Always grasp the 3.5mm jack directly. Do not expose the headset to excessive force or impact.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or low volume	Volume too low on device; Headset not fully plugged in; Incorrect audio output selected on device.	Increase device volume; Ensure 3.5mm jack is fully inserted; Check device audio settings to confirm headset is selected as output.
Poor sound quality (e.g., distorted, muffled)	Ear tips not properly sealed; Dirty ear tips/grilles; Damaged cable/jack.	Try different ear tip sizes for a better seal; Clean ear tips and grilles; Test with another audio device to rule out device issues. If still poor, the headset may be damaged.
Microphone not working	Microphone muted on device; Headset not fully plugged in; Device compatibility issue.	Check device settings for microphone input; Ensure 3.5mm jack is fully inserted; Test with another device to check microphone functionality.
Inline control button not responding	Device compatibility issue; Software glitch on device.	Restart your device; Test the headset with another compatible device to verify button functionality. Note that not all functions may be supported by all devices.

SPECIFICATIONS

- **Brand:** Sony
- **Model:** MH750
- **Connectivity Technology:** Wired
- **Headphones Jack:** 3.5 mm Jack

- **Color:** Black
- **Control Method:** Touch (via inline button)
- **Additional Features:** Stereo audio, Integrated microphone
- **Item Weight:** Approximately 1.4 Ounces *(Note: Original data listed 1.4 Pounds, which is likely a typo for a headset)*

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Sony website or contact Sony customer service. Keep your proof of purchase for warranty claims.

You can find more information and support resources at the [Sony Store on Amazon](#).